

Nokia Eksos N20

Narrowband Multiservice Access Node System Release C2.0 DEU

User Manual

C33993.20 B0

NOKIA



The following products comply with the protection requirements of the European Union Council Directive 89/336/EEC relating to electromagnetic compatibility (EMC), provided that installed using EMC-compatible installation practices (installation in mechanical housings stated to be EMC-compatible and using cabling material [at least as well shielded] and practices as stated in relevant Nokia Networks user manuals):

Product code	Product name	Release
Eksos N20	Narrowband Multiservice Access Node (see the System Release Item List)	C2.0 DEU

The information in this document is subject to change without notice and describes only the product defined in the introduction of this documentation. This document is intended for the use of Nokia Networks' customers only for the purposes of the agreement under which the document is submitted, and no part of it may be reproduced or transmitted in any form or means without the prior written permission of Nokia Networks. The document has been prepared to be used by professional and properly trained personnel, and the customer assumes full responsibility when using it. Nokia Networks welcomes customer comments as part of the process of continuous development and improvement of the documentation.

The information or statements given in this document concerning the suitability, capacity, or performance of the mentioned hardware or software products cannot be considered binding but shall be defined in the agreement made between Nokia Networks and the customer. However, Nokia Networks has made all reasonable efforts to ensure that the instructions contained in the document are adequate and free of material errors and omissions. Nokia Networks will, if necessary, explain issues which may not be covered by the document.

Nokia Networks' liability for any errors in the document is limited to the documentary correction of errors. Nokia Networks WILL NOT BE RESPONSIBLE IN ANY EVENT FOR ERRORS IN THIS DOCUMENT OR FOR ANY DAMAGES, INCIDENTAL OR CONSEQUENTIAL (INCLUDING MONETARY LOSSES), that might arise from the use of this document or the information in it.

This document and the product it describes are considered protected by copyright according to the applicable laws.

NOKIA logo is a registered trademark of Nokia Corporation.

Any other trademarks mentioned in the documents are the property of their respective companies, and they are mentioned for identification purposes only.

Copyright © Nokia Corporation 2002–2003. All rights reserved.

Document History

Document	Date	Comment
C33993001PE_00	20 Sep 2002	
C33993001PE_A0	29 Jan 2003	System Release Notes updated.

Contents

1	Guide to Documentation	C33836004SE_01
2	Installation	C33836005SE_B0
3	Commissioning and Maintenance	C33836006SE_D0
4	System Release Item List	EKN C2.0HA.1
5	System Release Notes	C33993002SE_A0
6	Product Description	C33836008SE_A1
7	Specific Instructions for Germany	C33993003SE_00
8	Glossary	C33836010SE_01
9	Index	C33993004SE_A0

Nokia Eksos N20

Narrowband Multiservice Access Node

Guide to Documentation

4 Jan 2002

1 About this document

This document describes the contents of the *Nokia Eksos N20 User Manual* and includes:

- a navigation aid for the documents included in the user manual
- a short description of the documents included in the user manual
- product codes of the Eksos N20 documents and documents of related products
- instructions for ordering the documents
- a description of typographic conventions.

For brevity, the name *Eksos N20* is used in place of Nokia Eksos N20 throughout this manual.

Readership

This manual is for the application planning, installation and commissioning personnel of the Eksos N20 Node. The reader is assumed to have basic knowledge of V5, SDH and PCM voice transmission.

Your comments

We appreciate your feedback. If you have any comments about this or any other manual, please fill in the documentation comment form in the beginning of this manual and return it to your local Nokia representative.

2 Contents of the User Manual

This chapter helps you to find the documents that help you in accomplishing your tasks. The navigation aid in Table 1 lists the documents, which are then described briefly in the order that they appear in the manual.

Task	Documents
Finding your way through the manual	– Guide to Documentation – Index – Glossary
Familiarisation with Eksos N20	– Product Description
Planning the application	– Product Description – System Release Item List – System Release Notes – Country-Specific Instructions
Installing Eksos N20	– Installation
Commissioning Eksos N20	– Commissioning and Maintenance – System Release Notes – Country-Specific Instructions
Maintaining and upgrading Eksos N20	– Commissioning and Maintenance – System Release Notes

Table 1 Navigation aid

Installation

- installation procedure
- instructions for routing the cables
- instructions for connecting power supplies and station alarms
- instructions for installing the subrack or cartridge
- instructions for protective earthing
- instructions for installing cable trays
- instructions for connecting interfaces
- instructions for installing plug-in units
- instructions for Ethernet cabling
- instructions for installing auxiliary equipment and accessories.

Commissioning and Maintenance

- commissioning requirements and procedure
- detailed instructions for commissioning
- instructions for managing alarms
- instructions for upgrading
- instructions for installing and using Eksos N20 Node Manager
- list of alarm messages.

System Release Item List

- lists all the products and the product codes for the hardware items and their respective software.

System Release Notes

- compatibility with other products
- new features
- known problems and remedies.

Product Description

- detailed information needed, for example, for application planning: examples of network and node applications, network management tools, construction, power supply, and specifications.

Country-Specific Instructions

- instructions for configuring country-specific settings
- brief description of the key features supported by the mapping.

Glossary

- all technical abbreviations used in the manual
- key terms.

Index

- tool to locate key information in the *Eksos N20 User Manual*.

Note

The *Eksos N20 User Manual* does not provide any in depth description of the SYNFO NET Access Node (SAN). For a detailed description of SAN, refer to its documentation.

3 Ordering documents

Tables 2 and 3 contain the titles of the documents and the product codes that are needed when ordering them.

To order the documents, contact your Nokia sales representative.

Eksos N20 documents	Product code
Nokia Eksos N20 Product Overview	C33478.20
Nokia Eksos N20 C2.0 Upgrade Instructions	C33836.22
ACCNODE CD-ROM	C33463.93

Table 2 Product codes for Eksos documents

Documents of related products	Product code
T35025.** OSI-DCN Adaptor User Manual	C33585.20
T30406 ETSI Rack Installation Instructions	C33472.20
T30400.01/.02 ETSI Rack Installation Instructions	C33912.20
DC-PSA Operating Instructions	C33470.20
Fuse Terminal Operating Instructions	C33508.20
Fan Unit Operating Instructions	C33461.20

Table 3 Product codes for documents of related products

There is no separate *Nokia Eksos N20 Node Manager User's Manual*. Instructions on how to start using Eksos N20 Node Manager are given in the *Commissioning and Maintenance* document of the *Eksos N20 User Manual* and in the on-line help of the Nokia Eksos N20 Node Manager software.

The *Product Overview* describes the basic features and applications of the Eksos N20 Node. It presents general information about the product and is not tied to any specific Eksos N20 release.

The *ACCNODE CD-ROM* includes the customer documents of Nokia's Access Nodes and the documents for the related mechanical structures and power supplies.

4 Typographic conventions

Table 4 presents the typographic conventions used in the *Eksos N20 User Manual*.

Convention	Meaning
<i>Italic font</i>	Indicates a word or phrase that is emphasised, or a reference to the title of a manual, for example: Refer to the <i>Nokia Eksos N20 User Manual</i> .
Bold font	Indicates the title of a window, or an option, command, field, group or button, or anything that you must type exactly as it appears, for example: Help → Index means: choose Index from the Help menu. A:\install means: type A:\install
ALL CAPITALS	Indicate a directory or file name, for example: INSTALL.EXE
SMALL CAPITALS	Indicate the keys of the terminal keyboard, for example: CTRL
▶	Indicates the start of a procedure.
_____	Indicates the end of a document.

Table 4 Typographic conventions

Nokia Eksos N20

Narrowband Multiservice Access Node

Installation

NOKIA

The information in this document is subject to change without notice and describes only the product defined in the introduction of this documentation. This document is intended for the use of Nokia Networks' customers only for the purposes of the agreement under which the document is submitted, and no part of it may be reproduced or transmitted in any form or means without the prior written permission of Nokia Networks. The document has been prepared to be used by professional and properly trained personnel, and the customer assumes full responsibility when using it. Nokia Networks welcomes customer comments as part of the process of continuous development and improvement of the documentation.

The information or statements given in this document concerning the suitability, capacity, or performance of the mentioned hardware or software products cannot be considered binding but shall be defined in the agreement made between Nokia Networks and the customer. However, Nokia Networks has made all reasonable efforts to ensure that the instructions contained in the document are adequate and free of material errors and omissions. Nokia Networks will, if necessary, explain issues which may not be covered by the document.

Nokia Networks' liability for any errors in the document is limited to the documentary correction of errors. Nokia Networks WILL NOT BE RESPONSIBLE IN ANY EVENT FOR ERRORS IN THIS DOCUMENT OR FOR ANY DAMAGES, INCIDENTAL OR CONSEQUENTIAL (INCLUDING MONETARY LOSSES), that might arise from the use of this document or the information in it.

This document and the product it describes are considered protected by copyright according to the applicable laws.

NOKIA logo is a registered trademark of Nokia Corporation.

Any other trademarks mentioned in the documents are the property of their respective companies, and they are mentioned for identification purposes only.

Copyright © Nokia Corporation 2000-2002. All rights reserved.

Document History

Document	Date	Comment
C33836005SE_00	13 Dec 2000	
C33836005SE_A0	9 Apr 2001	
C33836005SE_B0	4 Jan 2002	

Contents

Chapter 1	
About this document	1
Chapter 2	
Precautions	3
Chapter 3	
Installation procedure	7
3.1 Task list	7
3.2 Tools	9
Chapter 4	
Routing the cables and optical fibres	11
4.1 Routing electrical cables and installing strain reliefs	11
4.2 Marking cables	13
4.3 Laying optical fibres	15
4.3.1 Handling	15
4.3.2 Routing	15
Chapter 5	
Connecting the station alarms and power supply	19
5.1 17-slot subrack	19
5.1.1 Jumper settings	19
5.1.2 Power supply interfaces	22
5.2 8-slot cartridge	28
5.2.1 Jumper settings	28
5.2.2 Power supply interfaces	30

Chapter 6	
Installing the 17-slot subrack	33
6.1 Construction	33
6.2 Mounting the subrack to rack	34
6.3 Mounting the subrack on the wall	37
6.4 Mounting the bottom plate	39
6.5 Installing the service connector panel	40
Chapter 7	
Installing the 8-slot cartridge	41
7.1 Construction	41
7.2 Mounting the cartridge shelf to the rack	42
7.3 Mounting the cartridge onto cartridge shelf	43
Chapter 8	
Protective earthing	47
8.1 Earthing a station	47
8.2 Earthing the rack (protective earth)	49
8.3 Earthing the subrack	50
Chapter 9	
Installing the cable trays	53
Chapter 10	
Connecting the interfaces	57
10.1 Eksos N20 cables	58
10.2 Node Control Unit	60
10.2.1 2 Mbit/s interfaces	61
10.2.2 Synchronisation interfaces	62
10.2.3 Q1/AUX management interface	63
10.2.4 External supervisory interface	64
10.2.5 Q3 management interface	64
10.3 Line Measurement Unit	65
10.3.1 External supervision interface	65
10.3.2 External test access interface	65
10.4 PSTN and ISDN units	67
10.5 TR2M4 unit	71
10.6 Data Interface Units	73
10.7 SAN CORE2M units	77
10.7.1 Coaxial 2 Mbit/s interfaces (TRIB)	78
10.7.2 Symmetrical 2 Mbit/s interfaces (TRIB)	78
10.7.3 Auxiliary interface (AUX)	79
10.7.4 Synchronisation interfaces (SR, ST)	79

Chapter 11	
Installing and cabling the plug-in units	81
11.1 Unit locations	82
11.1.1 Coding system of the unit slots	82
11.1.2 Recommended unit slots	83
11.2 Handling plug-in units	85
11.3 Inserting plug-in units	86
11.4 Fitting blanking plates for unused unit locations	87
11.5 Cabling plug-in units	88
11.5.1 Inserting and replacing connector carriers	88
11.5.2 Cabling the Data Interface Unit	89
11.5.3 Tying electrical cables to cable trays	91
11.6 Connecting Eksos N20 to SAN	91
11.7 Service switch cabling	95
Chapter 12	
Ethernet cabling	101
Chapter 13	
Installing auxiliary equipment and accessories	105
13.1 Fan unit	105
13.2 Air deflectors	107
13.3 Subrack front cover	108

Chapter 1

About this document

Before beginning the installation, make sure that you have an installation plan available.

This document describes the general methods for mechanical installation and cabling of the Eksos N20 equipment.

In addition to this document, you will also need separate installation documents for the Rack, DC-PSA, Fan Unit, SYNFO NET Access Node (SAN) CORE2M unit and OSI-DCN Adaptor, and Indoor / Outdoor Cabinet, if used.

This document provides advice on:

- Precautions (Chapter 2)
- Installation procedure: task list and tools required (Chapter 3)
- Routing cables and optical fibres (Chapter 4)
- Connecting station alarms and power supply (Chapter 5)
- Installing the subrack (Chapter 6)
- Installing the cartridge (Chapter 7)
- Protective earthing (Chapter 8)
- Installing cable trays (Chapter 9)
- Connecting interfaces (Chapter 10)
- Installing and cabling plug-in units (Chapter 11)
- Ethernet cabling (Chapter 12)
- Installing auxiliary equipment and accessories (Chapter 13).

Chapter 2 Precautions

This chapter describes the general precautions that have to be taken into consideration when installing Eksos N20. These precautions ensure the safe and correct installation and operation of Eksos N20. Notice that specific chapters can also contain warnings and cautions that should be taken into account when performing specific tasks.

Laser safety

The pieces of equipment mentioned in this manual and marked with this sticker are classified as Class 1 laser products. The classification is based on European standards EN 60825-1:1994, EN 60825-1/A11:1996 and EN 60825-2:1994. They conform to the IEC 825-1:1993 and IEC 825-2:1993 standards of the International Electrotechnical Commission (IEC).



The maximum output power of Class 1	
1310 nm nominal wavelength	+9.4 dBm (= 8.8 mW)
1550 nm nominal wavelength	+10 dBm (= 10 mW)

! **Caution**

Using this equipment in ways other than those specified in these instructions may result in exposure to laser radiation exceeding the limits of laser Class 1.

Anti-static precautions



Caution

Always take standard anti-static precautions (such as wearing a wrist strap earthed to the rack) when handling Eksos N20 units because they contain components which may be damaged by static discharge.

Sensitivity to ESD



Caution

Always use shielded cables with the RJ45 connectors on the Node Control Unit (NCU). Units may be disturbed by high-level static discharges to the NCU if unshielded cables are used for cabling the RJ45 connectors (Q1, AUX, Supervision and Q3 Ethernet 10Base-T connectors) on the NCU.

Handling plug-in units



Caution

In addition to taking standard anti-static precautions, it is important to only hold plug-in units by the insertion/extraction levers or by the back connectors.

Inserting units in subrack



Caution

Take care that the front plate of the unit is in good contact with the subrack after the finger screws have been tightened.

Installing Eksos N20 on the wall in closed spaces



Caution

Do not install Eksos N20 directly above a radiator or a heater or store flammable materials near Eksos N20. Also, ensure that the air circulation in the space is adequate.



Caution

The wall onto which the Wall Mounting Set is installed must be suitable by its bearing capacity and fire resistance grading.

Optical fibres and electrical cables



Caution

Where electrical cables and optical fibres are run through the same shaft, use optical fibre guides to prevent damage occurring to the optical fibres.



Caution

Make sure that there is a standard protecting plate installed below the rack.

Storage of manuals



Caution

Do not store any paper or user manuals at the bottom of the rack. They may obstruct the air flow and cause a fire hazard.

Chapter 3

Installation procedure

Before beginning the installation, make sure that you have an installation plan available.

This chapter gives the order in which to install the equipment and lists the tools that are needed to install Eksos N20.

3.1 Task list

Before the actual installation procedure can be started, it is essential that the installation has been properly planned and that you are familiar with the installation and thermal plans.

We recommend that you start the installation from the subrack which is furthest from the point where cables enter the rack. Start with the lowermost subrack when guiding cables upwards and the uppermost subrack when guiding cables downwards. Note that a cabling space of at least 1U is recommended above and below the subrack if cable trays are not used.

Caution

Take standard anti-static precautions (such as wearing a wrist strap earthed to the rack) when handling the units because they contain components which may be damaged by static discharge.

Planning the installation

1. Make an installation plan. See the *Product Description* for information needed for the plan.
2. Make sure that you have the required tools available. See section 3.2.
3. Make sure that you have the required Eksos N20 equipment to complete the installation procedure.

► Installing the Eksos N20 node

1. If air deflectors have been preinstalled, remove them to allow for more cabling space.
2. If you are installing the node on the wall using the Wall Mounting Set, mount the set on the wall.
3. Bring the cables into the rack or cabinet. A subrack or cartridge can be used as a gauge to determine the correct cable length of each separate cable when installing the cables into the rack or cabinet. See Chapter 4.
4. Mark the signal cables and power supply cables. See Chapter 4.
5. Install the power supply unit(s) into the rack, cabinet or Wall Mounting Set.
6. Preinstall the power supply, alarm and earthing cables to be connected to the extension board of the subrack or cartridge. See Chapter 5.
7. Install the 17-slot subrack into the rack or cabinet, set the extension board jumpers and connect the power supply, alarm and earthing cables. See Chapter 6.
8. If you are using the 8-slot cartridge, first install the cartridge shelf into the rack or cabinet and then mount the cartridge on it. Set the extension board jumpers and connect the power supply, alarm and earthing cables. See Chapter 7.
9. Connect the earthing wire to the rack earth. See Chapter 8.
10. Install the cable trays. See Chapter 9.
11. Cut the cables to the correct length and fit connectors onto them.
12. Install the plug-in units in their places. See Chapter 11.
13. Connect the cables to unit connectors. Adjust the cables in the rack, if necessary, and then fully tighten the cable ties. See Chapters 10 and 11.

► Finishing off the installation procedure

1. Fit blanking plates to all unused locations of the subrack to provide electromagnetic shielding. See section 11.4.
2. Mark down the required information about the installation on a marking sheet.
3. Install air deflectors and fan units, if needed. See Chapter 13. Connect the power and alarm cable to the fan unit.
4. Fix the subrack cover in its place, if needed. See section 13.3. Note that the 8-slot cartridges do not have covers.
5. Install the bottom plate below the rack.
6. Make sure that there are no manuals or other papers stored at the bottom of the rack.

3.2 Tools

Below is a list of general tools for installing the subracks, air deflectors and other such mechanical parts.

- anti-static wrist strap
- allen key, 5 mm
- screwdriver, flat head, 0.6 x 3.5 mm
- screwdriver, flat head, 1.0 x 6 mm
- screwdriver, cross head, Pozidriv No. 2 and 3
- crimp tool ABIKO no. 3165, size 16
- socket wrench, 10 mm
- socket wrench, 13 mm
- adjustable wrench
- side-cutting pliers
- pointed pliers
- tool for the coaxial 1.0/2.3 (DIN 41626/2) connector, for example, crimping tool Rosenberger 11W150-000
- tool for Euroconnector, for example, wire-wrapping tool Gardner Denver, wrap bit 506445, sleeve 507100
- tool for RJ45 connectors, for example, Stewart Connector Systems hand crimping tool A32900.02
- cable tie tool.

The recommended connector and cable types are described in Chapter 5 (power cables) and Chapter 10 (signal cables).

Chapter 4

Routing the cables and optical fibres

Before beginning to route the cables, make sure that you have a routing plan available.

4.1 Routing electrical cables and installing strain reliefs

Note

The shielding foil of the cables does not usually need to be earthed except in the following special cases:

- when using the RJ45 connectors (Q1, AUX, Supervision and Q3 Ethernet 10Base-T) on the NCU
 - when the CORE2M interface is connected by Euroconnector to the NCU
 - when connecting the CORE2M synchronisation transmit connection to the NCU synchronisation input
 - always when a Data Interface Unit (DIU) is used.
-

► Routing the cables

1. Mount the strain reliefs to both sides of the rack. The orientation of the strain reliefs depends on whether cables are routed from the top or bottom of the rack. See Figure 1.
2. Mark the cables and install the connectors. See section 4.2.
3. Route the cables via the sides of the rack from the subrack location. It is easier to handle the connectors in the subrack connector field if cables are routed equally through both sides of the rack. An empty subrack can be used as a guide to gauge the exact length of cable required. See Figure 1.
4. Loosely tie the electrical signal cables to the strain reliefs using cable ties. Each cable must be tied to the strain relief closest to the subrack to which the cable is connected, see Figure 1.

Note

Only fully tighten the cable ties when the connectors have been connected to the plug-in units and any excess cable has been eased out of the rack.

Installing strain reliefs




Figure 1 Strain reliefs, tying the cables and schematic diagram of electrical cable routing

4.2 Marking cables

To facilitate the cable installation, maintenance, upgrades, and possible changes in the cabling, mark the cables and record their route information.

Product	Order code	Description
Labels for laser printers	TI 22736.10	2500 pcs Brady LAT-17-361 laser marker for >4 mm cables
	TI 22736.20	500 pcs Brady LAT-18-361 laser marker for 5-7 mm cables
	TI 22736.30	1000 pcs Brady LAT-19-361 laser marker for 8-11 mm cables
Labelling Pen	TI 22738	Brady Labelling Pen MP-1
Labels for Bradymarker XC printer	TI 22737.10	250 pcs Brady WML-211-292 marker for >4 mm cables
	TI 22737.20	250 pcs Brady WML-311-292 marker for 5-7 mm cables
	TI 22737.30	100 pcs Brady WML-711-292 marker 8-11 mm cables
Label Printer	TI 22739	Bradymarker XC Printer for TI 22737.xx Labels

Table 1 Recommended accessories for cable marking

Mark both ends of the cable by wire labels according to Figure 2, for example.




Figure 2 A marking strip on a cable

Example of marking structure

This example shows how to mark the cable to a connector.




Figure 3 Example of the marking code

Symbol	Meaning
1	Rack row: Rack rows follow consecutive numbering beginning from the front.
B	Rack: The location of the rack within the row is indicated by the letters A, B, C,
2	Shelf (or power supply unit): The location of the shelf (or power supply) in the rack is indicated by the numbers 1, 2, 3 The marking begins at the top of the rack.
A	Cartridge: The location of the cartridge in the shelf is indicated by letters A, B, C The marking begins from the left of the shelf.
1	Unit location: The location of the plug-in unit in the cartridge is indicated by numbers 1, 2, 3 The marking begins from the left of the cartridge.
TRIB	Interface abbreviation: The abbreviations of the interfaces are shown on the plug-in units, see Chapter 10.
R8	Connector abbreviation: Needed when coaxial 2 Mbit/s interfaces are used, see Chapter 10.

Table 2 Example on how to mark the cable to a connector

4.3 Laying optical fibres

4.3.1 Handling

Optical fibres require more careful handling than copper cables. To minimise the handling, it is recommended that the copper cables are installed before the optical fibres. Follow the recommendations for the bending radius and tensile strength of the fibre. Do not leave fibres under permanent stress.



Caution

Do not tie optical fibres to strain reliefs.

4.3.2 Routing

Routing in a rack

Route the fibres through fibre cable reels, if available. This way the fibres do not need to be cut to exact lengths, and the installation becomes easier. The reels are installed in the fibre cable reel cases above the rack, see Figure 5.

Bring the optical fibres into the back or side of the rack. Route the fibres through the fibre guides which are located on top of each subrack. See Figure 4. Fibre guides are available in the cabling accessory sets of optical plug-in units. If cable trays are used, fit guiding tubes onto the optical cables and then route in the same way as PSTN and ISDN cables.




Figure 4 Using the optical fibre guides on the subrack

Note

Use separate protective fibre guiding tubes if the electrical cables and optical fibres are guided through the same cable shaft.




Figure 5 Optical fibre routing scheme

Fibre cable reels

Each fibre needs one reel, into which the excess length, maximum 3 m, is rolled. Each fibre cable reel case holds 16 reels. For each rack, four cases can be installed, so a maximum of 64 fibres per rack can be handled.




Figure 6 Fibre cable reel and a case

Follow the instructions shown in Figure 7. When placing the reel into the case, be careful not to leave the fibres under the edge of the reel. Mark the reels on the marking labels on the case, so that the fibres can be easily identified later by maintenance personnel, for instance.




Figure 7 Rolling the excess fibre length into fibre cable reel

Chapter 5

Connecting the station alarms and power supply

This chapter describes the power supply and alarm cabling combinations for the Eksos N20 17-slot subrack, 8-slot cartridge and fan unit.

You might also need to refer to the following documents:

- *DC-PSA Operating Instructions*, which also covers the Capacitor Unit and Extension Unit
- *Fan Unit Operating Instructions*.

5.1 17-slot subrack

5.1.1 Jumper settings

Jumpers J1 to J4 are located on the extension board inside the subrack or cartridge, and must be set prior to installing plug-in units. J1 and J3 are used to connect the power supply buses together. J2 and J4 are used to connect the positive supply voltages to earth. See Figures 8 and 9, and Table 3.




Figure 8 Jumper locations on the subrack extension board

Each power supply bus provides power to units in alternate unit slot locations; one bus provides power to the odd-numbered unit locations in the range 1-15 and the other provides power to the even-numbered slots and slot 17. The buses can be connected together using jumpers J1 and J3. See Figure 9.




Figure 9 Power supply distribution and jumper principle

Jumper	Position	Effect
J1	1-2 (default)	VNB1 and VNB2 not connected together
	2-3	VNB1 and VNB2 connected together
J2	1-2	VPB1 and GND not connected together
	2-3 (default)	VPB1 and GND connected together
J3	1-2 (default)	VPB1 and VPB2 not connected together
	2-3	VPB1 and VPB2 connected together
J4	1-2	VPB2 and GND not connected together
	2-3 (default)	VPB2 and GND connected together
Caution: Use only default jumper settings for PSTN and ISDN applications.		

Table 3 Jumper settings on the extension board

Figure 10 and Table 4 illustrate the connections between a power supply unit and Eksos N20. The numbers given to the cables in Figure 10 refer to the numbers in column ‘#’ of Table 4. The order codes of these cables can be found in the *System Release Item List*.

To handle the high current requirements of some Eksos N20 nodes, it is recommended that all of the power cables are fitted as shown in Figure 10 and that the jumpers are set to their default positions. For partially populated nodes, this makes it easy to add plug-in units in the future without having to change the jumper settings. If the Eksos N20 node has less than eight PSTN or ISDN units, jumpers J1 and J3 can be reset to position 2-3 and feeding can be done with cable 2 (see Figure 10).




Figure 10 Power and alarm cables from a power supply to Eksos N20 and Fan Unit

#	Cable	Connection
1	Alarm cable NTM 0.5 m, 1.0 m, 1.5 m, 2.0 m, 2.5 m, 3.0 m, 3.5 m	DC-PSA to Eksos N20
2 and 3	Power cable NTM 0.5 m, 1.0 m, 1.5 m, 2.0 m, 2.5 m, 3.0 m, 3.5 m	DC-PSA, Extension Unit to Eksos N20
4	Fan interface cable Eksos 1.5 m	Eksos N20 to Fan Unit

Table 4 Power and alarm cables with Eksos N20

5.1.2 Power supply interfaces

The following connectors are located on the extension board at the back of the subrack (See Figure 11):

- station alarm ('rack alarm') (P4)
- service switch ('external switch matrix') (J2A: A to D)
- test bus (J3A: C and D) and SV1 measurement (J3A: A and B)
- future option (J11, J12, J13)
- power supply (P1, P2)
- fan connector (J5)
- signalling voltage (P3).

Fuses X1 and X2 on the extension board provide protection for the fans and are each rated at 2.5 A.




Figure 11 Power supply panel of the subrack extension board


15-pole male D-connector	Pinout of the station alarm outputs connector P4 as seen from the front of the subrack extension board		
	Signal	Pin	Explanation
	RK_AL_A	1	Rack alarm A
	RK_AL_B	2	Rack alarm B
	RK_AL_D	3	Rack alarm D
	VAP5	4	Auxiliary power supply
	RK_AL_E2	5	Rack alarm E2
	RK_AL_F2	6	Rack alarm F2
	N.C.	7	Unused
	N.C.	8	Unused
	GND	9	Ground
	GND	10	Ground
	GND	11	Ground
	GND	12	Ground
	RK_AL_E1	13	Rack alarm E1
	RK_AL_F1	14	Rack alarm F1
N.C.	15	Unused	

Table 5 Station alarm outputs connector P4 pinout





RJ45 connectors	Pinout of the service switch connector block J2A as seen from the front of the subrack extension board		
 <p>8 1 D</p>	Signal	Pin	Explanation
	PSVC1A	1	Connector for POTS line 1
	PSVC1B	2	Connector for POTS line 1
	PSVC2A	3	Connector for POTS line 2
	PSVC2B	4	Connector for POTS line 2
	PSVC3A	5	Connector for POTS line 3
	PSVC3B	6	Connector for POTS line 3
	PSVC4A	7	Connector for POTS line 4
PSVC4B	8	Connector for POTS line 4	
 <p>8 1 C</p>	PSVC5A	1	Connector for POTS line 5
	PSVC5B	2	Connector for POTS line 5
	PSVC6A	3	Connector for POTS line 6
	PSVC6B	4	Connector for POTS line 6
	PSVC7A	5	Connector for POTS line 7
	PSVC7B	6	Connector for POTS line 7
	PSVC8A	7	Connector for POTS line 8
	PSVC8B	8	Connector for POTS line 8
 <p>8 1 B</p>	ISVC1A	1	Connector for ISDN line 1
	ISVC1B	2	Connector for ISDN line 1
	ISVC2A	3	Connector for ISDN line 2
	ISVC2B	4	Connector for ISDN line 2
	ISVC3A	5	Connector for ISDN line 3
	ISVC3B	6	Connector for ISDN line 3
	ISVC4A	7	Connector for ISDN line 4
	ISVC4B	8	Connector for ISDN line 4
 <p>8 1 A</p>	ISVC5A	1	Connector for ISDN line 5
	ISVC5B	2	Connector for ISDN line 5
	ISVC6A	3	Connector for ISDN line 6
	ISVC6B	4	Connector for ISDN line 6
	ISVC7A	5	Connector for ISDN line 7
	ISVC7B	6	Connector for ISDN line 7
	ISVC8A	7	Connector for ISDN line 8
	ISVC8B	8	Connector for ISDN line 8

Table 6 Service switch connector block J2A pinout



RJ45 connectors	Pinout of the test bus and SV1 measurement connector block J3A as seen from the front of the subrack extension board		
 <p>D and C</p>	Signal	Pin	Explanation
	TL1A	1	Line test bus
	TL1B	2	Line test bus
	TI1B	3	Inward test bus
	TI1A	4	Inward test bus
	N.C.	5	Unused
	N.C.	6	Unused
	N.C.	7	Unused
GND	8	Ground	
 <p>B and A</p>	–	1	Parallel connection between A and B
	–	2	Parallel connection between A and B
	–	3	Parallel connection between A and B
	–	4	Parallel connection between A and B
	–	5	Parallel connection between A and B
	–	6	Parallel connection between A and B
	SV1M	7	SV1 Measurement and parallel connection between A and B
	–	8	Parallel connection between A and B

Table 7 Test bus and SV1 measurement connector block J3A pinout. See also Table 31 for the NCU/LMU front connector pinout.


Phoenix mini-combicon connector	Pinout of connectors J11 and J12 as seen from the front of the subrack extension board		
	Signal	Pin	Explanation
	VNB	1	Negative battery voltage
	N.C.	2	Unused
VPB	3	Positive battery voltage	

Table 8 Connector J11 and J12 pinout (future option)


Phoenix mini-combicon connector	Pinout of connector J13 as seen from the front of the subrack extension board		
	Signal	Pin	Explanation
	SV1	1	Signalling voltage
	N.C.	2	Unused
	GND	3	Ground

Table 9 Connector J13 pinout (future option)


AMP Mate'n'lok	Pinout of the power connectors P1 and P2 as seen from the front of the subrack extension board		
	Signal	Pin	Explanation
	VNB	1	Negative battery voltage
	VPB	2	Positive battery voltage
	GND	3	Ground

Table 10 Power connector P1 and P2 pinout


AMP Mate'n'lok	Pinout of the signalling voltage connector P3 as seen from the front of the subrack extension board		
	Signal	Pin	Explanation
	SV1	1	Signalling voltage
	GND	2	Ground
	GND	3	Ground

Table 11 Signalling voltage connector P3 pinout


9-pole female D-connector	Pinout of the fan power and alarm connector J5 as seen from the front of the subrack extension board		
	Signal	Pin	Explanation
	VNB2_FAN	1	Fan 2 negative battery voltage
	N.C.	2	Unused
	GND	3	Ground
	FALA	4	Fan alarm A
	VNB1_FAN	5	Fan 1 negative battery voltage
	N.C.	6	Unused
	VPB_FAN	7	Fan positive battery voltage
	VPB_FAN	8	Fan positive battery voltage
	FALB	9	Fan alarm B

Table 12 Fan power and alarm connector J5 pinout

5.2 8-slot cartridge

5.2.1 Jumper settings

Jumpers J2 and NR1 are located on the extension board inside the cartridge, and must be set prior to installing the plug-in units. J2 is used to connect the positive supply voltages to earth. See Figure 12 and Table 13.




Figure 12 Jumper locations on the cartridge extension board

Jumper	Position	Effect
J2	1-2	VPB1 and GND not connected together
	2-3 (default)	VPB1 and GND connected together
NR1	1-3, 2-4 (default)	When a SAN unit is installed in the cartridge, Fan Unit alarms E1 or F1 are not on.
	3-5, 4-6	When a SAN unit is installed in the cartridge, Fan Unit alarms E1 or F1 are enabled.
Caution: Use only default jumper settings for jumper J2 in PSTN and ISDN applications.		

Table 13 Jumper settings on the extension board

Figure 13 and Table 14 illustrate the connections between a power supply unit and Eksos N20. The numbers given to the cables in Figure 13 refer to the numbers in column ‘#’ of Table 14. The order codes of these cables can be found in the *System Release Item List*.

To handle the high current requirements of some Eksos N20 nodes, it is recommended that all of the power cables are fitted as shown in Figure 13 and that the jumpers are set to the default positions. For partially populated nodes, this makes it easy to add plug-in units in the future without having to change the jumper settings.




Figure 13 Power and alarm cables from a power supply to Eksos N20 and Fan Unit

#	Cable	Connection
1	Alarm cable NTM 0.5 m, 1.0 m, 1.5 m, 2.0 m, 2.5 m, 3.0 m, 3.5 m	DC-PSA to Eksos N20
2 and 3	Power cable NTM 0.5 m, 1.0 m, 1.5 m, 2.0 m, 2.5 m, 3.0 m, 3.5 m	DC-PSA, Extension Unit to Eksos N20
4	Fan interface cable Eksos 1.5 m	Eksos N20 to Fan Unit

Table 14 Power and alarm cables with Eksos N20 and the 8-slot cartridge

5.2.2 Power supply interfaces

The following connectors are located on the extension board at the back of the cartridge (See Figure 14):

- station alarm ('rack alarm') (P4)
- fan connector (J5)
- service switch ('external switch matrix') (J2A: A to D)
- test bus (J3A: C and D) and SV1 measurement (J3A: A and B)
- power supply (P1)
- signalling voltage (P3)
- future option (J1, J3).

Fuse X1 on the extension board provides protection for the fans and is rated at 2.5 A.




Figure 14 Power supply panel of the cartridge extension board


15-pole male D-connector	Pinout of the station alarm outputs connector P4 as seen from the front of the cartridge extension board		
	Signal	Pin	Explanation
	RK_AL_A	1	Rack alarm A
	RK_AL_B	2	Rack alarm B
	RK_AL_D	3	Rack alarm D
	VAP5	4	Auxiliary power supply
	RK_AL_E2	5	Rack alarm E2
	RK_AL_F2	6	Rack alarm F2
	N.C.	7	Unused
	N.C.	8	Unused
	GND	9	Ground
	GND	10	Ground
	GND	11	Ground
	GND	12	Ground
	RK_AL_E1	13	Rack alarm E1
	RK_AL_F1	14	Rack alarm F1
N.C.	15	Unused	

Table 15 Station alarm outputs connector P4 pinout


9-pole female D-connector	Pinout of the fan power and alarm connector J5 as seen from the front of the cartridge extension board		
	Signal	Pin	Explanation
	VNB2_FAN	1	Fan 2 negative battery voltage
	N.C.	2	Unused
	GND	3	Ground
	FALA	4	Fan alarm A
	VNB1_FAN	5	Fan 1 negative battery voltage
	N.C.	6	Unused
	VPB_FAN	7	Fan positive battery voltage
	VPB_FAN	8	Fan positive battery voltage
FALB	9	Fan alarm B	

Table 16 Fan power and alarm connector J5 pinout

The pinout of connector blocks J2A and J3A is the same as on the extension board of the 17-slot subrack, see section 5.1.2.


AMP Mate'n'lok	Pinout of the power connector P1 as seen from the front of the cartridge extension board		
	Signal	Pin	Explanation
	VNB	1	Negative battery voltage
	VPB	2	Positive battery voltage
	GND	3	Ground

Table 17 Power connector P1


AMP Mate'n'lok	Pinout of the signalling voltage connector P3 as seen from the front of the cartridge extension board		
	Signal	Pin	Explanation
	SV1	1	Signalling voltage
	GND	2	Ground
	GND	3	Ground

Table 18 Signalling voltage connector P3 pinout


Phoenix mini-combicon connector	Pinout of connector J1 as seen from the front of the cartridge extension board		
	Signal	Pin	Explanation
	VNB	1	Negative battery voltage
	N.C.	2	Unused
	VPB	3	Positive battery voltage

Table 19 Connector J1 pinout (future option)


Phoenix mini-combicon connector	Pinout of connector J3 as seen from the front of the cartridge extension board		
	Signal	Pin	Explanation
	SV1	1	Signalling voltage
	N.C.	2	Unused
	GND	3	Ground

Table 20 Connector J3 pinout (future option)

Chapter 6

Installing the 17-slot subrack

Before beginning the installation procedure, make sure that you have an installation plan available.

6.1 Construction




Figure 15 17-slot subrack without front cover

6.2 Mounting the subrack to rack

A standard ETSI or 19" rack can contain either three or four Eksos subracks, depending on the power consumption and the number of ventilation components required.

An airspace of at least 1U in 19" racks or 25 mm in ETSI racks must be left beneath the front cover of the lowest subrack in the rack if cable trays are not used.

In a 2-meter high rack, the capacitor unit and the air deflector can be mutually exclusive options.

Note

We recommend that the fan unit is installed also in 3-subrack installations if the maximum number of units are installed in the rack.




Figure 16 Equipping recommendation for 19" racks




Figure 17 Equipping recommendations for ETSI racks




Figure 18 Mounting the subrack to a rack (ETSI and 19")

6.3 Mounting the subrack on the wall

The Wall Mounting Set can be used for mounting 17-slot Eksos N20 subracks in small locations where space is a premium. In addition to the subrack, the Wall Mounting Set can also accommodate a DC-PSA, fan unit and connecting bar frame.




Figure 19 Eksos N20 in a Wall Mounting Set

The procedure for installing the subrack in a Wall Mounting Set is shown in Figure 20.

Install Eksos N20 in a Wall Mounting Set in the following order:

1. Eksos N20 subrack
2. DC-PSA
3. Connecting bar frame, if used
4. Fan unit.




Figure 20 Installing Eksos N20 into Wall Mounting Set

6.4 Mounting the bottom plate

If the rack contains 1 to 3 subracks, install a bottom plate below the lowest subrack. If the rack is fully equipped (that is, contains 4 subracks), install only the floor plates.

When a Wall Mounting Set is used, the bottom plates are always used.




Figure 21 Installing the bottom plate below a rack

6.5 Installing the service connector panel

Attach the service connector panel to the rack edge or cabinet mounting rail, for example.

The Y-type connector on the service connector panel interface contains an integrated switch. When the node manager cable is not plugged in, a direct connection is formed past the connector.

! Caution

The Ethernet connectors must not come into contact with any metal parts of the subrack or the service connector panel. Take care to correctly install the insulating plates and shields for the Ethernet connectors.

If only one subrack is to be installed, terminate the other interface of the Y-type connector as shown in Figure 23.

► Connecting the service connector panel

1. Mount the service connector panel with the Y-type connector to the rack, see mounting principle in Figure 22.
2. Connect the Ethernet cables:
 - Connect the Ethernet cable from the Y-type connector to the NCU Q3 connector (Figure 22).
 - Connect Ethernet cables to other network elements if necessary.
 - Terminate the Ethernet where necessary (Ethernet terminated at the Y-type connector; Figure 23).




Figure 22 Example on connecting the service connector panel




Figure 23 Terminating the Ethernet connection at the Y-type connector

Chapter 7

Installing the 8-slot cartridge

Before beginning the installation procedure, make sure that you have an installation plan available.

7.1 Construction




Figure 24 Dimensions of the 8-slot cartridge

7.2 Mounting the cartridge shelf to the rack

The cartridge shelf is a rack mounting device for Eksos N20 8-slot cartridges. The cartridge shelf offers the possibility to install other equipment, such as broadband equipment, next to the Eksos N20 node.

The shelf can be installed in the ETSI or 19" rack. The installation procedure is shown in Figure 25.




Figure 25 Mounting the cartridge shelf to a rack (ETSI and 19")

7.3 Mounting the cartridge onto cartridge shelf

Installing the cartridge shelf and cartridge to the rack is similar to the installation of the 17-slot subrack, except that you must take into account the required height of the complete cartridge shelf installation. This height depends on the equipment installed alongside the cartridge. On their own, the cartridge and shelf require 8U.

Typically, you need to reserve 10U for the cartridge and shelf, and 1U for the Fan Unit, which is installed below the cartridge shelf. The Fan Unit should be used when the equipment installed next to the Eksos N20 cartridge requires enhanced heat dissipation.




Figure 26 Equipping example for the cartridge and shelf




Figure 27 Attaching the 8-slot cartridge to rack and shelf




Figure 28 Attaching the side support to the rack edge




Figure 29 Attaching the cartridge to the shelf

The service connector panel is attached, for example, to the rack edge or cabinet mounting rail. For instructions, see Section 6.5.

Chapter 8

Protective earthing

Before beginning the earthing activities, make sure that you have an earthing plan available.

This chapter describes the general aspects of protective earthing. The exact earthing of terminals and connectors are specified in the rack documentation.

8.1 Earthing a station



WARNING

Adjacent racks must be linked by a conductor to prevent voltage differences occurring between them (safety risk).



Caution

The principles given below are especially important if there are outgoing subscriber lines connected.

When earthing multiple racks or rack rows, you should pay attention to the following details:

- Prevent any earth loops between protective earth and signal cable sleeves. If loops cannot be avoided, the area of the loops should be restricted to the minimum, for example by using cable trays for earthing.
- If external AC-powered apparatus (for example, measuring devices) are connected to the telecommunications equipment, the earthing should be done so that differences between earth potentials are avoided. This is achieved best by using isolation transformers in AC-feeding.
- The earth structure of multiple racks should form a mesh network to provide an impedance as low as possible.

- The cross-connection frame must also be earthed.
- For PSTN and ISDN applications, the battery plus must always be earthed at the DC-PSA.




Figure 30 Earthing by connection to a single earthing conductor (in accordance with ETS 300253)




Figure 31 Earthing by connection to an earthing bus (loop) conductor

Wherever possible, earthing should be implemented as shown in Figure 31. However, if no earthing bus conductor is available, connect the racks directly to the combiner bar or directly to the main earthing bar if it is closer or if there is no

combiner bar at all. The positive pole of the ACDC charger system should be connected to the same bar.

8.2 Earthing the rack (protective earth)

The rack can be earthed either with rigid connection to a mechanical support or cable tray, or with a separate wire. The recommended minimum cross-section for the conductor is 16 mm^2 for copper cables or 25 mm^2 for aluminium cables.

Each rack must be earthed to the main earthing bar (MEB) with a copper wire of at least 16 mm^2 either directly, via combiner bar or via earthing bus conductor.




Figure 32 Principle of rack earthing

8.3 Earthing the subrack

All metal surfaces that the user can access during normal operation should be connected together and directly to the rack. Exceptions to this rule of thumb are those cable sleeves and connectors which are recommended to be insulated from the earth to avoid circulating current.

! Caution

The Ethernet LAN cables must not be earthed to the rack or subrack.

If the equipment is placed into a dry environment ($RH < 60\%$ most of the time), the insulation stickers of the subrack mounting brackets should be left away to get the impedance between the subrack and the rack the smallest possible.

If the installation environment is humid ($RH \geq 60\%$ most of the time) and the rack is not of stainless steel, the mounting brackets must be insulated from the rack body to avoid corrosion. This is done by installing the stickers included in the grounding accessories. Also, the DC-PSA must be provided with stickers (see the DC-PSA documentation for further details).

The subrack must always be earthed with a separate wire, see Figure 33. The cross-section of the earthing conductor must be equal to or larger than that of the power feeding conductors. The recommended minimum cross-section is 6 mm^2 . This wire has to be as short as possible.




Figure 33 Earthing wire connected to earthing point

For PSTN/ISDN applications, set the jumpers on the subrack to their default positions as described in Table 3 of Chapter 5 'Connecting station alarms and power supply' (positive supply voltages are connected to earth).

Note

Make sure that all contacts are tight (in many racks, cage nuts do not make good contact).

Chapter 9 Installing the cable trays

Cable trays are installed above and below the subrack and cartridge. The space required by the cable tray is 1U. Without any cable trays, the subrack requires a space of 8U. The cable tray is used to secure the cable in place and also to ensure that the airflow through the rack installation is not obstructed.




Figure 34 Principle of the cable tray installation (including subrack and air deflector)

- ▶ To mount the cable trays to an ETSI rack (see Figure 35):
 1. Fix the nuts to the rack.
 2. Fix the mounting brackets to the cable tray.
 3. Fix the cable tray to the rack with four screws.
 4. If the Q3 interface is used, remove the sticker from the cable tray.




Figure 35 Mounting cable trays to ETSI rack

- To mount the cable trays to a 19-inch rack (see Figure 36):
1. Fix the nuts to the rack.
 2. Fix the mounting brackets to the cable tray.
 3. Fix the cable tray to the rack with two screws.




Figure 36 Mounting cable trays to 19-inch rack

Chapter 10

Connecting the interfaces

Before beginning to connect the interfaces, make sure that you have a cabling plan available.

It is important that you have the required cables and connectors and you know which interfaces to connect before installing the plug-in units.

This chapter illustrates the connectors and pinout of the following Eksos N20 plug-in units:

- Node Control Unit (75 Ω)
- Node Control Unit (120 Ω)
- Node Control Unit (75/120 Ω)
- Line Measurement Unit
- PSTN unit
- ISDN BRA U-interface unit
- TR2M4 unit (75 Ω)
- TR2M4 unit (120 Ω)
- Data Interface Unit
- SAN CORE2M units.

10.1 Eksos N20 cables

Cable type	Product Code	Connector and main usage
MMHS 4 x 2 x 0.4 + 0.4	TI 22701.41	RJ45 connector 120 Ω synch in/out Management interfaces Service switch cabling Test bus SV1 measurement
		C/4 Euroconnector 2 x 2 Mbit/s - 120 Ω 4 channel PSTN and ISDN-U
MMHS 8 x 2 x 0.4 + 0.4	TI 22701.42	2 x C/4 Euroconnector 4 x 2 Mbit/s - 120 Ω 8 channel PSTN and ISDN-U
MMHS 2 x 8 x 2 x 0.4 + 0.4	TI 22701.70	C/1 Euroconnector 16 channel PSTN and ISDN-U
		C/2 Euroconnector 8 x 2 Mbit/s - 120 Ω (CORE2M)

Table 21 Twin pair cables used in Eksos N20 applications

Cable type	Product Code	Connector
Coaxial cable 75 double screen / Amgab	TI 22706.1	Coaxial 1.0/2.3

Table 22 Coaxial cables used in Eksos N20 applications

Optical fibre type	Connector
D3.0 mm SM-10/125 μm, blu	FC/PC and SC connector (CORE2M)
D3.0 mm SM-10/125 μm, orn	FC/PC and SC connector (CORE2M)
D2.0 mm SM-10/125 μm, yel, HF	FC/PC and SC connector (CORE2M)

Table 23 Optical fibres used in Eksos N20 applications

Cable type	Product Code
Node Manager Cable	T30404.21
Ethernet Cable, 50 cm	T30405.01
80 cm Ethernet cable (Subrack–Subrack)	T30405.08
120 cm Ethernet Cable (Rack–Rack)	T30405.12
NTM Dual Ethernet Cable 1 m	T30436.01
NTM Dual Ethernet Cable 3 m / 0.5 m	T30436.02

Table 24 Thin wire Ethernet cables used in Eksos N20 applications

Accessory type	Product Code
Adapter for NTM Ethernet cable	T30436.03
T-BNC Connector with protective cover	T30405.11
50 Ω Ethernet Line Termination	T30405.10
Eksos Service Connector Panel	E30444.02

Table 25 Thin wire Ethernet cabling accessories

10.2 Node Control Unit




Figure 37 Connectors on NCU (75 Ω, 75/120 Ω and 120 Ω)

10.2.1 2 Mbit/s interfaces

Euroconnector		Pins of the 2 Mbit/s interface as seen from the front of the NCU			
	Pin	a	b	c	Explanation
	16	N.C.	N.C.	N.C.	Unused
	15	R1A	N.C.	R1B	Receive 1
	14	N.C.	GND	N.C.	Ground
	13	T1A	N.C.	T1B	Transmit 1
	12	N.C.	GND	N.C.	Ground
	11	R2A	N.C.	R2B	Receive 2
	10	N.C.	GND	N.C.	Ground
	9	T2A	N.C.	T2B	Transmit 2
	8	N.C.	N.C.	N.C.	Unused
	7	R3A	N.C.	R3B	Receive 3
	6	N.C.	GND	N.C.	Ground
	5	T3A	N.C.	T3B	Transmit 3
	4	N.C.	GND	N.C.	Ground
	3	R4A	N.C.	R4B	Receive 4
	2	N.C.	GND	N.C.	Ground
1	T4A	N.C.	T4B	Transmit 4	

Table 26 4 x 2 Mbit/s Euroconnector C/2




Figure 38 2 Mbit/s coaxial connectors

10.2.2 Synchronisation interfaces


RJ45 female connector	Pins of the SYNC IN interface as seen from the front of the NCU		
	Signal	Pin	Explanation
	N.C.	1	Unused
	N.C.	2	Unused
	N.C.	3	Unused
	SYN R1A	4	Synchronisation receive
	SYN R1B	5	Synchronisation receive
	N.C.	6	Unused
	N.C.	7	Unused
N.C.	8	Unused	

Table 27 SYNC IN connector pins


RJ45 female connector	Pins of the SYNC OUT interface as seen from the front of the NCU		
	Signal	Pin	Explanation
	SYN T1A	1	Synchronisation transmit
	SYN T1B	2	Synchronisation transmit
	N.C.	3	Unused
	N.C.	4	Unused
	N.C.	5	Unused
	N.C.	6	Unused
	N.C.	7	Unused
N.C.	8	Unused	

Table 28 SYNC OUT connector pins

10.2.3 Q1/AUX management interface


RJ45 female connector	Pins of the Q1 interface as seen from the front of the NCU		
	Signal	Pin	Explanation
	Q1OCL+	1	Q1 output clock positive, idle state +5 V ¹⁾
	Q1OCL-	2	Q1 output clock negative, idle state +0 V ¹⁾
	Q1OUT+	3	Q1 bus output positive V.11 signal, idle state +5 V
	Q1IN+	4	Q1 bus input positive V.11 signal, idle state +5 V
	Q1IN-	5	Q1 bus input negative V.11 signal, idle state 0 V
	Q1OUT-	6	Q1 bus output negative V.11 signal, idle state 0 V
	Q1ICL+	7	Q1 input clock positive, idle state +5 V ¹⁾
Q1ICL-	8	Q1 input clock negative, idle state +0 V ¹⁾	
1) Clock is not used in asynchronous Q1 use.			

Table 29 Q1 connector pins


RJ45 female connector	Pins of the AUX interface as seen from the front of the NCU		
	Signal	Pin	Explanation
	AUXOCL+	1	AUX bus output positive V.11 clock
	AUXOCL-	2	AUX bus output negative V.11 clock
	AUXOUT+	3	AUX bus output positive V.11 signal, idle state +5 V
	AUXIN+	4	AUX bus input positive V.11 signal, idle state +5 V
	AUXIN-	5	AUX bus input negative V.11 signal, idle state 0 V
	AUXOUT-	6	AUX bus output negative V.11 signal, idle state 0 V
	AUXICL+	7	AUX bus input/output positive V.11 clock
AUXICL-	8	AUX bus input/output negative V.11 clock	

Table 30 AUX connector pins

10.2.4 External supervisory interface


RJ45 female connector	Pins of the external supervisory interface as seen from the front of the NCU		
	Signal	Pin	Explanation
	PAI1	1	External Alarm Input 1
	PAI2	2	External Alarm Input 2
	PAI3	3	External Alarm Input 3
	PAIO1	4	External Alarm Input/Output 1
	PAIO2	5	External Alarm Input/Output 2
	IAV1	6	Analog Voltage Measurement Point 1
	IAV2	7	Analog Voltage Measurement Point 2
	GND	8	Ground

Table 31 External supervisory connector pins

10.2.5 Q3 management interface


RJ45 female connector	Pins of the Q3 interface as seen from the front of the NCU		
	Signal	Pin	Explanation
	TD+	1	Ethernet
	TD-	2	Ethernet
	RD+	3	Ethernet
	RXD	4	Unused
	TXD	5	Unused
	RD-	6	Ethernet
		7	Unused
GND	8	Ground	

Table 32 Q3 connector pins

10.3 Line Measurement Unit




Figure 39 Connectors on LMU

10.3.1 External supervision interface

The external supervision interface connector pinout is the same as for the NCU. Please refer to section 10.2.4.

10.3.2 External test access interface

This interface is not normally used. It should only be used when external test equipment will be used for testing the lines.


RJ45 female connector	Pins of the external test access interface as seen from the front of the LMU		
	Signal	Pin	Explanation
	TEST IN A	1	External test in
	TEST IN B	2	External test in
	TEST OUT A	3	External test out
	TEST OUT B	4	External test out
	N.C.	5	Unused
	N.C.	6	Unused
	N.C.	7	Unused
	GND	8	Ground

Table 33 External test connector pins

10.4 PSTN and ISDN units




Figure 40 Connectors on PSTN and ISDN plug-in units

Euroconnector		Pins of the PSTN interface as seen from the front of the PSTN unit		
	Pin	a	c	Explanation
	31	Pa1	Pb1	Line Interface 1
	29	Pa2	Pb2	Line Interface 2
	27	Pa3	Pb3	Line Interface 3
	25	Pa4	Pb4	Line Interface 4
	23	Pa5	Pb5	Line Interface 5
	21	Pa6	Pb6	Line Interface 6
	19	Pa7	Pb7	Line Interface 7
	17	Pa8	Pb8	Line Interface 8
	15	Pa9	Pb9	Line Interface 9
	13	Pa10	Pb10	Line Interface 10
	11	Pa11	Pb11	Line Interface 11
	9	Pa12	Pb12	Line Interface 12
	7	Pa13	Pb13	Line Interface 13
	5	Pa14	Pb14	Line Interface 14
	3	Pa15	Pb15	Line Interface 15
1	Pa16	Pb16	Line Interface 16	

Table 34 PSTN TRIB 1-16 Euroconnector pins (Upper Euroconnector)

Euroconnector		Pins of the PSTN interface as seen from the front of the PSTN unit		
	Pin	a	c	Explanation
	31	Pa17	Pb17	Line Interface 17
	29	Pa18	Pb18	Line Interface 18
	27	Pa19	Pb19	Line Interface 19
	25	Pa20	Pb20	Line Interface 20
	23	Pa21	Pb21	Line Interface 21
	21	Pa22	Pb22	Line Interface 22
	19	Pa23	Pb23	Line Interface 23
	17	Pa24	Pb24	Line Interface 24
	15	Pa25	Pb25	Line Interface 25
	13	Pa26	Pb26	Line Interface 26
	11	Pa27	Pb27	Line Interface 27
	9	Pa28	Pb28	Line Interface 28
	7	Pa29	Pb29	Line Interface 29
	5	Pa30	Pb30	Line Interface 30
	3	Pa31	Pb31	Line Interface 31
1	Pa32	Pb32	Line Interface 32	

Table 35 PSTN TRIB 17-32 Euroconnector pins (Lower Euroconnector)


Euroconnector	Pins of the ISDN U-interface as seen from the front of the ISDN unit			
	Pin	a	c	Explanation
	31	A1	B1	Line Interface 1
	29	A2	B2	Line Interface 2
	27	A3	B3	Line Interface 3
	25	A4	B4	Line Interface 4
	23	A5	B5	Line Interface 5
	21	A6	B6	Line Interface 6
	19	A7	B7	Line Interface 7
	17	A8	B8	Line Interface 8
	15	A9	B9	Line Interface 9
	13	A10	B10	Line Interface 10
	11	A11	B11	Line Interface 11
	9	A12	B12	Line Interface 12
	7	A13	B13	Line Interface 13
	5	A14	B14	Line Interface 14
	3	A15	B15	Line Interface 15
1	A16	B16	Line Interface 16	

Table 36 ISDN U-interface TRIB 1-16 Euroconnector pins

10.5 TR2M4 unit




Figure 41 Connectors on TR2M4 (75 Ω and 120 Ω)


Euroconnector		Pins of the 2 Mbit/s interface as seen from the front of the TR2M4			
	Pin	a	b	c	Explanation
	16	N.C.	GND	N.C.	Ground
	15	R1A	N.C.	R1B	Receive 1
	14	N.C.	GND	N.C.	Ground
	13	T1A	N.C.	T1B	Transmit 1
	12	N.C.	GND	N.C.	Ground
	11	R2A	N.C.	R2B	Receive 2
	10	N.C.	GND	N.C.	Ground
	9	T2A	N.C.	T2B	Transmit 2
	8	N.C.	GND	N.C.	Ground
	7	R3A	N.C.	R3B	Receive 3
	6	N.C.	GND	N.C.	Ground
	5	T3A	N.C.	T3B	Transmit 3
	4	N.C.	GND	N.C.	Ground
	3	R4A	N.C.	R4B	Receive 4
	2	N.C.	GND	N.C.	Ground
1	T4A	N.C.	T4B	Transmit 4	

Table 37 4 x 2 Mbit/s Euroconnector C/2




Figure 42 2 Mbit/s coaxial connectors

10.6 Data Interface Units




Figure 43 Connectors on Data Interface Units (DIU)


Euroconnector		Pins of the 2 x V.xx connector as seen from the front of the DIU				
	Pin	a	b	c	Explanation	
		32	N.C.	N.C.	N.C.	Unused
		31	P1_104a	N.C.	P1_104b	Receive data
		30	P1_142	N.C.	P1_102a	Test indicator/DTE ground
		29	P1_114a	N.C.	P1_114b	Tx element timing (DCE)
		28	P1_141	N.C.	–	Local loopback and reserved
		27	P1_115a	N.C.	P1_115b	Rx element timing (DCE)
		26	P1_113a	N.C.	P1_113b	Tx element timing (DTE)
		25	P1_103a	N.C.	P1_103b	Transmit data
		24	N.C.	N.C.	N.C.	Unused
		23	P1_106a	N.C.	P1_106b	Send
		22	P1_107a	N.C.	P1_107b	Data set ready
		21	P1_109a	N.C.	P1_109b	Data channel received
		20	P1_108a	N.C.	P1_108b	Data terminal ready
		19	P1_105a	N.C.	P1_105b	Send
		18	P1_140	N.C.	P1_102b	Remote loopback/DCE ground
		17	P1_102	N.C.	N.C.	Signal ground
		16	N.C.	N.C.	N.C.	Unused
		15	P2_104a	N.C.	P2_104b	Receive data
		14	P2_142	N.C.	P2_102a	Test indicator/DTE ground
		13	P2_114a	N.C.	P2_114b	Tx element timing (DCE)
		12	P2_141	N.C.	–	Local loopback and reserved
		11	P2_115a	N.C.	P2_115b	Rx element timing (DCE)
		10	P2_113a	N.C.	P2_113b	Tx element timing (DTE)
		9	P2_103a	N.C.	P2_103b	Transmit data
		8	N.C.	N.C.	N.C.	Unused
		7	P2_106a	N.C.	P2_106b	Send
		6	P2_107a	N.C.	P2_107b	Data set
		5	P2_109a	N.C.	P2_109b	Data channel received
		4	P2_108a	N.C.	P2_108b	Data terminal ready
		3	P2_105a	N.C.	P2_105b	Send
		2	P2_140	N.C.	P2_102b	Remote loopback/DCE ground
		1	P2_102	N.C.	N.C.	Signal ground

Table 38 2 x 2 Mbit/s Euroconnector C/2 for V.xx interfaces

Euroconnector		Pins of the 2 x X.21 connector as seen from the front of the DIU				
	Pin	a	b	c	Explanation	
	32	N.C.	N.C.	N.C.	N.C.	Unused
	31	P1_104a	N.C.	P1_104b	Receive data, R	
	30	N.C.	N.C.	N.C.	Unused	
	29	P1_114a	N.C.	P1_114b	Signal element timing DCE, S	
	28	N.C.	N.C.	N.C.	Unused	
	27	P1_115a	N.C.	P1_115b	Byte timing/DTE signal element timing, B	
	26	P1_113a	N.C.	P1_113b	Signal element timing DTE, X	
	25	P1_103a	N.C.	P1_103b	Transmit data, T	
	24	N.C.	N.C.	N.C.	Unused	
	23	N.C.	N.C.	N.C.	Unused	
	22	N.C.	N.C.	N.C.	Unused	
	21	P1_109a	N.C.	P1_109b	Indication I	
	20	N.C.	N.C.	N.C.	Unused	
	19	P1_105a	N.C.	P1_105b	Control C	
	18	N.C.	N.C.	N.C.	Unused	
	17	P1_102	N.C.	N.C.	Signal ground	
	16	N.C.	N.C.	N.C.	Unused	
	15	P2_104a	N.C.	P2_104b	Receive data, R	
	14	N.C.	N.C.	N.C.	Unused	
	13	P2_114a	N.C.	P2_114b	Signal element timing DCE, S	
	12	N.C.	N.C.	N.C.	Local loopback and reserved	
	11	P2_115a	N.C.	P2_115b	Byte timing/DTE signal element timing, B	
	10	P2_113a	N.C.	P2_113b	Signal element timing DTE, X	
	9	P2_103a	N.C.	P2_103b	Transmit data, T	
	8	N.C.	N.C.	N.C.	Unused	
	7	N.C.	N.C.	N.C.	Unused	
	6	N.C.	N.C.	N.C.	Unused	
	5	P2_109a	N.C.	P2_109b	Indication I	
	4	N.C.	N.C.	N.C.	Unused	
	3	P2_105a	N.C.	P2_105b	Control C	
	2	N.C.	N.C.	N.C.	Unused	
	1	P2_102	N.C.	N.C.	Signal ground	

Table 39 2 x 2 Mbit/s Euroconnector C/2 for X.21 interfaces


Euroconnector		Pins of the 2 x G.703 connector as seen from the front of the DIU				
	Pin	a	b	c	Explanation	
	32	N.C.	N.C.	N.C.	N.C.	Unused
	31	P1_104a	N.C.	P1_104b	P1_104b	Receive data
	30	N.C.	N.C.	N.C.	N.C.	Unused
	29	P1_114a	N.C.	P1_114b	P1_114b	Transmit element timing DCE
	28	N.C.	N.C.	N.C.	N.C.	Unused
	27	P1_115a	N.C.	P1_115b	P1_115b	Receive element timing DCE
	26	N.C.	N.C.	N.C.	N.C.	Unused
	25	P1_103a	N.C.	P1_103b	P1_103b	Transmit data
	24	N.C.	N.C.	N.C.	N.C.	Unused
	23	N.C.	N.C.	N.C.	N.C.	Unused
	22	N.C.	N.C.	N.C.	N.C.	Unused
	21	N.C.	N.C.	N.C.	N.C.	Unused
	20	N.C.	N.C.	N.C.	N.C.	Unused
	19	N.C.	N.C.	N.C.	N.C.	Unused
	18	N.C.	N.C.	N.C.	N.C.	Unused
	17	N.C.	N.C.	N.C.	N.C.	Unused
	16	N.C.	N.C.	N.C.	N.C.	Unused
	15	P2_104a	N.C.	P2_104b	P2_104b	Receive data
	14	N.C.	N.C.	N.C.	N.C.	Unused
	13	P2_114a	N.C.	P2_114b	P2_114b	Transmit element timing
	12	N.C.	N.C.	N.C.	N.C.	Unused
	11	P2_115a	N.C.	P2_115b	P2_115b	Receive element timing
	10	N.C.	N.C.	N.C.	N.C.	Unused
	9	P2_103a	N.C.	P2_103b	P2_103b	Transmit data
	8	N.C.	N.C.	N.C.	N.C.	Unused
	7	N.C.	N.C.	N.C.	N.C.	Unused
	6	N.C.	N.C.	N.C.	N.C.	Unused
	5	N.C.	N.C.	N.C.	N.C.	Unused
	4	N.C.	N.C.	N.C.	N.C.	Unused
	3	N.C.	N.C.	N.C.	N.C.	Unused
	2	N.C.	N.C.	N.C.	N.C.	Unused
1	N.C.	N.C.	N.C.	N.C.	Unused	

Table 40 2 x 64 kbit/s Euroconnector C/2 for G.703 interface

10.7 SAN CORE2M units

Refer to the *Synfonet Access Node Operating Manual* for further instructions on installing the SAN CORE2M units.




Figure 44 Connectors on the SAN CORE2M units T31491.**

10.7.1 Coaxial 2 Mbit/s interfaces (TRIB)




Figure 45 Coaxial 2 Mbit/s interfaces, TRIB. Notice that the interface numbering starts here from the bottom.

10.7.2 Symmetrical 2 Mbit/s interfaces (TRIB)

Euroconnector	Pins of the 2 Mbit/s interface as seen from the front of the SAN CORE2M unit				
	Pin	a	b	c	Explanation
	16	GND	R8B	R8A	Receive 8 / Ground
	15	N.C.	T8B	T8A	Transmit 8
	14	N.C.	R7B	R7A	Receive 7
	13	N.C.	T7B	T7A	Transmit 7
	12	N.C.	R6B	R6A	Receive 6
	11	GND	T6B	T6A	Transmit 6 / Ground
	10	N.C.	R5B	R5A	Receive 5
	9	N.C.	T5B	T5A	Transmit 5
	8	N.C.	R4B	R4A	Receive 4
	7	N.C.	T4B	T4A	Transmit 4
	6	GND	R3B	R3A	Receive 3 / Ground
	5	N.C.	T3B	T3A	Transmit 3
	4	N.C.	R2B	R2A	Receive 2
	3	N.C.	T2B	T2A	Transmit 2
	2	N.C.	R1B	R1A	Receive 1
	1	GND	T1B	T1A	Transmit 1 / Ground

Table 41 CORE2M symmetrical 2 Mbit/s interfaces connector, TRIB

10.7.3 Auxiliary interface (AUX)


9-pole male D-connector	Pins of the SR auxiliary interface as seen from the front of the SAN CORE2M unit		
	Signal	Pin	Explanation
	RCLKB	1	Future use (Receiver timing, wire b)
	RXB	2	Received signal, wire b
	GIO	3	Common signal ground
	TXB	4	Transmitted signal, wire b
	TCLKB	5	Future use (Transmitter timing, wire b)
	RCLKA	6	Future use (Receiver timing, wire a)
	RXA	7	Received signal, wire a
	TXA	8	Transmitted signal, wire a
	TCLKA	9	Future use (Transmitter timing, wire a)

Table 42 AUX connector pins

10.7.4 Synchronisation interfaces (SR, ST)


9-pole male D-connector	Pins of the SR synchronisation interface as seen from the front of the SAN CORE2M unit		
	Signal	Pin	Explanation
	N.C.	1	Unused
	RCLKB	2	Received synchronisation reference, wire b
	GIO	3	Common signal ground
	N.C.	4	Unused
	N.C.	5	Unused
	GIO	6	Common signal ground
	RCLKA	7	Received synchronisation reference, wire a
	N.C.	8	Unused
	N.C.	9	Unused

Table 43 SR synchronisation connector pins


9-pole male D-connector	Pins of the ST synchronisation interface as seen from the front of the SAN CORE2M unit		
	Signal	Pin	Explanation
	N.C.	1	Unused
	N.C.	2	Unused
	GIO	3	Common signal ground
	TCLKB	4	Transmitted synchronisation reference, wire b
	N.C.	5	Unused
	N.C.	6	Unused
	N.C.	7	Unused
	TCLKA	8	Transmitted synchronisation reference, wire a
	GIO	9	Common signal ground

Table 44 ST synchronisation connector pins

Coaxial interface option

Each synchronisation interface can be equipped with an asymmetrising adapter, which converts the interface into 75 Ω coaxial interface. The connector can be chosen as Type43 or SMB. The same adapter can be used in either the receiving or transmitting interface.

Chapter 11

Installing and cabling the plug-in units

Before beginning the installation procedure, make sure that you have an installation plan available.

Caution

Do not add units in the configuration during software download.

Install the plug-in units into the subrack after the subrack has been mounted into the rack.

The units' front panels provide effective EMC screening, and in most cases unshielded cables can be used (see Chapter 2 and section 4.1 for restrictions).

Installing the units

1. Familiarise yourself with the installation plan.
Do not insert units into incorrect slots (section 11.1).
 2. Open the subrack cover, if fitted, see section 13.3.
-

Caution

Wear a wrist earthing strap or other such protection when handling plug-in units which have been removed from their package (section 11.2).

3. Insert the plug-in units into the subrack (section 11.3).
4. Fit blanking plates to all unused subrack locations to provide electromagnetic shielding (section 11.4).
5. Keep a record of the unit identification data of each unit, see markings in section 4.2.
6. Connect the optical fibres to the optical interface units. Route the fibres as illustrated in section 4.3.

7. Connect electrical cables to the interfaces, see section 11.5.
8. Close the subrack cover (optional). See that the optical fibres are not left in stress under the cover (section 13.3).

11.1 Unit locations

11.1.1 Coding system of the unit slots

Each plug-in unit type is provided with a mechanical unit slot coding block. The coding prevents you from installing the unit into an incorrect slot in the subrack. The coding blocks of the plug-in units and backplane connectors are colour coded. Plug-in units must only be connected to backplane connectors with matching coding blocks.




Figure 46 Unit slot coding. When the coding pin and the slot in the coding block match, the plug-in unit can be inserted into the unit slot.

11.1.2 Recommended unit slots

Two different 17-slot Eksos subrack and 8-slot Eksos cartridge versions are available. One of these has slots reserved for housing SAN CORE2M units.

Tables 45 and 46 show which plug-in units can be fitted into each unit slot of the 17-slot Eksos subracks.

Key to slot coding tables

 = required unit slot

 = allowed unit slot

 = not allowed unit slot

Note: This subrack cannot house CORE2M units



Unit/slot	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
NCU																	
PSTN																	
LMU																	
ISDN																	
TR2M4																	
DIU																	
ACL4																	

Table 45 Recommended unit slots in Eksos N20 subrack
























Unit/slot	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
CORE2M																	
NCU																	
PSTN																	
LMU																	
ISDN																	
TR2M4																	
DIU																	
ACL4																	

Table 46 Recommended unit slots in Eksos N20/SAN subrack

Key to slot coding tables

 = required unit slot

 = allowed unit slot

 = not allowed unit slot

Note: This cartridge cannot house CORE2M units








Unit/slot	1	2	3	4	5	6	7	8
NCU								
PSTN								
LMU								
ISDN								
TR2M4								
DIU								
ACL4								

Table 47 Recommended unit slots in Eksos N20 cartridge























Unit/slot	1	2	3	4	5	6	7	8
CORE2M								
NCU								
PSTN								
LMU								
ISDN								
TR2M4								
DIU								
ACL4								

Table 48 Recommended unit slots in Eksos N20/SAN cartridge

11.2 Handling plug-in units

Grasp the plug-in units by the insertion/extraction levers or back connectors.




Figure 47 Holding a plug-in unit



Caution

When removing a plug-in unit from its anti-static packaging, you must equalise your potential with the rack. Always use an earthing wrist strap when handling plug-in units. The subrack and rack have special connectors for this purpose, see Figure 48.




Figure 48 Example of connecting the earthing wrist strap to the subrack

Optical interface units

The optical interfaces are sealed with protective caps. Remove the caps before connecting the optical fibres. Store the caps for later use.

When removing optical interface units, disconnect the unit from the subrack backplane before removing the optical cables from the optical connectors. When the optical interface unit has been removed, make sure that the protective caps are put back on to the optical interfaces. Fit protective caps to optical cables if they are going to be left disconnected.

11.3 Inserting plug-in units

Note

Before installing a plug-in unit, ensure that its colour coding block matches the colour of the coding block in the backplane slot.

► Inserting a plug-in unit (see Figure 49):

1. Open the unit's insertion/extraction levers.
2. Insert the unit into the subrack slot.
3. Close the insertion/extraction levers when the plug-in unit is in place.
4. Firmly tighten the finger screws of the plug-in units.




Figure 49 Inserting a plug-in unit into a subrack

11.4 Fitting blanking plates for unused unit locations

For correct EMC performance, one-slot blanking plates must be fitted to the front of the subrack to cover all slots which are not occupied by plug-in units. When installing blanking plates, take care not to damage the EMI gasket.




Figure 50 One-slot blanking plate for unused plug-in unit locations

11.5 Cabling plug-in units

11.5.1 Inserting and replacing connector carriers




Figure 51 Inserting and replacing cables and carriers: coaxial connectors




Figure 52 Inserting and replacing cables and carriers: Euroconnectors

11.5.2 Cabling the Data Interface Unit

If you are using cables that are shorter than 3 m, the cable must always be EMC-shielded. If you are using cables longer than 3 m, the first 3 m of the cable must be shielded, but the rest of the cable can be unshielded.

The earth wire must always be connected.

For EMC reasons, the connectors on the DIU must have a protective metallic housing whenever the V.24/V.28 interface is used. If this interface is not used at all, a plastic housing can also be used.

The metallic housing is rather rigid, so you may need to use pliers or other such tool to close the snaps.




Figure 53 Assembling the EMC connector of the Data Interface Unit




Figure 54 Connecting cables to Data Interface Unit

11.5.3 Tying electrical cables to cable trays




Figure 55 Principle of tying electrical cables to cable trays

11.6 Connecting Eksos N20 to SAN

Connecting 2 Mbit/s interfaces

The 2 Mbit/s aggregate interfaces of the NCU can be connected to tributary 2 Mbit/s interfaces of SAN CORE2M units to provide STM-1 interfaces.

A SAN CORE2M unit can be installed into a special Eksos N20/SAN Subrack (T30427.03). Alternatively, separate SDH units such as a SAN CORE2M and SAN2M unit can be installed into a separate SAN Cartridge.

One SAN CORE2M unit provides 8 x 2 Mbit/s interfaces, three SAN2M units provide up to 3 x 21 x 2 Mbit/s interfaces and an NCU provides 4 x 2 Mbit/s interfaces. This means that the SAN units can provide tributary interfaces to multiple NCU aggregate interfaces.

75 Ω interfaces

The 2 Mbit/s interfaces (75 Ω) of both the NCU and SAN CORE2M unit are realised by the use of coaxial 1.0/2.3 connectors with a dual layout principle utilising similar coaxial carrier construction practices (see Figure 51).

Note

The connections must be made externally using jumper cables.

The point-to-point connections are made using coaxial jumper cables. See Chapter 10.

120 Ω interfaces

The 2 Mbit/s interfaces (120 Ω) of both the NCU and the SAN CORE2M units are realised by the use of 3 x 16 pin Euroconnectors. See Chapter 10.

Note

The connections must be made externally using shielded jumper cables.

A prefabricated shielded jumper cable (E30445.04) is available for connecting a SAN CORE2M unit (8 x 2 Mbit/s) to two NCUs (2 x 4 x 2 Mbit/s). This cable can be used to connect a SAN CORE2M unit to an NCU. The NCU can be in a neighbouring Eksos N20 subrack or, in the case of the Eksos N20/SAN Subrack, installed in the same subrack as the SAN CORE2M unit.




Figure 56 Example of connecting SAN CORE2M and NCU 2 Mbit/s interfaces

Connecting external synchronisation interfaces

The different NCU variants provide both 75 Ω unbalanced and 120 Ω balanced external synchronisation interfaces. See Chapter 10.

The 75 Ω unbalanced interface is realised by the use of Coaxial 1.0/2.3 connectors and the 120 Ω balanced interface is realised by the use of RJ45 connectors. Both interface types provide one input and one output connector.

The SAN CORE2M units provide only 120 Ω balanced external synchronisation interfaces realised by the use of 9-pin input and 9-pin output D-connectors.

Note

To provide an external synchronisation interface between an NCU and SAN CORE2M unit installed into the same Eksos N20/SAN subrack (T30427.03), we recommend that the T35010.11 and T35010.21 versions of the NCU are used.

Both NCU versions provide a 120 Ω balanced interface type. In this case a 9-pin D-connector / RJ45 Adapter Cable will need to be made.




Figure 57 Connecting synchronisation interfaces

If a 75 Ω external synchronisation input of the NCU is to be connected to a 120 Ω external synchronisation output of a SAN CORE2M unit in a separate cartridge or to another SYNFO NET equipment, the 120 Ω output can be converted by the use of an external Synchronisation Adapter (T30420.09 or T30420.10). See the equipment’s manual for information concerning the installation of the adapter.

11.7 Service switch cabling

Wiring before the service is switched

Each PSTN and ISDN unit has relays for switching up to two subscriber interfaces to some dedicated lines in the backplane. These service switch lines are wired to a set of RJ45 connectors on the subrack extension board. Each line uses two pins on an RJ45, so when a service is switched, each subscriber line is connected to two pins of one of the RJ45 connectors. Cabling is needed from this point onwards and it has to be installed in advance.

To provide for remote upgrades from PSTN to ISDN, cabling is needed from the RJ45 connector on extension board of the Eksos N20 subrack to an ISDN interface (of the same Eksos N20 node, or the interface on another node).

To provide for remote upgrades from PSTN to ADSL+PSTN, cabling is needed from the RJ45 connector on extension board of the Eksos N20 subrack to the Digital Subscriber Line Access Multiplexer (DSLAM), then from the splitter on the DSLAM back to a PSTN interface (of the same Eksos N20 node, or the interface on another node).




Figure 58 Principle of wiring for PSTN and ISDN service upgrade; main distribution frame used




Figure 59 Principle of wiring for PSTN and ISDN service upgrade; reserved service upgrade connectors




Figure 60 Principle of wiring for PSTN or ISDN service upgrade; main distribution frame used




Figure 61 Principle of wiring for PSTN and ISDN service upgrade; the existing line is changed to fixed ADSL/PSTN (ISDN) connection

For pinout of service switch connectors in connector block J2A, see Chapter 5. For pinout of PSTN and ISDN units, see section 10.4.

Correlation between unit slot in which the unit is installed and the pins to which the interface can be wired			
Unit slot number	J2A (RJ45)	RJ45 pin where the interface is switched to	Switched ISDN lines
2, 6, 10, 14	B	1,2 and 3,4	1 and 2
3, 7, 11, 15	B	5,6 and 7,8	3 and 4
4, 8, 12, 16	A	1,2 and 3,4	5 and 6
5, 9, 13, 17	A	5,6 and 7,8	7 and 8

Table 49 Correlation between unit slot and switched ISDN line

Correlation between unit slot in which the unit is installed and the pins to which the interface can be wired			
Unit slot number	J2A (RJ45)	RJ45 pin where the interface is switched to	Switched PSTN lines
5, 9, 13, 17	D	1,2 and 3,4	1 and 2
2, 6, 10, 14	D	5,6 and 7,8	3 and 4
3, 7, 11, 15	C	1,2 and 3,4	5 and 6
4, 8, 12, 16	C	5,6 and 7,8	7 and 8

Table 50 Correlation between unit slot and switched PSTN line

Wiring after the service has been switched

To make the switch permanent, the subscriber lines have to be cabled as if there was no temporary remote switch:

- Wire the switch cabling to other, free interfaces that can then be used for future remote switches.
- Wire the switched subscriber lines directly to the interfaces these subscribers have been switched to.

This wiring should be done when the site is visited the first time after the subscriber lines have been switched.

Chapter 12

Ethernet cabling

When planning your Ethernet topology, you should divide the Ethernet into segments as follows:

- Connect network elements which belong to the same IS-IS level 2 routing area into the same Ethernet segment. This will reduce ISO/IP traffic in your local area management network.
- We recommend that ISO/IP and TCP/IP networks are kept separate.




Figure 62 Q3 DCN via SAN 10Base-2 Ethernet connector




Figure 63 10Base-2 (thin wire) Ethernet connection to WAN




Figure 64 Q3 DCN via SAN DCC and 10Base-T Hub

Chapter 13

Installing auxiliary equipment and accessories

Before beginning the installation, make sure that you have an installation plan available.

13.1 Fan unit




Figure 65 Fan Unit with earthing cable and rotatable mounting brackets




Figure 66 Mounting the Fan Unit into 19" and ETSI racks with rotatable mounting brackets

13.2 Air deflectors

The air deflectors, with or without front grilles, are available in 1U or 4U heights, but 2U and 5U air deflectors can also be used if no cable trays are installed below and above the subrack.




Figure 67 Principle of mounting the air deflector and front grille

13.3 Subrack front cover

The front cover provides protection for the cables but is not necessary for EMC shielding purposes. Front covers are not necessary if you are installing the subrack into a rack which has a front door.

If a front cover is to be used with an Eksos N20 subrack, it is necessary to fit spring clips to each side of the subrack to hold the cover (see Figure 68). Adjust the vertical position of the spring clips so that the unit LEDs can be seen through the front cover.

► Attaching the front cover:

1. Align the holes in the cover with the red spring clips on the subrack.
2. To secure the cover, push the cover squarely onto the subrack until all of the spring clips have clicked.

► Detaching the front cover:

1. Push in the top red spring clips at each side of the cover (see Figure 69).
2. With the springs depressed, lift the cover up and away from the subrack.




Figure 68 Attaching the spring clips to the subrack




Figure 69 Attaching and detaching the front cover to the 17-slot subrack

Front covers are also available for the DC-PSA, Fan Unit and Capacitor Unit. For further details, see their respective documentation.

Nokia Eksos N20

Narrowband Multiservice Access Node

Commissioning and Maintenance

NOKIA

The information in this document is subject to change without notice and describes only the product defined in the introduction of this documentation. This document is intended for the use of Nokia Networks' customers only for the purposes of the agreement under which the document is submitted, and no part of it may be reproduced or transmitted in any form or means without the prior written permission of Nokia Networks. The document has been prepared to be used by professional and properly trained personnel, and the customer assumes full responsibility when using it. Nokia Networks welcomes customer comments as part of the process of continuous development and improvement of the documentation.

The information or statements given in this document concerning the suitability, capacity, or performance of the mentioned hardware or software products cannot be considered binding but shall be defined in the agreement made between Nokia Networks and the customer. However, Nokia Networks has made all reasonable efforts to ensure that the instructions contained in the document are adequate and free of material errors and omissions. Nokia Networks will, if necessary, explain issues which may not be covered by the document.

Nokia Networks' liability for any errors in the document is limited to the documentary correction of errors. Nokia Networks WILL NOT BE RESPONSIBLE IN ANY EVENT FOR ERRORS IN THIS DOCUMENT OR FOR ANY DAMAGES, INCIDENTAL OR CONSEQUENTIAL (INCLUDING MONETARY LOSSES), that might arise from the use of this document or the information in it.

This document and the product it describes are considered protected by copyright according to the applicable laws.

NOKIA logo is a registered trademark of Nokia Corporation.

Any other trademarks mentioned in the documents are the property of their respective companies, and they are mentioned for identification purposes only.

Copyright © Nokia Corporation 2000-2003. All rights reserved.

Document History

Document	Date	Comment
C33836006SE_00	14 Dec 2000	
C33836006SE_A0	5 Apr 2001	
C33836006SE_B0	4 Jan 2002	
C33836006SE_C0	20 Sep 2002	
C33836006SE_D0	29 Jan 2003	Change in Appendix B.

Contents

Chapter 1	
About this document	1
Chapter 2	
Commissioning requirements and procedure	3
2.1 General commissioning procedure	3
2.2 Basic commissioning for all Eksos N20 nodes	4
2.2.1 Requirements	4
2.2.2 Procedure	5
2.3 Commissioning a V5.2 multiplexer	6
2.3.1 Requirements	6
2.3.2 Procedure	7
2.4 Commissioning a V5.1/V5.2 converter	9
2.4.1 Requirements	9
2.4.2 Procedure	10
2.5 Commissioning a service switch	11
2.5.1 Requirements	11
2.5.2 Procedure	11
2.6 Commissioning leased lines	13
2.6.1 Requirements	13
2.6.2 Procedure	14
2.7 Commissioning an application for scheduled line testing	14
2.7.1 Requirements	14
2.7.2 Procedure	15
Chapter 3	
Detailed instructions	17
3.1 Switching the power on	17
3.2 Connecting Node Manager cable to the node	18
3.3 Starting Node Manager	19

3.4	Connecting to a node	20
3.4.1	Connecting to a fresh node	20
3.4.2	Reconnecting using the new address	23
3.5	Changing node settings	24
3.6	Installing plug-in units	24
3.7	Configuring 2M interfaces	25
3.8	Configuring synchronisation	26
3.9	Configuring management channels (DCN time slots)	29
3.10	Configuring external alarms and station alarms	32
3.10.1	Configuring Digital Inputs	33
3.10.2	Configuring Digital Inputs/Outputs	34
3.10.3	Configuring Analog Inputs	35
3.11	Creating and configuring a V5 interface	37
3.11.1	V5.2 interface	37
3.11.2	V5.1 interface	45
3.12	Configuring PSTN interfaces	49
3.13	Configuring ISDN interfaces	51
3.14	Provisioning user ports	54
3.14.1	Identifying interfaces and time slots	55
3.14.2	Configuring, editing and deleting user ports	56
3.14.3	Blocking and unblocking a user port	58
3.15	Starting or stopping a V5 interface	59
3.16	Editing or deleting a V5 interface	60
3.17	Configuring service switches	61
3.17.1	Configuring service switch cabling	62
3.17.2	Switching a service	63
3.17.3	Re-configuring service switches	64
3.18	Configuring DIU interfaces	65
3.19	Configuring leased lines	67
3.20	Configuring and viewing monitoring data	71
3.20.1	Current alarms list	71
3.20.2	Event history log	71
3.20.3	Performance monitoring	73
3.20.4	Block status	77
3.21	Line testing	78
3.21.1	On-demand tests	79
3.21.2	Scheduled tests	86
3.22	Stopping Node Manager	89
3.23	Clearing node configuration data ('blasting' the node)	91

Chapter 4	
Managing alarms	93
4.1 Alarm severity	93
4.2 LED indicators of plug-in units	94
4.3 Station alarm lamps and relays	95
4.4 Managing alarms with Node Manager	96
Chapter 5	
Upgrading	99
5.1 Adding and removing tributary units	99
5.1.1 Adding tributary units	99
5.1.2 Removing tributary units	100
5.1.3 Replacing tributary units	100
5.2 Downloading software	101
Appendix A	
Installing and using Eksos N20 Node Manager	A-1
A.1 Installing Eksos N20 Node Manager	A-1
A.1.1 Modifications to your Windows operating system	A-2
A.1.2 Installation procedure	A-4
A.1.3 Changing the stack startup	A-6
A.1.4 Changing the NSAP address after installation	A-7
A.1.5 Enabling security	A-7
A.1.6 Frequently asked questions	A-10
A.2 Using Eksos N20 Node Manager	A-11
A.2.1 Description of Eksos N20 Node Manager	A-11
A.2.2 Operating Eksos N20 Node Manager	A-13
Selecting actions	A-13
Receiving data from the node	A-14
Making changes to the node	A-14
A.2.3 Using online Help	A-14
A.2.4 Saving and loading data as files	A-15
Saving the whole node	A-15
Saving data from a window	A-16
Loading a whole node configuration from file	A-17
A.2.5 Printing data	A-18
A.2.6 Frequently asked questions	A-19
A.2.7 Main menus of Eksos N20 Node Manager	A-20
Appendix B	
Alarm messages	B-1

Appendix C

Windows for Data Interface Units	C-1
C.1 Subrack window	C-1
C.2 Unit configuration window	C-1
C.3 Functional block settings window	C-2
C.4 Advanced interface settings tabs	C-6
C.4.1 G.703 tab	C-7
C.4.2 X.21 tab	C-8
C.4.3 V.xx tab	C-10
C.4.4 V110 Adaptation tab	C-13
C.4.5 X.30 Adaptation tab	C-15
C.4.6 Input buffer tab	C-16
C.4.7 Sampling tab	C-17
C.4.8 V.14 tab	C-18
C.4.9 POH tab	C-19
C.4.10 Bitmasks tab	C-20



Chapter 1

About this document

This document explains how to take Nokia Eksos N20 nodes into use. The tool used to perform the actions described in this document is called Nokia Eksos N20 Node Manager.

For brevity, the name *Node Manager* is used for Nokia Eksos N20 Node Manager.

This document covers the following topics:

- Commissioning requirements and procedures (Chapter 2)
- Detailed instructions for the commissioning: (Chapter 3)
 - Switching power on
 - Connecting Node Manager cable to a node
 - Starting Node Manager
 - Connecting to a node
 - Changing node settings
 - Installing plug-in units
 - Configuring 2M interfaces
 - Configuring synchronisation settings
 - Configuring management channels
 - Configuring external alarms
 - Creating and configuring a V5 interface
 - Configuring PSTN and ISDN interface settings
 - Provisioning user ports
 - Starting and stopping a V5 interface
 - Editing or deleting a V5 interface
 - Configuring service switches
 - Configuring Data Interface Unit interfaces
 - Configuring leased lines
 - Configuring event history log and performance monitoring settings
 - Line testing
 - Stopping Node Manager
- Managing alarms (Chapter 4)
- Upgrading (Chapter 5)
- Installing and using Eksos N20 Node Manager (Appendix A)
- Alarm messages (Appendix B)
- DIU windows (Appendix C).

Chapter 2

Commissioning requirements and procedure

This chapter explains how to take Eksos N20 nodes into use. It assumes that the following tasks have already been successfully completed:

- mechanical installation has been completed
- cables have been connected and plug-in units inserted
- the power supply has been connected
- Node Manager has been installed in the PC
- you have made an application plan (a node configuration plan).

For instructions for commissioning the SAN CORE2M units, refer to the *SYNFONET Access Node* documentation.

For instructions for commissioning the OSI-DCN Adaptor units, refer to the *OSI-DCN Adaptor User Manual*.

Note

Information for application planning can be found in the *Product Description*.

2.1 General commissioning procedure

This section presents the general procedure required to commission the Eksos N20 node. Note that commissioning must always begin with an application plan. The actual commissioning tasks vary according to this plan and the required Eksos N20 application.

All Eksos N20 nodes require basic commissioning (section 2.2). The commissioning procedures for specific applications are given in sections 2.3 to 2.7.

- Follow this procedure to start and configure a node:
1. Make an application plan. For information needed in planning, see sections 2.2 to 2.7 in this document and the relevant sections in the *Product Description* document.
 2. Switch the power on (see section 3.1).
 3. Connect Node Manager cable to the node (see section 3.2).
 4. Start Node Manager (see section 3.3).
 5. Make the basic node settings (see sections 2.2 and 3.4).
 6. Disconnect from the node and reconnect to the node using the new address (see section 3.4.2).
 7. Do the commissioning tasks according to sections 2.3 to 2.7:
 - Commissioning a V5.2 multiplexer (see section 2.3)
 - Commissioning a V5.1 / V5.2 converter (see section 2.4)
 - Commissioning a service switch (see section 2.5)
 - Commissioning leased lines (see section 2.6)
 - Configuring scheduled line tests (see section 2.7).
- Note that Eksos N20 nodes support simultaneously all of these applications. If you want to use Eksos N20 for all applications, follow the detailed instructions in Chapter 3.
8. Make the event log settings and configure performance monitoring if wanted (see section 3.20).
 9. Close the connection to the node (see section 3.22).

2.2 Basic commissioning for all Eksos N20 nodes

Basic commissioning is needed for all Eksos N20 applications. This procedure configures the basic settings that the node needs to operate. Before starting the basic commissioning, make sure that the installation and cabling have been done as shown in the *Installation* document and that there exists an application plan.

2.2.1 Requirements

For basic commissioning of an Eksos N20 node, you will need the following:

- a minimum of one NCU unit
 - in slot one if Eksos N20 subrack or cartridge is used
 - in slot three if Eksos N20/SAN subrack or cartridge is used
- node address (NSAP) to identify the node in the network
- node name and its location information
- information about synchronisation sources
- information about the time slots used for communication channels
- local exchange (LE) information.

2.2.2 Procedure

- ▶ To do the basic commissioning on the Eksos N20 node, follow the procedure in Table 1:

Task	How? Refer to:	Remarks and tips
1. Set node name and location.	Section 3.4	This is optional but recommended. Node names can be added to databases to help network management.
2. Set the node address (NSAP).	Section 3.4	For the node address, you need the following information: – Area name – AFI – IDI – Node system ID.
3. Install the units with the software.	Section 3.4	Node Manager does this when commissioning the node for the first time.
4. Configure the aggregate 2M interface.	Section 3.7	Some of the interfaces will be used as synchronisation sources. Often the same interfaces are used as V5 links. One or two of these interfaces may carry Q3 traffic.
5. Build the synchronisation priority list.	Section 3.8	Possible synchronisation sources: – any 2 Mbit interface from NCU or TR2M4 – external synchronisation input from master NCU – internal clock (always last on the list) Typically, the bits in the 2Mbit/s signal that is used to connect to an LE are used for synchronisation.
6. Set up the Q3 management channel.	Section 3.9	Typically, a time slot in one of the 2 Mbit/s signals towards the LE is used for Q3. If the LE does not support fractional V5.2 interface (where some of the time slots are used for other than V5), it may be better to connect the Q3 traffic through Ethernet interface to the Ethernet interface of the on-site SYNFO NET equipment and route the Q3 in the SDH overhead. Alternatively, the Q3 traffic could be connected to the V.11 interface and then to third-party equipment that route it onwards.

Table 1 Procedure for basic commissioning

2.3 Commissioning a V5.2 multiplexer

Before commissioning a V5.2 multiplexer, make sure that the installation and cabling have been done as shown in the *Installation* document. Also make sure that the basic commissioning has been done as explained in section 2.2.

The configuration at both ends of a V5 interface must always match. Thus, the configuration of the V5.2 interface in Eksos N20 must be exactly the same as in the LE.

2.3.1 Requirements

To commission a V5.2 multiplexer, you will need the following:

- plug-in units
 - a minimum of one NCU unit in slot one (Eksos N20 subrack or cartridge) or slot three (Eksos N20/SAN subrack or cartridge); each V5.2 interface requires one NCU
 - PSTN and/or ISDN units for subscriber interfaces
- configuration information about the V5.2 interfaces at the local exchange (LE)
 - interface ID and provisioning variant
 - IDs for the 2M links used to connect to the LE
 - time slots and IDs for the communication channels
 - time slots used to provide protection
 - L3 and EF addresses for user ports (subscriber interfaces).

Each NCU provides four 2 Mbit/s interfaces that can be associated with any V5.2 interface. There must be at least one NCU per each V5.2 interface. One 2 Mbit/s interface can carry up to 30 (or 31, if time slot 16 is not used for signalling) simultaneous phone calls.

2.3.2 Procedure

► To commission a V5.2 multiplexer, follow the procedure in Table 2:

Task	How? Refer to:	Remarks and tips
1. Do the basic commissioning.	Section 2.2.2	
2. Set the interface ID and provisioning variant. Optionally give a name.	Section 3.11.1	The ID has to be the same on the node and LE. The node's provisioning variant must match the active variant at the LE.
3. Configure 2M links.	Section 3.11.1	You can simplify the procedure by using numbering schemes or rules. The links can be given IDs that start from the interface ID: for example, an interface with interface ID 53 could use links with IDs 53, 54 and 55.
4. Configure communication channels (C-channels).	Section 3.11.1	<ul style="list-style-type: none"> – The C-channel configuration must be identical with the configuration defined in the LE. – At least one C-channel carrying the vital protocols must be assigned to time slot 16 of one link. – If two or more links are used, time slot 16 of the secondary link must be assigned as the location for a vital standby channel.
5. Configure signalling and protection.	Section 3.11.1	<ul style="list-style-type: none"> – You can simplify the procedure by always placing the signalling protocols in time slot 16 of the primary link and the protection in time slot 16 of the secondary link. – PSTN and ISDN protocols can be placed in the time slot used for the vital protocols or in a different time slot. – It is possible to set the ISDN-Ds signalling in several different C-channels. – It may be wise to place the ISDN protocols in a link that is located on an NCU that is a pure V5 slave. This way ISDN messages can be routed through the node without loading the V5 master. – Up to three protecting standby channels can be set for PSTN and ISDN protocols. These can be set to any of free time slots 15, 16 or 31 of any link.
6. Start interfaces.	Section 3.11.1	
7. Configure user ports.	Section 3.14.2	Numbering rules can be used. For example, you can set the PSTN L3 addresses to be: (slot number – 1) × 32 + interface number.

Table 2 Procedure for commissioning a V5.2 multiplexer

Examples for configuring V5.2 interfaces

Link	TS 15	TS 16	TS 31
NCU 1, interface 1, link ID 21		C-channel 0: vital protocols, PSTN, ISDN-Ds	
NCU1, interface 2, link ID 22		Vital standby	

Table 3 Configuring a simple, small V5.2 interface

In the example of Table 3, a problem in link 21 would cause all protocols to be moved to time slot 16 of link 22.

Link	TS 15	TS 16	TS 31
NCU 1, interface 1, link ID 71	C-channel 1: ISDN-Ds	C-channel 0: vital protocols PSTN	
NCU 1, interface 2, link ID 72	Standby	Vital standby	
NCU 1, interface 3, link ID 73			
NCU 1, interface 4, link ID 74			
NCU 2, interface 3, link ID 75			
NCU 2, interface 4, link ID 76			

Table 4 Configuring a large V5.2 interface

In the example of Table 4, a problem in link 71 (the primary link) would cause the vital protocols to be moved to time slot 16 of link 72 (the secondary link) and the ISDN-Ds protocol to time slot 15.

2.4 Commissioning a V5.1/V5.2 converter

Before commissioning a V5.1/V5.2 converter, make sure that the installation and cabling have been done as shown in the *Installation* document. As the converter application is an extension of the V5.2 multiplexer application, read first also section 2.3. Also, make sure that the basic commissioning has been done as explained in section 2.2.

The configuration at both ends of a V5 interface must always match. In the converter application, the configuration of the V5.2 interfaces must match the configuration information at the local exchange (LE) and the configuration of the V5.1 interfaces must match the configuration information in the V5.1 node.

2.4.1 Requirements

To commission a V5.1/V5.2 converter, you will need the following:

- plug-in units
 - a minimum of one NCU unit in slot one (Eksos N20 subrack or cartridge) or slot three (Eksos N20/SAN subrack or cartridge)
 - a minimum of one TR2M4 unit to provide a V5.1 interface to the V5.1 node (one TR2M4 unit can connect to four V5.1 nodes)
- configuration information about the V5.2 interfaces at the local exchange (LE)
 - interface ID and provisioning variant
 - IDs for the 2M links used to connect to the LE
 - time slots for the communication channels
 - time slots used to provide protection
 - L3 and EF addresses for user ports (subscriber interfaces)
- configuration information about the V5.1 nodes
 - physical 2 Mbit/s used for Eksos N20
 - time slots and IDs for the communication channels
 - time slots used for user ports and their addresses
 - information about possible leased lines on the V5.1 node.

2.4.2 Procedure

- ▶ To commission a V5.1/V5.2 converter, follow the procedure in Table 5:

Task	How? Refer to:	Remarks and tips
1. Do the basic commissioning.	Section 2.2.2	
2. Configure V5.2 interface if not done already.	Section 3.11.1	See Table 2.
3. Set the V5.1 interface ID and provisioning variant, optionally give a name.	Section 3.11.2	
4. Configure the 2M link.	Section 3.11.2	Possibly reserve a time slot for Q1 management.
5. Configure communication channels (C-channels).	Section 3.11.2	Time slots available: 15, 16 and 31.
6. Configure signalling.	Section 3.11.2	<ul style="list-style-type: none"> – Vital protocols always use the C-channel in time slot 16. – The PSTN and ISDN protocols can be placed in any C-channel created. – In V5.1, there can be only one instance for the ISDN-Ds protocol.
7. Start interface.	Section 3.11.2	
8. Configure user ports for V5.2 and V5.1 interfaces.	Section 3.14.2	A PSTN subscriber uses one time slot; an ISDN subscriber normally uses two time slots.
9. Set up Q1 management of the V5.1 node.	Section 3.9	

Table 5 Procedure for commissioning a V5.1/V.2 converter

2.5 Commissioning a service switch

Note

Before starting to configure service switches, make a plan and follow it consistently.

Before commissioning a service switch, make sure that the installation and cabling have been done as shown in the *Installation* document. Also, make sure that the basic commissioning has been done as explained in section 2.2.

2.5.1 Requirements

To commission a service switch, you will need the following:

- plug-in units
 - a minimum of one NCU in slot one (Eksos N20 subrack/cartridge) or slot three (Eksos/SAN subrack or cartridge)
 - PSTN and/or ISDN units
 - to provide ADSL services, broadband equipment should be available.
- application specific installation and cabling
 - the service switch cabling must be in place
- configuration information
 - configuration information of the V5.2 user ports and their addresses
 - information about the service switch cabling. It is often logistically efficient to standardise the configurations for sets of node types.
 - cabling information about other equipment, such as broadband equipment.

2.5.2 Procedure

The work takes place in three phases:

1. Preparing the service switch cabling. This phase is the most efficient when the service switch is taken into account in the initial installation. The cabling information is also configured in the node.
2. Switching services for one or more subscriber lines. This is done when a customer requests upgrading to ISDN or ADSL. Switching is done remotely, without visiting the site.
3. Changing the temporary service switches into permanent ones and releasing the resources for new remote service switches. This should be done during the first site visit after the service upgrade.

Restrictions

When configuring the service switch, take into consideration the following restrictions:

- one service switch connection per plug-in unit
- each plug-in unit can access one out of two accessible bus lines
- up to eight service switch connections for PSTN units per subrack
- up to eight service switch connections for ISDN units per subrack
- service switch connections are not activated during ongoing line tests
- line tests have higher priority than service switch connections if the **Super Cut Call** option is used in line testing.

► To commission a service switch, follow the procedure in Table 6:

Task	How? Refer to:	Remarks and tips
1. Do the basic commissioning.	Section 2.2.2	
2. Add cabling information to the node.	Section 3.17.1.	The node has no means for checking the cabling, so special attention is required.
3. Configure services that will be provided when the service is switched.	Section 3.17.1.	<ul style="list-style-type: none"> – User ports can be preconfigured (also on the LE). The advantage of a preconfigured user port is that less work is needed at the time of the actual upgrade. A disadvantage may be that the L3 will change and it thus has to be reassociated with the directory number (in the LE), or the directory number will change. – Broadband and other equipment may also need to be configured.
4. When the customer makes a request, switch the service and inform the customer.	Section 3.17.2.	The customer may have to install ISDN or broadband equipment.
5. When the node is visited, recable the node.	<i>Installation</i> document.	
6. Update the cabling information.	Section 3.17.1.	

Table 6 Procedure for commissioning a service switch

2.6 Commissioning leased lines

Before commissioning a leased line, make sure that the installation and cabling have been done as shown in the *Installation* document. Also, make sure that the basic commissioning has been done as explained in section 2.2.

2.6.1 Requirements

To commission a leased line, you will need the following:

- mandatory plug-in units
 - a minimum of one NCU in slot one (Eksos N20 subrack/cartridge) or slot three (Eksos/SAN subrack or cartridge)
- optional plug-in units
 - depending on the leased line utilised, either PSTN, ISDN, Data or TR2M4 units
 - in case of remote application, you may use Nokia HDSL line cards to provide the high speed connection over subscriber cable pairs. ACL4 can be installed in the Eksos subrack, whereas ACL2 needs its own mechanics. At the remote end, you have the choice of Nokia stand-alone terminals and plug-in ACL4/ACL2 line terminals, for example, in the case of a remote access multiplexer.
- configuration information about the leased lines
 - configuration information about the interfaces and time slots that will be used for leased lines
- configuration information about other equipment
 - configuration information of the data terminals.

Special care must be taken to ensure that the configuration of leased line data interface parameters, bit allocations to time slots and possible bit masks are the same at both ends of the leased line connection.

Restrictions

A full ISDN leased line reserves three time slots: two for B-channels, each 1 x 64 kbit/s, and one for D-channel, 1 x 16 kbit/s. Although the D-channel has a bit rate of 16 kbit/s, it is cross-connected at the 64 kbit/s level.

In case of $n \times 64k / n > 1$ connections, all time slots used for a single leased line must be consecutive ones. For example, a single leased line can use time slots 11, 12 and 13, but not 11, 12 and 14.

2.6.2 Procedure

- ▶ To commission leased lines, follow the procedure in Table 7:

Task	How? Refer to:	Remarks and tips
1. Do the basic commissioning.	Section 2.2.2	
2. Configure the interfaces involved. If already configured, check the configuration of these interfaces.	Section 3.19.	<ul style="list-style-type: none"> – Remember to bring the 2M interfaces into use and to enable power on the ISDN units or interfaces. – Time slot 0 cannot be cross-connected. – All time slots used for a single leased line must be consecutive ones.
3. Add the leased line to the active bank.	Section 3.19.	Alternatively, add the leased line to the inactive bank and then switch banks.

Table 7 Procedure for commissioning leased lines

2.7 Commissioning an application for scheduled line testing

Before commissioning the node, make sure that the installation and cabling have been done as shown in the *Installation* document. Also, make sure that the basic commissioning has been done as explained in section 2.2.

The lines to be tested must be in V5 use. The configuration at both ends of a V5 interface must always match. The configuration of the V5.2 interfaces must match the configuration information at the local exchange (LE) and the configuration of the V5.1 interfaces must match the configuration information in the V5.1 node.

2.7.1 Requirements

To commission an application for scheduled line testing, you will need the following:

- plug-in units
 - a minimum of one NCU unit in slot one (Eksos N20 subrack or cartridge) or slot three (Eksos N20/SAN subrack or cartridge)
 - an LMU
 - PSTN and/or ISDN units
- a plan for the tests
 - what tests will be run?
 - how often and when will the tests be run?
 - what interfaces will be tested?
 - what thresholds will be used?

2.7.2 Procedure

- To commission an application for scheduled line testing, follow the procedure in Table 8:

Task	How? Refer to:	Remarks and tips
1. Do the basic commissioning.	Section 2.2.2	
2. Create the V5 interface, if not already created.	Section 3.11	
3. Choose the schedule for the tests.	Section 3.21.2	In the scheduled tests, the subscriber line is blocked for the duration of the test. If the subscriber line is not in V5 use, the system will issue an Access Fail error message.
4. Choose the tests to be run.	Section 3.21.2	Available tests: electrical test, loop resistance, POTS diagnostics, dial tone test.
5. Choose the interfaces to be tested.	Section 3.21.2	You can choose several interfaces at a time.
6. Set thresholds for the tests.	Section 3.21.2	

Table 8 Procedure for commissioning an application for scheduled line testing

Chapter 3

Detailed instructions

Before starting the commissioning, make sure that you have a node configuration plan available. For information needed for making a plan, see Chapter 2 and the *Product Description* document.

The instructions in this chapter follow the recommended order of commissioning in cases where all functionalities of Eksos N20 are wanted.

3.1 Switching the power on

The power is switched on with the switch on the rack power supply used.




Figure 1 Power switches in DC-PSA

3.2 Connecting Node Manager cable to the node

One end of the management cable is connected to the Ethernet interface of the PC where Node Manager is running, and the other end to the Q3 interface on the NCU or on a service connector panel located on the rack.




Figure 2 Q3 interface on NCU and on service connector panel

There may be several Eksos N20 Node Managers at a time connected to the management network. One node can handle up to four management connections, for example, connections to Nokia NMS and Eksos N20 Node Manager.

3.3 Starting Node Manager

Make sure that you start the correct Node Manager version.

► To start Node Manager:

1. Switch on your computer.

Node Manager must be installed on your computer. Instructions for installing Node Manager can be found in *Appendix A*.

The computer must be physically connected to a new Eksos N20 node via an Ethernet cable connected from the Ethernet port on the computer to the NCU in the subrack (see section 3.2).

2. If Windows NT 4.0 is not operating already, start it now.
3. Double-click the *Eksos N20 Node Manager Program-item icon* on the desktop.

Node Manager will start up and display the **Eksos Node Manager** window (Figure 3):




Figure 3 Eksos Node Manager window showing the Manage Node window

3.4 Connecting to a node

3.4.1 Connecting to a fresh node

When you set up a connection to a fresh node with Node Manager, make sure that the node is not connected to any other fresh nodes. Otherwise this other node will also get the identification data, which must be unique to each node. If necessary, disconnect the node you are commissioning from the local Ethernet LAN network.

When you are connecting to a fresh node with Node Manager, the node installation wizard will start and guide you through the first phases of the installation.

► To connect to a fresh node, follow this procedure:

1. When starting Node Manager, the **Manage Node** dialog box opens automatically. You can also access it from the **Eksos Node Manager** window by selecting **Node** → **Manage....**




Figure 4 Manage Node dialog box

2. In the **Area** group box, select **Local LAN** from the drop-down list box.
3. In the **Node List** group box, select the fresh node: **DEADDEADF5B0**. This is the node that you are connected to.
4. Click **Manage**.

Note

There should only be one **DEADDEADF5B0** node in the network at a time.

If the connection is successful, and you are connecting to a previously uninstalled node, the first dialog box of the Installation Wizard will be displayed.




Figure 5 The first dialog box of Installation Wizard

If the node has already been installed, the **Eksos Node Manager** window will be displayed containing the **Subrack** window of the selected node.

The different steps of the installation and the related Installation wizard windows are briefly described in the following. Some of the windows are discussed also in section 3.5, “Changing node settings”.

- ▶ To set Node Information, fill in the following boxes:

Type: In this system release, the default type is ‘Eksos Mux’.

Name: Enter the descriptive name of the node according to the node configuration plan, with possibly the transmission connection information.

Location: Enter the descriptive name of the equipment station or equivalent according to the node configuration plan, with possibly the rack row and subrack location in the rack.

Release: Always ‘EKN C2.0’ in this system release.

- ▶ To give Node Address (NSAP), fill in the following boxes:

Area Name: Select the correct area for the node according to the node configuration plan. If your Node Manager installation does not yet have the correct area in its database, you might want to add it now by clicking on **Database...**

Make sure that the **AFI**, **IDI** and **Area address** are according to the node configuration plan. These define the area the node is in.

Node System ID: Type in the node ID (12 hexadecimal characters) according to the node configuration plan. This ID identifies the node within a particular area.

- ▶ To install units:

1. Each type of node configuration has a default card set associated with it. To install it, select the node type in the **Default Units Set** drop-down list box.
2. If you have already inserted all the units in the node, select **None** in the **Default Units Set** and click **Configure From Node**. This will automatically read which units are present in the node and set up this dialog box accordingly.

Note

This procedure can take up to one minute.

You can also set the unit configuration manually, see section 3.6. Afterwards, you can add, change and remove units from the configuration.

3. Set the correct time on the node. You can enter the time manually or set it to match the PC time. Click **Finish**>.

The **Real Time Clock** window is not dynamically updated. To update its contents, click in the **Real Time Clock** window to make it active and select **Data** → **Refresh from Node**.

4. Read through the **Information** window that is automatically displayed to ensure that the configuration is as you want it. If the configuration is correct, click **Send**. The details of the new node will be sent to the node and it will be installed.

Note

This procedure can take a few minutes.

If the configuration is not correct, click <**Back** to return to the previous dialog box in the Installation Wizard.




Figure 6 Information window

3.4.2 Reconnecting using the new address

- ▶ To update the node information from **DEADDEADF5B0** to the new node information defined in section 3.4.1:
 1. Disconnect from the node you are managing by selecting **Node** → **Stop Managing**.
 2. Select **Node** → **Manage**. The **Manage Node** dialog box opens.
 3. In the **Area** group box, select the node from the drop down box.
 4. To update the node (NSAP) address, wait a few minutes and click the **Refresh** button a couple of times until the **DEADDEADF5B0** address disappears. The new address is displayed in the **Node List**.
 5. Select the new address and click **Manage** in the toolbar to start managing the node again.

3.5 Changing node settings

- ▶ To view or change settings on a node, select **Configure**→**Node Settings**.

After the system has taken a few moments to get the current settings from the node, the **Node Settings** dialog box will be displayed. The first window to be displayed is **Node**. You can move to any of the other windows by clicking on its tab.

When you edit data obtained from the node, the changes which you can see on your screen are not immediately applied to the node. To put the changes into effect, you must send the edited data to the node by selecting **Data**→**Send to Node**. This command updates the node with the changed data that is currently in the active window.

3.6 Installing plug-in units

If you have already installed the plug-in units by using the Installation wizard, you can move directly to section 3.7.

All plug-in units have to be installed with Node Manager before they can be used in a node. We recommend that you place the units in the subrack before you start to install them, although it is not obligatory to do so.

You can install one or several units at a time. When all modifications have been done, Node Manager will check the new configuration before sending it to the node. Node Manager reports an error if an obviously incorrect configuration is set up.

The node configuration can be changed as often and as many times as necessary.

Before Node Manager can accept the configuration, it must include the units that are vital for correct operation. A Node Control Unit (NCU) must always be in place, whereas the other necessary units depend on the application. For information about the units required in the most common applications, see Chapter 2.

- ▶ To install a unit in a node, follow the procedure below:

1. In the **Subrack** window, click the slot where you want to install the unit.
2. Select **Configure** → **Unit Type...**

The **Unit Type** dialog box will be displayed for the currently selected slot in the **Subrack** window.

3. In the **Type** drop-down list box, select the new unit type you want to install in the selected slot. Then click on **OK**.
 - The unit types listed are the only units that can be installed in the selected slot.
 - If you want to uninstall a unit, that is, remove the unit from the node, select **No Unit** from the list box.

The **Subrack** window will be updated with the new unit for the currently selected slot. The way that the unit is displayed in the **Subrack** window will indicate whether it has been correctly installed (see Figure 7).




Figure 7 Correct and incorrect installations in a subrack

4. After you have installed all the units, select **Data** → **Send to Node** to send the contents of the window to the node.

To view information on a unit, click first on the unit and then select **Node**→**Unit Information**.

3.7 Configuring 2M interfaces

► To bring the 2M interface(s) into use:

1. Select an NCU or TR2M4 by clicking on it in the **Subrack** window. Then select **Configure** → **Interface**. The **Ux 2M** window (the 2M window for unit in slot x) will open.
2. Right-click the selected interface and select **Configure** from the pop-up menu.
3. In **E12** tab, bring the interface into use. You can select several interfaces by clicking the **Also Apply To...** button and selecting the interfaces in the window that opens.
 - For configuring Performance Collection, see section 3.20.3.
4. In **E12/P12** tab, select whether the CRC check is on or off. You can set CRC on for several interfaces by clicking the **Also Apply To...** button and selecting the interfaces in the window that opens.
5. Click **OK**. Then select **Data** → **Send to Node** to send the contents of the window to the node.

3.8 Configuring synchronisation

Synchronisation source priority list

Take the synchronisation sources into use and arrange them into priority order as planned. The following source candidates are available:

- any 2 Mbit/s interface from NCU or TR2M4
- external synchronisation input from master NCU
- internal clock (always the last item on the list).

Node synchronisation proceeds according to the priority list of the allowed synchronisation sources. The source with the highest priority is used to synchronise the node clock.

In case the source being used becomes unavailable, the equipment switches automatically to the second highest synchronisation source.

- ▶ To change the priority of the synchronisation sources, follow the procedure below:
 1. Select **Configure** → **Synchronisation**. The **Synchronisation** window will be displayed.




Figure 8 Synchronisation window

2. Click the **NE Clock** tab if it is not already selected.

3. In the **Mode** group box, select **Priority List**. This sets the source automatically, using the sources in the **Priority List** list box. The other mode options are:
 - **Manual** (forces the synchronisation to a set reference source from the **Sources List**)
 - **Hold-over** (forces the synchronisation source to use the internal oscillator that holds over the previously used source).
4. Select a source from the **Sources** list box by clicking on it. Click **Add** to move the selected source into the **Priority List** list box. Repeat this step until all the sources you require have been added to the **Priority List** list box.
5. Select an entry in the **Priority List** list box whose level of priority you want to either raise or lower.
6. Set the priority of the new signal source by either:
 - clicking on **Raise** to increase the priority for that signal
 - clicking on **Lower** to decrease the priority.
7. Continue moving the signal sources until they are ordered in the desired priority. You can also remove a signal source from the **Priority List** list box by selecting it and then clicking on **Remove**.
8. Select **Data** → **Send to Node** to send the contents of the window to the node.
9. To update the **Synchronisation** window, select **Data** → **Refresh from Node**.

Note

You cannot raise the priority of the **Internal** synchronisation source (Internal clock). This is always the last source in the **Priority List**. This source will be used if none of the other synchronisation sources in the priority list are available.

- To calibrate the internal node clock:
1. Select **Configure** → **Synchronisation**. The **Synchronisation** window will be displayed.
 2. Click the **NE Clock** tab if it is not already selected. The current internal source being used for synchronisation is shown in the **Status** group box.
 3. In the **Internal Clock** group box, check the **Calibrate Internal Clock** option.
 4. Select **Data** → **Send to Node**.

The internal node clock should be calibrated at least once a year.

- ▶ To select the source to be used for external synchronisation output:
 1. Select **Configure** → **Synchronisation**. The **Synchronisation** window will be displayed.
 2. Click the **Sync Output** tab if it is not already selected.




Figure 9 Sync Output tab of the Synchronisation window

3. Select the source of the ExtS1 Reference Signal.

The options are:

 - **Node clock** (the current node clock is used as the reference for the output)
 - **Other** (a manually selected source is used for the output).
4. Select **Data** → **Send to Node** to send the contents of the window to the node.

Note

The synchronisation output is out of use:

- in hold-over mode
 - when the internal clock is used.
-

3.9 Configuring management channels (DCN time slots)

This section describes the settings for Node Manager and network management communication between the nodes. These settings define whether the management data channel is connected via the data communications channel of the selected 2M signal to the remote node. When the channel is enabled at both ends of the 2M link, management traffic can access the remote node.

- ▶ To connect to the Q3 stack:
 1. Select **Configure** → **Man. and Aux. Channels** to open the **Management and Auxiliary Channels** window. The window shows the current management channel status for all the Q3 stacks in the node. The **Q3 Management** tab is displayed by default.




Figure 10 The Q3 Management tab

2. In the **Q3 Management** tab, select a Q3 stack of the wanted unit in the **Q3 Stack** column.

The NCU has two Q3 stacks and TR2M4 unit four Q3 stacks to choose from, each of these stacks providing 31 time slots (1 to 31).

3. Click the **Configure** button. The **Configure Ux NCU/TR2M4 stack** dialog box opens (the x stands for the unit slot number).
4. In the **Connection** tab, click on the + of the desired interface.
5. Click on the desired time slot + **Ux 2M i/f 1 TS-x** for the DCN channel to be created. The **To PDH** will be highlighted. Click **OK**.

Repeat steps 2. to 5. for each DCN channel you want to create.

6. Select **Data** → **Send to Node**.

- ▶ To add a node neighbour manually to the Q3 routing table:
 1. Select **Configure** → **Man. and Aux. Channels**. The **Management and Auxiliary Channels** window will be displayed.
 2. In the **Q3 Management** tab, select a Q3 stack of the desired unit in the **Q3 Stack** column. Then click on **Configure** to open the **Configure Ux NCU/TR2M4 Stack** dialog box (the x stands for the unit slot number).
 3. Select the **Manual Adjacencies** tab. Then click **Add**. The **Add Manual Adjacency** dialog box appears.




Figure 11 Add Manual Adjacency dialog box

4. Select a member from the **Sub-Network Point of Attachment (SNPA)** list.
5. Type in a **System ID** and click **OK**.
6. Select **Data** → **Send to Node**.

- ▶ To connect to the Q1 stack:
 1. Select **Configure** → **Man. and Aux. Channels** to open the **Man. and Aux. Channels** window where you can set up the DCN.
 2. Click on the **Summing Points** tab.
 3. In the **Summing Points** tab, select a summing point for the configuration from the drop-down list. Then click on the **Configure** button. The **Configure Summing Point** dialog box opens.




Figure 12 The **Configure Summing Point** dialog box

4. In the **Aux.**, **TS-N** and **ISDN-UQ** tabs, select the type of connection point.
5. Click on the + of the desired interface and item for the Q1 connection to be created.
6. Select the desired item:

- for the auxiliary interfaces (**AUX** tab): asynchronous, co-directional, contra-directional DCE or contra-directional DTE
- for the 2M time slots (**TS-N** tab): To PDH

Note that in every separate NCU or TR2M4 unit, only *two* time slots from all the 2M interfaces of the unit can be connected to a summing point.

- for the ISDN interface (**ISDN-UQ** tab): D-channel.

7. To determine the role of the connection, click the **Add Master** or **Add Slave** button.

Repeat steps 4. to 7. for each Q1 summing point you want to create.

8. Click **OK**. Then select **Data** → **Send to Node** to send the contents of the window to the node.

3.10 Configuring external alarms and station alarms

You can use Node Manager to enable or disable the use of external alarms and station alarms on the node. The default setting is **Disabled**.

► To enable or disable the use of station alarms:

1. Select **Monitor** → **External Alarms**. The **External Alarms and Station Alarms** window will appear.




Figure 13 External Alarms And Station Alarms window

2. In any of the three tabbed windows, click the **Station Alarms** check box to enable or disable station alarms.

Note

To avoid problems in interpreting the alarm history log, we recommend that you do not change severities for alarms that are ON.

3.10.1 Configuring Digital Inputs

► To configure digital inputs:

1. In the **External Alarms and Station Alarms** window, **Digital Inputs** tab, select an input from the drop-down list box in the **Alarm** group box. There are three **PAIs** for each NCU and LMU. **PAI1**, **PAI2** and **PAI3** are for the first (leftmost) NCU in the subrack and the next three inputs for the LMU (or the next NCU).

The **Status** box shows whether the alarm is On or Off. If you have a colour monitor, the background colour of the **Status** box will be red when the alarm is on and green when the alarm is off. If you have a monochrome monitor, the background colour of the **Status** box will be dark grey when the alarm is on and white when the alarm is off.

2. From the **Indication** drop-down list box, select whether this input is shown as an **Alarm** or as a **Status** report.
3. From the **Severity** drop-down list box, select a severity for the alarm. There are four levels of severity:
 - Critical
 - Major
 - Minor
 - Warning.
4. From the **Probable Cause** drop-down list box, select an alarm text for the alarm.
5. In the **Time constant** drop-down list box, select **No filtering** or a time period.
 - The time constant is the minimum filtering time before an alarm state change can occur on the node.
6. From the **Polarity** drop-down list box, select **Normal logic** or **Reverse logic**.
 - **Normal logic**: an alarm is triggered by the signal going high
 - **Reverse logic**: an alarm is triggered by the signal going low.
7. In the **Additional text** box, enter a description of the alarm.
8. Select **Data** → **Send To Node** to send the new setup to the node.

3.10.2 Configuring Digital Inputs/Outputs

This window is used to configure interfaces which can be set to act as either inputs or outputs. In the **External Alarms and Station Alarms** window, **Digital Inputs/Outputs** tab, select the appropriate option button:

- **Use as alarm output**
- **Use as alarm input.**

► To configure a digital interface as an alarm output:

1. In the **Alarm** group box, select an interface from the drop-down list box. There are two **PAIOs** for each NCU and LMU. **PAIO1** and **PAIO2** are for the first (leftmost) NCU in the subrack and the next two inputs for the LMU (or the next NCU).
2. From the **Polarity** drop-down list box, select **Normal logic** or **Reverse logic**.
 - **Normal logic:** an alarm is triggered by the signal going high
 - **Reverse logic:** an alarm is triggered by the signal going low.
3. In the **Additional text** box, enter a description of the alarm.
4. From the **Forced alarm status** drop-down list box, select one of the three options:
 - **Active**
 - **Auto**
 - **Cleared.**
5. From the **Connect to input** drop-down list box, select the alarm input to which the alarm output is to be mapped. The content of the list depends on the number of NCUs and LMUs present in the subrack.
6. Select **Data** → **Send To Node** to send the new setup to the node.

► To configure a digital interface as an alarm input, please refer to section 3.10.1.

3.10.3 Configuring Analog Inputs

► To configure analog inputs:

1. In the **External Alarms and Station Alarms** window, **Analog Inputs** tab, select an input from the drop-down list box in the **Alarm** group box. There are two **IAVs** for each NCU and LMU. **IAV1** and **IAV2** are for the first (leftmost) NCU in the subrack and the next two inputs for the LMU (or the next NCU).

- **IAV1** is an input with a voltage range from 0 to +5 V.
- **IAV2** is an input with a voltage range from 0 to -70 V.

The **Status** box shows whether the alarm is On or Off. If you have a colour monitor, the background colour of the **Status** box will be red when the alarm is on and green when the alarm is off. If you have a monochrome monitor, the background colour of the **Status** box will be dark grey when the alarm is on and white when the alarm is off.

2. From the **Indication:** drop-down list box, select whether this input is shown as an **Alarm** or as a **Status** report.
3. From the **Severity:** drop-down list box, select a severity for the alarm. There are four levels of severity:
 - Critical
 - Major
 - Minor
 - Warning.
4. From the **Probable Cause** drop-down list box, select a text for the alarm.
5. In the **Time Constant** drop-down list box, select either **No filtering** or a time period.
 - The time constant is the minimum filtering time before an alarm state change can occur on the node.
6. From the **Polarity:** drop-down list box, select either **Normal logic** or **Reverse logic**.
 - **Normal logic:** an alarm is triggered when the voltage is outside the range
 - **Reverse logic:** an alarm is triggered when the voltage is within the set range.
7. In the **Additional text** box, enter a description of the alarm.
8. From the **Edit threshold** box, select a value for the high and low threshold to trigger or cancel the alarm. The range for the high threshold is 100 to -99 and for the low threshold -100 to 99. (The values are percentages of the maximum voltage level for the selected input, see the examples below.)
 - The **Voltage** box is read-only. It displays the last read voltage from the selected line.
9. Select **Data** → **Send To Node** to send the new setup to the node.

Examples of setting alarm thresholds

Input 1 (IAV1), with the voltage range from 0 to +5 V

- ▶ To set the allowed voltage range from 2 V to 4 V (so that an alarm will be raised if the voltage is outside of this range):
 1. Set the low threshold value to 40(%), which gives voltage level
 $0.4 \times 5 \text{ V} = 2 \text{ V}$
 2. Set the high threshold value to 80(%), which gives voltage level
 $0.8 \times 5 \text{ V} = 4 \text{ V}$

Note

Giving a negative value (–1 to –100) has the same effect as setting the threshold value to 0 (zero).

Input 2 (IAV2), with the voltage range from 0 to –70 V

- ▶ To set the allowed voltage range from –35 V to –56 V (so that an alarm will be raised if the voltage is outside of this range):
 1. Set the low threshold value to –80(%), which gives voltage level
 $-0.8 \times 70 \text{ V} = -56 \text{ V}$
 2. Set the high threshold value to –50(%), which gives voltage level
 $-0.5 \times 70 \text{ V} = -35 \text{ V}$

Note

Giving a positive value (1 to 100) has the same effect as setting the threshold value to 0 (zero).

3.11 Creating and configuring a V5 interface

Note

An Eksos N20 node can have up to four V5.2 interfaces. The maximum number of V5.1 interfaces depends on how many TR2M4 units have been installed in the Eksos N20 node.

Note

The V5.2 interface running in the node master unit can support the maximum of 256 ISDN or 512 PSTN connections. If you need a bigger node, you must install a second NCU unit to operate the V5.2 interface.

Note

We recommend that you configure the V5.2 interfaces at the Local Exchange end and the V5.1 interface at the V5.1 multiplexer before configuring them in Eksos N20. This way you get the needed IDs at the LE and at the V5.1 multiplexer and also minimise the number of management sessions to the LE and V5.1 multiplexer.

3.11.1 V5.2 interface

The V5.2 Interface wizard leads you through all the necessary windows, which cover the following main tasks:

- configuring interface settings
- configuring 2M links
- configuring communication channels (C-channels)
- configuring signalling.

► To configure interface settings:

1. Select **Configure** → **V5 Interfaces**. The V5.2 Interface Wizard starts with **Configure V5 Interfaces** dialog box as its first window.




Figure 14 Configure V5 Interfaces dialog box

2. Click the **New V5.2...** button. Then, click **Next>**.
 - The **New V5.2...** button is enabled if the number of existing V5.2 interfaces is less than four.
3. Enter **Interface name**, **Interface ID** and **Provisioning variant**.
 - Interface ID is the interface’s unique number within the LE and therefore the Interface ID must be the same as the ID at the LE. If the ID is not the same at both ends, the exchange cannot recognise the Eksos N20 node.
 - The provisioning variant must be the same as the one at the LE.
4. Select the V5 Master Unit. The **V5 Master Unit** box contains a list of the unit numbers for all NCUs that can be selected as the V5 master unit. If not selected otherwise, Node Manager puts the V5 Master Unit on the first NCU available that is not the Node Master. If the Node Master is the only NCU available, this unit will be proposed by Node Manager.

Note

Selecting the node master unit of the Eksos N20 node to be the V5 master will reduce the overall performance of the Eksos N20 node. The node master unit is the NCU in slot 1 in the Eksos N20 subrack or in slot 3 in the Eksos N20 / SAN subrack.

5. In the **Interface** window, click **Advanced...** The **Advanced V5.2 Interface Settings** dialog box will be displayed.

If you are willing to accept the default settings shown, click **Cancel** to return to the **Interface** window, and then click **Next>** to proceed immediately to configuring 2M links. If you want to change some of the settings, continue from step 6.




Figure 15 Advanced V5.2 Interface Settings dialog box

6. Select one of the three option buttons in the **Link ID Checking** group box.
 - The setting should be the same at the LE.
 - The **Enable Link ID Checking** is the default and recommended selection as long as CRC4 error checking is selected for the link.
7. In the **Startup** group box, select the options wanted.
 - The possible values for **Startup delay** are 1 to 60 minutes. The default value is 2 minutes.
 - The settings for **Startup allowed during PSTN failure** and **Accelerated Unblocking** should match the settings on the corresponding V5.2 interfaces within the LE.
8. In the **Alarm Reporting** group box, select which error types you wish to have reported.
9. In the **2M Fault Timers** group box, select the values for **Fault On** and **Fault Off**. The values can be set in the range 1 to 250.
10. Click **OK**.

- ▶ To configure 2M links:
 1. In the **Interface** window, click **Next>** to proceed. The **2M Links** dialog box is displayed.




Figure 16 2M Links dialog box

2. Select a 2M link by clicking on it, then click the **Add Link...** button. The **Add Link** dialog box opens.

A V5.2 interface can contain up to 16 links. When the maximum number of links has been reached, the **Add Link...** button becomes disabled.




Figure 17 Add Link dialog box

3. In the **Add Link** dialog box, enter a suitable **Link ID**. The Link ID given here must be the same as the one given at the LE. In the **Timeslot usage** group box, select the time slots which you want to use for V5.2 and then click **OK**.

The V5.2 interface may use some or all of the 2M links available on the node. Each link in the interface has a unique link ID within the interface. This ID must be supplied at both ends of the link (that is, the Eksos N20 node and the LE).

4. Click **OK**.

Note

Repeat steps 2. to 4. for each 2M link.

- ▶ To configure communication channels (C-channels):

! Caution

The C-channel configuration in the Eksos N20 end must be identical with the configuration defined in the LE.

1. In the **2M Links** window, click **Next>** to open the **C-channels** dialog box.




Figure 18 C-channels dialog box

2. In the **C-channels** dialog box, click the **TS 16** cell to select it. Then click **Add...** to open the **Add C-channel** dialog box.

For each of the 2M links created, configure a C-channel by selecting a cell representing the required time slot.

Note

Vital signalling and vital standby must always be configured in time slot 16.




Figure 19 Add C-channel dialog box

3. In the **Add C-channel** dialog box, type a C-channel ID and click **OK**.

Notice that C-channel IDs must be mapped to time slots before PSTN or ISDN C-paths can be configured for them.

4. If more than one link is used, a protecting signalling protocol (Vital Standby) must be assigned. Select time slot 16 of the secondary link and assign the protecting signalling protocol to it by clicking on **Vital Standby**. Then click **Next>**.

- The protecting C-channels do not require C-channel IDs.

5. Set standby C-channels for the PSTN or ISDN signalling by selecting a time slot and clicking on **Standby**. The maximum number of standby channels per V5.2 is three.

► To configure signalling (mapping):

1. In the **C-channels** dialog box, click one of the time slot cells to select it. Then click **Add...** to open the **Add Signalling** dialog box.




Figure 20 Add Signalling dialog box

2. Check the **Vital** check box.

The link for which you configure the vital signalling will be the *primary* link.

3. Check the **PSTN** check box. The C-path for PSTN signalling can be configured to the same time slot as the vital signalling. Click **OK**.
4. Select a time slot from the list by clicking on it, then click **Add...** to open the **Add Signalling** dialog box.

- The C-path for ISDN signalling is recommended to be configured to a separate time slot from the PSTN and Vital signalling. Select, for example, time slot 15 of the primary link and assign the ISDN signalling to it.
5. Check the **ISDN-Ds** and **ISDN-p** check boxes, if these are relevant for you, and click **OK**.
 6. Select the **PSTN mapping** drop down box to set the country mapping.
 7. When all configuration is complete, click **Finish**. A summary page will be displayed to allow entered details to be verified. If any details shown are incorrect, click **<Back** to return to previous pages.




Figure 21 Summary page

8. Once all details are verified correct, click **Create** to create the V5.2 interface.

3.11.2 V5.1 interface

The V5.1 Interface wizard leads you through all the necessary windows which cover the following main tasks:

- setting interface settings
- configuring a 2M link
- configuring communication channels (C-channels).

Note

It is necessary that a V5.2 interface be configured before configuring the V5.1 interface.

► To configure interface settings:

1. Start by selecting **Configure** → **V5 Interfaces**. The V5.1 Interface Wizard opens with **Configure V5 Interfaces** dialog box as its first window.




Figure 22 Configure V5 Interfaces dialog box

2. Click the **New V5.1...** button to create a new V5.1 interface. Then, click **Next>**.
 - The **New V5.1...** button is enabled when the Eksos N20 node has less than the maximum number of V5.1 interfaces that can be supported by the TR2M4 units.
3. Enter **Interface name**, **Interface ID** and **Provisioning variant**.
 - Interface ID is the interface's unique number within the V5.1 node and therefore the Interface ID must be the same as the ID at the V5.1 node.
4. In the **Interface** window, click **Advanced...** The **Advanced V5.1 Interface Settings** dialog box will open.

If you are willing to accept the default settings shown, click **Cancel** to return to the **Interface** window. Then click **Next>** to proceed immediately to configuring the 2M link. If you want to change some of the settings, continue from step 5.

The screenshot shows the 'Advanced V5.1 Interface Settings' dialog box. It contains the following sections and controls:

- Link ID Checking:** Three radio button options: 'Do not check link IDs', 'Do not check link IDs on interface recovery', and 'Check link IDs always'.
- Startup:** A dropdown menu for 'Startup behaviour' set to 'V1 Case 2', a spinner for 'Startup delay' set to '2' Minutes, a dropdown for 'Startup allowed during PSTN failure' set to 'No', and a dropdown for 'Accelerated unblocking' set to 'Off'.
- Alarm Reporting:** Five checkboxes: 'Port Control Protocol Timeout Errors', 'PSTN Protocol Timeout Errors', 'Port Control Protocol Errors', 'PSTN Protocol L3 Address Errors', and 'Port Control Protocol L3 Address Errors'.
- 2M Fault Timers:** Two spinners: 'Fault On' set to '200' x 100 ms and 'Fault Off' set to '200' x 100 ms.

Buttons for 'OK' and 'Cancel' are located at the bottom of the dialog.

Figure 23 Advanced V5.1 Interface Settings dialog box

5. In the **Startup** group box, select the options wanted and click **OK**.
6. In the **Startup** group box, select the options wanted.
 - The possible values for **Startup delay** are 1 to 60 minutes. The default value is 2 minutes.
7. In the **Alarm Reporting** group box, select which error tyoes you wish to have reported.
8. In the **2M Fault Timers** group box, select the values for **Fault On** and **Fault Off**. The values can be set in the range 1 to 250.
9. Click **OK**.

- ▶ To configure the 2M link:
 1. In the **Interface** window, click **Next>**. The **2M Links** dialog box will open.
 2. From the **Associated and Available Links** list, select a 2M link, then click **Add Link...** The **Add Link** dialog box opens.
 3. In the **Add Link** dialog box, select the time slots which you want to use for V5.1 and then click **OK**.

Note

When you have selected and added a link, it is not possible to add any further links because there is only one link in a V5.1 interface.

- ▶ To configure communication channels (C-channels):
 1. In the **2M Links** dialog box, click **Next>** to open the **C-channels** dialog box.
 2. In the **C-channels** dialog box, click one of the time slot cells to select it.
 3. Click the **Next>** button to open the **Signalling** dialog box.
 4. In the **Signalling** dialog box, click the cell where you placed the C-channel. The click **Add** to open the **Add Signalling** dialog box.
 5. Check the **Vital**, **PSTN**, **ISDN-Ds** and **ISDN-p** boxes if they are relevant for you to set the signalling. Then click **OK**. Your selections now show in the **Signalling** dialog box.

Note

As there is only one 2M link in a V5.1 interface, time slot 16 is always used for vital signalling. Vital signalling cannot be moved from time slot 16.

6. When the configuration is complete, click **Finish**. A summary page will be displayed to allow the entered details to be verified. If any details shown are incorrect, click **<Back** to return to previous pages.




Figure 24 Summary page

7. Once all details are verified correct, click **Create** to create the V5.1 interface.

3.12 Configuring PSTN interfaces

This section lists the interface-specific attributes that need to be set before the PSTN interfaces can be brought into use.

! Caution

The DC feed settings affect PSTN units' power consumption and heat dissipation. For more information about the settings, see the *Country Specific Instructions*.

► To specify the **DC Set/General/Speech** settings:

1. Select the PSTN unit which you want to configure by clicking on it in the **Subrack** window.
2. Select **Configure** → **Interface** to open the **Ux PSTN** dialog box (x stands for the slot number where the unit is installed).
3. Select an interface by clicking on it, then right-click **Configure**. The **Configure PSTN Ux** dialog box opens.




Figure 25 The DC Set tab of the **Configure PSTN Ux** dialog box

4. In the **DC Set** tab/**General** tab/**Speech** tab, select the interface you want to configure.

- The **Also Apply To...** button allows you to specify that any editing changes which you have made in one interface will also be made to one or more of the other interfaces in the tab which is open. These editing changes only become visible after the data has been sent to the node.
5. If you want, enter a name for the interface. The name can be up to 20 characters long.
 6. Select the wanted options from the drop-down list boxes.

For information about the values needed, see the *Specific Instructions for XX* in this manual.
 7. When the settings in the tab are as you want them, click **OK**. Then select **Data** → **Send to Node** to send the contents of the window to the node.

3.13 Configuring ISDN interfaces

This section lists the attributes that need to be set before the ISDN interfaces can be brought into use.

- ▶ To configure the **Power Feeding**:
 1. Select the ISDN unit which you want to configure by clicking on it in the **Subrack** window.
 2. Select **Configure** → **Interface** to open the **Ux ISDNUQ** dialog box (x stands for the slot number where the unit is installed).
 3. Select an interface by clicking on it, then right-click **Configure**. The **Configure ISDNUQ Ux** dialog box opens.
 4. Select the **Power Feeding** tab.





Figure 26 The **Power Feeding** tab of the **Configure ISDNUQ Ux** dialog box

5. In the **Unit Power Feeding** group box, select the **Feeding voltage** required. This voltage is applied to all ports of the selected ISDN unit. The default is 0 V. For more detailed instructions, see the *Country Specific Instructions*.

6. In the **Interface Power Feeding** group box, set the interface levels. Select one of the ports, which are listed by number, and then click **Edit...** Set the maximum power in the **Maximum Power** text box at the planned level in range 0 to 6 000 mW. The maximum power can be adjusted at 100 mW intervals. Setting the maximum power to 0 mW means that the port is switched off, regardless of the **Unit Power Feeding** settings, as no current is driven to the ports. Be careful not to exceed the maximum permitted unit power level.

 **Caution**

If the configuration is incorrect (that is, if the sum of maximum power defined for all interfaces is bigger than the maximum permitted unit power), the unit may reset or stop working.

If the configuration is correct and the power consumption of the whole unit is bigger than the maximum permitted unit power, the interface with the biggest delta is switched off (delta = power consumption of the interface – maximum interface power). If the power consumption is still too high, further interfaces are switched off. This only happens if the interfaces are driven in the unit mode.

Line feeding voltage	Maximum permitted unit power level
65 V	23.8 W
70 V	25.5 W
97 V	35.0 W
110 V	37.3 W

Table 9 Maximum unit power levels allowed for different feeding voltages

7. From the **Power Limited by** drop-down list box, select either **Unit** (power to the interface is cut off when the unit limit is exceeded) or **Interface** (power to the interface is cut off when the interface limit is exceeded). When the settings are as you want them, click **OK**.

- **Unit** is the default setting and means that the power is cut off when the unit-level limit has been exceeded.

Actual Power is not editable. This value shows the actual power as measured at the interface. It is not updated automatically, so if you want to see what the current level is, close the window and select **Data** → **Refresh from Node**.

8. Click **OK**. Then select **Data** → **Send to Node** to send the contents of the window to the node.

Thresholds allow you to specify two parameters relating to DEG (DEGraded signal) alarms, for a particular interface or for a specified set of interfaces.

- To configure the **Threshold** parameters, follow the procedure below:
1. Select the ISDN unit which you want to configure by clicking on it in the **Subrack** window.
 2. Select **Configure** → **Interface** to open the **Ux ISDN** dialog box (x stands for the slot number where the unit is installed).
 3. Select an interface from the list and right-click **Configure**. The **Configure ISDNUQ Ux** dialog box opens.
 4. In the **Thresholds** tab, select the interface you want to configure.
 - The **Also Apply To...** button allows you to specify that any editing changes which you have made in one interface will also be made to one or more of the other interfaces in the tab which is open.
 5. If you want alarms to be reported for this unit, check the **Monitored** check box.
 6. If you want, enter a name for the interface in the **Name** text box. The name can be up to 15 characters long.
 7. In the **Definition of Bad Seconds** group box, select a number from the **Minimum number of bad blocks in a bad second** box.

This attribute specifies the threshold value for bad blocks during one second. Note that the detection of bit errors differs between units using 2B1Q and 4B3T line code. 2B1Q units detect bit errors using CRC12 checks on multiframe basis, whereas 4B3T units detect line code violations. For this reason also the allowed range of values is different for 2B1Q and 4B3T units:

 - 2B1Q: 0 to 666 blocks
 - 4B3T: 0 to 1000 blocks.

The default value is 0, which means that no performance alarms (Far-End Block Error) are generated from this interface.
 8. To define when a DEG alarm is being issued, select a number from the **Number of consecutive bad seconds before DEG alarm** box.
 - The number selected specifies the number of consecutive bad seconds that are detected before the DEG (Degraded signal) alarm is generated. The minimum number you can select is 2, and the maximum is 10 (default is 5).
 9. Click **OK** and select **Data** → **Send to Node** to send the contents of the window to the node.

3.14 Provisioning user ports

Note

To provision user ports, the V5 interface has to be created first.

This section gives advice on how to configure interfaces and time slots using the **Interface Usage** window. This window displays how the tributary and aggregate interfaces of the Eksos N20 node are used. The window displays the following information:

- physical interfaces of the PSTN, ISDN and DIU units
- time slots of the TR2M4 unit
- interfaces of the NCU unit.

You can carry out the following tasks with the **Interface Usage** window:

- identifying tributary and aggregate interfaces and time slots in use
- tracking faults
- configuring, editing and deleting user ports for specified physical interfaces
- blocking user ports for testing purposes.

3.14.1 Identifying interfaces and time slots

- To identify interfaces and time slots, follow the procedure below:
1. Select the unit in the **Subrack** window by clicking on the unit..
 2. Select **Configure** → **Interface Usage** from the menu. The **Interface Usage** dialog box will open.

Location	Capacity	Usage	Alarm
U 5 i/f: 1	b1, b2,d	ISDN port	<input type="checkbox"/> Cleared
U 5 i/f: 2	b1, b2,d	ISDN port	<input type="checkbox"/> Cleared
U 5 i/f: 3	b1, b2,d	ISDN port	<input type="checkbox"/> Cleared
U 5 i/f: 4	b1, b2,d	ISDN port	<input type="checkbox"/> Cleared
U 5 i/f: 5	b1, b2,d	ISDN port	<input type="checkbox"/> Cleared
U 5 i/f: 6	b1, b2,d	ISDN port	<input type="checkbox"/> Cleared
U 5 i/f: 7	b1, b2,d	ISDN port	<input type="checkbox"/> Cleared
U 5 i/f: 8	b1, b2,d	ISDN port	<input type="checkbox"/> Cleared
U 5 i/f: 9	b1, b2,d	ISDN port	<input type="checkbox"/> Cleared
U 5 i/f:10	b1, b2,d	ISDN port	<input type="checkbox"/> Cleared
U 5 i/f:11	b1, b2,d		<input type="checkbox"/> Cleared
U 5 i/f:12	b1, b2,d		<input type="checkbox"/> Cleared
U 5 i/f:13	b1, b2,d		<input type="checkbox"/> Cleared
U 5 i/f:14	b1, b2,d		<input type="checkbox"/> Cleared
U 5 i/f:15	b1, b2,d		<input type="checkbox"/> Cleared
U 5 i/f:16	b1, b2,d		<input type="checkbox"/> Cleared
U 7 i/f: 1		PSTN port	<input type="checkbox"/> Cleared
U 7 i/f: 2		PSTN port	<input type="checkbox"/> Cleared

Figure 27 The **Interface Usage** dialog box

3. In the **Tributaries** tab and **NCUs** tab, you can identify how the tributary and aggregate interfaces and time slots are being used.
 - The **Location** column gives the unit number, interface number and for TR2M4 units the time slots.
 - For ISDN interface, the **Capacity** column shows how much capacity has been used for the application given in the **Usage** column. The possible values are b1, b2, d, blank and any combination of these.
 - The **Usage** column shows what the interface or time slot is being used for
 - The **Alarm** column shows the most severe alarms.

3.14.2 Configuring, editing and deleting user ports

Note

Before starting to configure, edit or delete user ports, refresh the window manually by selecting **Data** → **Refresh from Node**.

Each PSTN unit may have up to 32 user ports and each ISDN unit up to 16 user ports. The TR2M4 unit has four 2M interfaces. Each user port must be individually added to the V5.2 or V5.1 interface, and the appropriate user port address supplied. This is the address which identifies the subscriber at the local exchange.

- ▶ To select user ports, follow the procedure below:
 1. Select the unit in the **Subrack** window by clicking on the unit.
 2. Select **Configure** → **Interface Usage** from the menu. The **Interface Usage** dialog box will open.
 3. Select the **User Ports** tab.




Figure 28 The User Ports tab in the Interface Usage dialog box

4. In the **Units to include** list box, select which units you want the window to show: **All units**, **PSTN units**, **ISDN units**, **TR2M4 units**.
5. In the **Usage to include** drop-down list box, select **All**.

The other alternatives can be used to edit or delete user ports:

- **User ports** (all assigned interfaces/time slots which have been assigned as user ports)
 - **Unassigned** (all interface/time slots which have not been assigned, but can be assigned)
 - **Non-V5** (all interfaces/time slots which are not in V5 use).
6. In the **Data to show** group box, select whether you want to identify V5.1 or V5.2 interfaces. The other options in this group box are:
- **Location** displays the unit and interface number, and the time slot number for TR2M4 units.
 - **Usage** displays whether the interface is used for a leased line, management & auxiliary channel, V5.1 or V5.2.
 - **Operational data** displays the operational state, status, request and alarm information.
 - **Port settings** displays if the port is used for leased lines or grading.

The availability of these options is determined by the selections in the **Units to include** and **Usage to include** list boxes.

7. Select a port by clicking on it in the list.

To add the port to the V5.2 or V5.1 interface, click **Assign**. You can select more than one port by using the SHIFT or CTRL key in conjunction with the mouse or the up and down arrow keys, in the standard way for Windows.

To delete a port, click on **Unassign**.

Depending on the port selected, the **Assign L3 Address to PSTN Port**, **Assign EF Address to ISDN Port** or **Assign User Ports on TR2M4 Unit** dialog box will open.




Figure 29 The Assign L3 Address to PSTN Port dialog box

- To assign addresses to user ports, follow the procedure below:

Note

You can assign ISDN and PSTN user ports by double-clicking the line in the **Location** group box.

1. In the **Interface Usage** dialog box, select the **User Ports** tab.
2. PSTN or ISDN unit: enter the V5.2 interface ID and L3/EF address in the **User Ports** tab, **Address to assign** group box.

TR2M4 unit: enter the V5.2 interface ID and L3/EF address in the **V5.2 address to assign** and **V5.1 address to assign** group box.

- The L3 addresses of the PSTN ports and the EF addresses of the ISDN ports have to be identical to the port addresses assigned at the LE.
3. PSTN and TR2M4 units: you can set up a semi-permanent leased line by checking the **Semi-permanent leased port** box. By default, this feature is off.

ISDN and TR2M4 units: select the **C-Channel ID** in the **Signalling** group box. You can also enable **Grading Messages** in the **Description** group box.

Enabling grading messages causes a notification to be sent to the LE if the threshold set for the DEG alarm has been exceeded (see above).

4. Click **OK** and select **Data** → **Send to Node**.

3.14.3 Blocking and unblocking a user port

Node Manager allows you to block or unblock a port in the V5 interface for testing purposes, for example.

Note

If you want to block PSTN semi-permanent lines, make sure that the LE supports this function. All local exchanges do not support blocking of semi-permanent lines.

- To block a user port:

1. Select the unit in the **Subrack** window.
2. Select **Configure** → **Interface Usage** from the menu. The **Interface Usage** dialog box will open.
3. Select the **User Ports** tab.
4. From the list, select the user port that you want to block.

5. Select either **Block** or **Block Now**.
 - Selecting **Block** causes a blocking request to be sent to the LE. The port will not be blocked until the LE grants a blocking permission (that is, not until the ongoing call is finished).
 - Selecting **Block Now** causes the port to be blocked immediately, that is, it interrupts a phone call possibly on at the moment of giving the blocking command.

▶ To cancel a blocking request selected with the **Block** option:

1. Open the appropriate user port window.
2. Select the user port which is blocking.
3. From the **Request** box, select **Abort Block**.

▶ To unblock a user port:

1. Open the appropriate user port window.
2. Select the user port that you want to unblock.
3. From the **Request** box, select **Unblock**.

3.15 Starting or stopping a V5 interface

▶ To start or stop a V5 interface, follow the procedure below:

1. Select **Configure** → **V5 Interface**. The **Configure V5 Interface** dialog box will be displayed.
2. From the **V5.1 and V5.2 Interfaces** list box, select an interface.
3. Select the wanted option.

The buttons are enabled only if the related actions are valid for the selected interface. This box only displays values which are valid for the current state of the selected interface.

- To start an interface, select **Start**. You cannot change the signalling without stopping an interface.
 - To stop an interface, select **Stop**. Note that selecting **Stop** will stop all traffic.
 - Selecting **Restart PSTN** will restart PSTN protocols and will disconnect all PSTN traffic.
4. Select **Data** → **Send to Node**. You can check the **Status** in the **V5.1 and V5.2 Interfaces** list box.

3.16 Editing or deleting a V5 interface

Note

Before starting the editing, refresh the window manually by selecting **Data** → **Refresh from Node**. Some of the edit functions also require stopping the interface.

Editing an existing V5 interface may be necessary:

- to review configuration in case it does not match that on the local exchange
 - to move or add/delete signalling from one 2 link to a new link
 - to run tests on the 2M link
 - to block a 2M link.
-

Note

If security is enabled, you must hold at least user access level 4 to be able to configure an existing V5 interface.

► To edit or delete a V5 interface, follow the procedure below:

1. Select **Configure** → **V5 Interface** to display the **Configure V5 Interface** dialog box.
2. From the **V5.1 and V5.2 Interfaces** list box, select an interface.
3. Click the **Delete** or **Edit** button for the wanted option.

Selecting the **Edit** button opens the **Configure V5.2 Interface Properties** or **Configure V5.1 Interface Properties** dialog box, depending on the selected interface type.

4. Select **Data** → **Data Send to Node**.
-

Note

If the selected link belongs to an interface that has been started, you should first stop the interface. However, it is possible to delete a link from a started interface as long as the link contains no signalling.

► To add a new 2M link to an existing V5 interface, follow the procedure below:

1. Stop the V5 interface in Eksos N20. If you do not want to configure C-channels, this step is unnecessary.
2. Make the necessary modifications in the LE configuration.
3. Bring the new 2M interface into use in Eksos N20.
4. Add the new link to the Eksos N20 V5 interface. First add the link, then assign C-channels if necessary.
5. If you had to stop the V5 interface, start it again.

Note

When you are reconfiguring the subscriber signalling, first delete the old part (C-channels and standby channels) and send the changes to the node. Then refresh the settings manually and only after that configure the new subscriber signalling with the same settings as at the LE.

3.17 Configuring service switches

This section lists the procedures that are required to bring the service switch into use. When configuring the service switch, take into account the following configuration restrictions:

- one service switch connection per plug-in unit
- plug-in units can access one out of two accessible bus lines
- up to eight service switch connections for PSTN units per subrack
- up to eight service switch connections for ISDN units per subrack
- line tests have higher priority than service switch connections, which is why service switch connections are not activated during ongoing line tests.

Note

Before starting to configure service switches, make a plan and follow it consistently.

Note

Make sure that the units have been installed and physical cabling for the service switch has been done before configuring the service switch cabling.

3.17.1 Configuring service switch cabling

- ▶ To configure the service switch cabling:
 1. Select **Configure** → **Service Switch Cabling** from the main menu. The **Service Switch Cabling** dialog box will open.

The **Service Switch Cabling** dialog box provides an overview of all service switch connections and available services.




Figure 30 Service Switch Cabling dialog box

2. Select the line that you want to configure in the **PSTN connections** or **ISDN connections** group box, and then click the **Configure** button. (Alternatively double-click the line you want to change.) The **Configure Service Switch Cabling** dialog box will open.

The **Configure** button will only be enabled when a line is selected in one of the group boxes.

External units are indicated by *Ext.* in front of the unit description.

3. In the **Configure Service Switch Cabling** dialog box, you can add, edit or delete cabling information for the associated connector.

Figure 31 Configure Service Switch Cabling dialog box

4. Select the line to be configured in the **Line No** drop-down box in the **Connector** group box. Node Manager automatically chooses the line selected in the **PSTN connections** or **ISDN connections** group box as the default choice.
5. In the **Service** group box, select the required service.
6. In the **Splitter** group box, you can write the name, location, slot and interface for the splitter.
7. In the **PSTN/ISDN** group box, select the tributary interface. You can also write the name, location and slot for the service.
8. In the **ADSL unit** group box, you can write the name, location, slot and interface of the ADSL unit.
9. When the settings are as you want them, click **OK**.
10. Select **Data -> Send to Node**. To check the updated window, select **Data -> Refresh from Node**.

3.17.2 Switching a service

The procedure below presents the generic rules of service switching.

Note

Make sure that the units have been installed, physical cabling for the service switch has been done and the service switch cabling has been configured.

- ▶ To switch a service, follow the procedure below:
 1. Select the unit in the **Subrack** window by double-clicking it. The **Ux <unit>** window opens (x stands for the slot number where the unit is installed).
 2. In the **Ux <unit>** window, select the interface and right-click to open the pop-up menu.
 3. Select **Switch Service** from the pop-up menu.
 4. Select a service from the **Service Switch Unitx** dialog box.
 5. In the pop-up menu that opens, click **OK**, then select **Data** → **Send to Node**.

Note

If only the **None** option is available in the pop-up menu, make sure that you have configured service switch cabling correctly, see section 3.17.1.

Note

If you want to remove service switch cabling for a particular line, there must be no service set for that line (that is, the **None** option must be selected).

3.17.3 Re-configuring service switches

This section outlines the procedure for changing temporary service switches into permanent ones and releasing the resources for new remote service switches. This should be done during the first site visit after the temporary switches have been configured.

- ▶ To re-configure service switches, follow the procedure below:
 1. Release the service switch according to the instructions given in section 3.17.2. After this, the selected service should be **None**.
 2. Modify the service switch cabling, if that is needed, according to instructions given in section 3.17.1.
 3. If you need to install or remove plug-in units, or modify cabling, do these only after the first two steps have been done.

3.18 Configuring DIU interfaces

This section lists the interface-specific attributes that need to be set before the DIU interfaces can be brought into use.

! Caution

Do not configure DIU settings when the interface is in use.

► To configure a DIU interface:

1. Select the DIU unit which you want to configure by clicking it in the **Subrack** window. Note that the **Subrack** window also shows the type of the DIU unit:
 - **DIU-GG** is the 4 x G.703/G.704 unit
 - **DIU-VV** is the 4 x V.xx/X.21 unit
 - **DIU-VG** is the 2 x V.xx/X.21 + 2 x G.703/G.704 unit.
2. With the DIU unit selected, select **Configure** → **Interface** or double-click the DIU unit. The **Ux DIU_XX** window is displayed.

The **Unit Configuration** window shows one functional block for each interface.

3. Select the interface by either double-clicking it or by right-clicking it and then selecting **Configure** from the pop-up menu. The **Configure DIU-XX Ux** dialog box will open.




Figure 32 Configure DIU_XX Ux window

4. In the **Interface** group box, select the desired values.
 - The **Also Apply To...** button allows you to copy all of the attribute settings to all of the interfaces selected in the **Number** box.
 - Enter a name for the interface in the **Name** text box.
5. In the **Settings** group box select the appropriate interface settings.

Note

User action in this window can cause changes to data in proceeding windows. Because of this, non-valid combinations are greyed-out.

You can set the rate in the **User rate** drop-down box, but note that the rate can change according to selections made in the **Settings** group box. **Cross-connect rate** is display only and its value updated by Node Manager according to the current settings.

Note

Clicking **Advanced...** opens the **Advanced DIU Interface Settings** dialog box. The contents of this window depend on the settings made in Step 5.

6. When the settings are as you want them, click **OK**.
7. Select **Data -> Send to Node**. If you want to check the current settings, select **Data -> Refresh from Node** and the view the window again.

3.19 Configuring leased lines

Note

A semi-permanent leased line is under the V5 control. A permanent leased line is provided via a cross-connect and it is not under V5 control.

Note

The Eksos N20 node cannot determine when a V5 ISDN B-channel is operating as a semi-permanent leased line. Semi-permanent ISDN B-channels are configured on the LE only.

Eksos N20 provides two separate banks for leased line settings. Each bank contains separate configuration information of leased lines for the Eksos N20 node. Only one of these banks can be activated at a time. The other bank will remain passive until it is activated.

Eksos N20 supports permanent leased lines and semi-permanent leased lines. You can edit active or inactive banks, switch an inactive bank to be active or vice versa, and copy information from one bank to another.

The following plug-in units support leased lines:

- TR2M4 (time slot 0 cannot be cross-connected)
- DIU
- NCU (time slot 0 cannot be cross-connected)
- ISDN (up to 48 x 64 kbit/s time slots for cross-connection)
- PSTN (up to 32 x 64 kbit/s time slots for cross-connection).

Note

A line test and switching an interface override a leased line.

When creating a new leased line, take into account the following restrictions:

- There must be equal capacity on both sides.
- Use only continuous blocks of connection points (time slots).
- A block of connection points (time slots) must be completely on one interface.

Note

If a PSTN interface is configured as a V5.2 user port, it cannot be reconfigured as a leased line interface. You first have to take the port out of V5 use and then you can change it to a leased line connection.

- ▶ To add or edit leased lines:
 1. Select **Configure** → **Leased Lines** → **Active Leased Line Bank** from the main menu (Alternatively, you can select **Inactive Leased Line Bank**). The **Active Leased Line Bank** window will open.




Figure 33 The Active Leased Line Bank window

2. Click the **Add.../Edit** button to create a new leased line or to edit one. The **Add Leased Line** or **Edit Leased Line** dialog box opens according to your selection.

In the **Add Leased Line** dialog box, you can define one or more leased lines. For a leased line to be formed, you have to define two connection points.




Figure 34 The Add Leased Line dialog box

3. In the **CP 1** list, select the first connection point. Multiple connections must use continuous connection points. Those connection points that cannot be selected are greyed out.
4. In the **CP 2** list, select the second connection point. Multiple connections must use continuous connection points. Those connection points that cannot be selected are greyed out.
5. In the **Number of Connections** box, select the number of cross-connections. Note that you cannot select this option before you have defined both connection points.
6. You can also enter or edit a name for the leased line in the **Name** box. Note that when more than one leased lines are created in the same operation, all leased lines will have the same name.
7. Once you have created or edited the required leased lines, click **OK**. The **OK** button will not be enabled until an equal number of connections are made at both connection points.

Note

Repeat steps 2. to 7. for each leased line to be added or edited.

8. Select **Data** → **Send To Node** to send the new setup to the node.

► To delete a leased line:

1. Select **Configure** → **Leased Line** → **Active Leased Line Bank** or **Inactive Leased Line Bank** from the main menu. For example, the **Active Leased Line Bank** window will open.
2. From the **n x 64 kbit/s** tab, select one or more lines that you want delete.
3. To delete the cross-connections, click the **Delete** button.
4. Select **Data** → **Send To Node** to send the new setup to the node.

► To manage a leased line bank:

1. Select **Configure** → **Leased Lines** → **Bank Management** from the main menu. The **Bank Management** window will open.
2. From the **Inactive** box, select a bank.
3. From the box in the middle, select the required command.
 - **Copy** copies all configured cross-connections from one bank to another
 - **Swap** activates an inactive bank
 - **None** is the default command which does not alter the settings.

The arrow attributed to a command indicates the direction in which the command is to be issued.

4. Select **Data** → **Send to Node** to send the contents of the window to the node.

3.20 Configuring and viewing monitoring data

3.20.1 Current alarms list

- ▶ To view current alarms, select **Monitor** → **Current Alarms**. The **Current Alarms List** window will be displayed, containing details of the current alarms on the currently managed node. The window is automatically updated if any new alarms occur on the node while the window is open.




Figure 35 Current Alarms List window

The alarms are displayed in the window, one per line, the most recent at the top. Each line contains the severity and classification of the alarm followed by the long form of the descriptive text message about the alarm. The severities are:

- Critical
- Major
- Minor
- Warning.

3.20.2 Event history log

The event history log is a file that is stored in memory on a node. It is used to record information about:

- alarms that have been generated by the node
- alarms that have been cleared on the node.

After the units are installed, the default state for the event logging is 'Enabled'.

We recommend that the event history log is enabled, because if there are any problems, examining the event log will help to trace the possible fault.

- ▶ To view the event history log file for the node which is currently being managed:
 1. Select **Monitor** → **Event History Log**.
 2. Update the contents of the **Event History Log** window by selecting **Data**→ **Refresh from Node**.




Figure 36 The Event History Log window

The alarms are displayed exactly as they would be displayed in the **Current Alarm List** window, except that the time and date the alarm occurred is also given. The events can be sorted according to time, severity, type or name of the event.

Alarms are displayed in the window one per line, the most recent at the top. Each line contains the time and date, severity and classification of the alarm followed by the long form of the descriptive text message about the alarm.

At the bottom of the window, you can view how full the log is and check the number of entries in the log.

- ▶ To set up an event history log file for the node which is currently being managed:
 1. Select **Monitor** → **Event History Log**.
 2. Click **Set Up...**. The **Set Up Event History Log** dialog box appears.
 3. To enable the event history file, check the **Enabled** check box in the **Data Collection** group box.
 4. Select **Wrap** or **Halt** from the **Full Action** group box, depending on what you want to happen to the event history log file when it becomes full:
 - **Wrap** starts to overwrite the log file from the beginning with new alarms
 - **Halt** stops appending new alarms to the log file and logging will be continued only after you have cleared the log.
 5. Click **OK**.
 6. Select **Data** → **Send To Node**.
- ▶ To clear the event history log file:
 1. Select **Monitor** → **Event History Log**.
 2. Check the **Clear Log** check box.
 3. Select **Data** → **Send To Node**.

The event history log file will be cleared of all information. The configuration settings for the log file will be retained.

3.20.3 Performance monitoring

The performance windows provide the current and past error performance on functional blocks within an Eksos N20 node. Performance information conforms to G.826 and is available as absolute counts or as ratios.

The NCU collects the following performance information on both the aggregate and the tributary 2M interfaces:

- Errored Seconds (ES)
- Severely Errored Seconds (SES)
- Unavailable Seconds (UAS)
- Background Block Errors (BBE).

Before you can view performance data, you must first enable the collection of the data by configuring the performance attributes.

- ▶ To configure the performance data collection:
 1. In the **Subrack** window, double-click the unit (NCU or TR2M4) you want to configure.
 2. Double-click the interface (2M) for which you want to enable data collection. The **Configure Ux 2M** window (x stands for the slot number where the unit is installed) is displayed.




Figure 37 Configure Ux 2M window

3. In every window in which it appears, the **Performance Collection** group box allows you to choose whether performance data will be collected every 15 minutes, every 24 hours, at both of these intervals, or not at all. To enable or disable either or both of the collection intervals, check the appropriate check box.
4. Click **OK** and then select **Data** → **Send to Node**.

- ▶ To view the performance data:
 1. In the **Subrack** window, double-click the unit you want to configure.
 2. Right-click the selected interface

A pop-up menu is displayed enabling you to choose whether you want to view **Current Performance** or **Performance History**.

 - **Current Performance** shows information about the current recording period.
 - **Performance History** shows information about previously completed recording periods (up to 16 records).
- ▶ To monitor current performance:
 1. In the **Subrack** window, double-click the unit (NCU or TR2M4 unit) you want to monitor. Select an interface from the next window that is displayed.
 2. Select **Monitor** → **Current Performance**. The **Current Performance** window will be displayed. This window contains performance details for the currently-selected unit/interface in the **Subrack** window. If no details are shown, configure the performance data collection attributes.




Figure 38 Current Performance window

Performance data is collected in periods of 15 minutes and 24 hours. The 15-minute periods start at 0, 15, 30 and 45 minutes past each hour and the 24-hour periods start at midnight each day. This means that the first period after starting data collection will generally be shorter than a full period and hence will be marked by the node as **Suspect**.

You can see the data either in absolute counts or as ratios.


Time Elapsed indicates the time from the start of the period.

The status can be one of the following:

- **OK**
- **Suspect**
- **Not Collected**

► To monitor performance history:

1. In the **Subrack** window, double-click the unit (NCU or TR2M4 unit) you want to monitor. Select an interface from the next window that is displayed.
2. Select **Monitor** → **Performance History**. The **Performance History** window will be displayed. This window contains performance details for the currently-selected unit/interface in the **Subrack** window. If no details are shown, configure the performance data collection attributes.



No.	End Date	End Time	Collection	ES	SES	UAS	BBE
1	08.11.2000	0:00:00	Suspect	1	0	10	435
2	12.11.2000	0:00:00	OK	1	0	39	9
3	15.11.2000	0:00:00	OK	0	0	41604	0
4	16.11.2000	0:00:00	OK	0	0	86400	0
5	17.11.2000	0:00:00	OK	0	0	86400	0

Figure 39 Performance History window

You can select either the 15-minute periods or 24-hour periods to monitor. For other details of the window, please refer to the **Current Performance** window.

3.20.4 Block status

The **Block Status** window shows the active alarms and events of the selected block of the unit. Block status can be viewed for NCU, TR2M4, ISDN and PSTN units.

► To view the block status:

1. In the **Subrack** window, double-click the unit you want to monitor.
2. Select an interface from the unit window. Then select **Monitor** → **Block Status**.




Figure 40 Block Status window

3. If you want the window to be updated automatically when new alarms occur, check **Auto Refresh**.

There can be multiple instances of this window to view the details of more than one block.

3.21 Line testing

This section explains how to use the line testing feature of Eksos N20. To perform most of these tests, an LMU must be installed in the node.

The tests for the ISDN and DIU units become available only when the units have been configured in their slots.

The types of tests supported are listed in Tables 10 to 13.

Test type	Result format	Criteria, thresholds	Activation
Basic test-out (electrical tests), including measurements for the following subtests: – AC _{RMS} voltage (a–gnd, b–gnd, and a–b) – DC voltage (a–gnd, b–gnd, and a–b) – Capacitance (a–gnd, b–gnd, and a–b) – Leakage resistance (a–gnd, b–gnd, a–b, b–a, a–batt, and b–batt)	Pass, Fail. Subtests: Value & status	All subtests' status OK. Subtests configurable: Low, High	On-demand/ scheduled
Loop resistance measurement R _{a-b}	Value & status	Configurable Low, High	On-demand/ scheduled

Table 10 Supported test-out measurements

PSTN Test-in tests	Result format	Criteria, thresholds	Activation
PSTN interface diagnostic test, including the following subtests: – Feeding voltage test – Feeding current test – Loop detection test – Ring trip detection test – Ringing current test – Private meter pulse test – CODEC test	Pass, Fail. Subtests: OK/ NOK	All subtests OK. Subtests: fixed value	On-demand/ scheduled
Dial tone test	Pass, Fail	Dial tone detected ¹⁾	On-demand/ scheduled
1) Note that only the continuous dial tone (425 Hz) is supported.			

Table 11 Supported PSTN test-in measurements

ISDN loopback tests	Result format	Criteria, thresholds	Activation
Loop1 (in line termination (LT))	Pass/Fail	1)	On-demand
Loop1A (in regenerator (REG))	Pass/Fail	1)	On-demand
Loop2 (in NT1)	Pass/Fail	1)	On-demand
1) Except for the LoopD, a selectable test pattern can be inserted and compared with the signal received through the loop. The criteria for comparing the received data is stated in Node Manager as Percentage of error seconds . There is a fixed threshold that will define the result of loopback test as Fail if more than 5% of the seconds during the loopback activation time are erroneous.			

Table 12 Supported ISDN loopback tests

ISDN Remote tests	Result format	Criteria, thresholds	Activation
Partial activation test	Pass/Fail	NT confirmation	On-demand
Full activation test	Pass/Fail	NT confirmation	On-demand
Node sends corrupt CRC to NT1 *)	Pass/Fail	FarEndBlockError alarm	On-demand
NT1 sends corrupt CRC to node *)	Pass/Fail	NearEndBlockError alarm	On-demand
Hold NT1 state *)	Pass/Fail	NT confirmation	On-demand
Node sends pulse mask to NT1	Pass/Fail	NA	On-demand
*) only with ISDNQ			

Table 13 Supported ISDN remote tests

3.21.1 On-demand tests

The **Interface Tests** window lists all of the interfaces on the node and their test-related attributes. This window allows you to request tests, view the requests before sending them to the node, and to decide against requests before sending them. It is also possible to abort or remove a running test.

Open the **Interface Tests** window by selecting **Configure** → **Interface Tests...** → **On-demand Tests** from the main menu bar.

► To request interface tests:

1. Select **Request Test...** to open the **Configure Interface Tests** dialog box.
2. You can now choose to perform line tests, ISDN loopbacks, ISDN remote test or DIU loopbacks by selecting the appropriate tab.

► To perform line tests:

1. In the **Configure Interface Tests** dialog box, select the **Line Tests** tab.




Figure 41 Line Tests tab

2. From the **Test Definition** group box, select the tests you want to perform.
 - **Electrical Test** and **Loop Resistance** apply to both PSTN and ISDN interfaces. The tests measure the electrical characteristics of the line. If the user sets up tests on more than one line in the same user interface operation, failure or cancellation affects all interfaces on which the test has been set up and cancels also all other tests on all interfaces sent with the same request.
 - **Interface Diagnostic** and **Dial Tone Test** only apply to PSTN interfaces. They can be requested on more than one interface.

- **External Test Access** and **Dry Loop** tests apply to both PSTN and ISDN interfaces. There can be only one external test access or dry loop in a node at a time. It is not possible to set up line tests on other interfaces while one interface is in the external test access or dry loop state. The timeout for these tests can be set in the node settings menu. These states can be cancelled also by the **Cancel** option.
 - In the **External Test Access** state, the subscriber line is connected to the external test interface of the LMU, thus allowing you to conduct measurements using external measuring devices.
 - Selecting the **Dry Loop** test option does not activate any tests. It is a function that disconnects the line circuit from the subscriber line and leaves the circuit in an open state, thus enabling external test access to the line (without using the LMU's external test access interface).
 - **Cable pair ID tone** behaves in the same way as the **External Test Access** and **Dry Loop** tests. **Cable pair ID tone** can only be requested for a single interface and cannot be included in a multiple test request or in a single test request on multiple interfaces. This state can be cancelled also by the **Cancel** option.
3. In the **Test Conditions** group box, specify the action which should be taken if a customer call occurs when the line test is attempted:
- cut call,
 - reject test
 - wait.
- If there is a call attempt while the line tests are in progress and **Reject Test** has been selected, the call will fail. (This does not concern electrical measurements for PSTN interfaces).
- If you select **Wait**, the test will be conducted normally if the line becomes free during the wait time selected. If the line keeps busy, the test will be rejected.
- The **Super Cut Call** option in the **Test Conditions** group box is intended to be used when testing lines assigned for service switching. The service switch connections affect line testing only if the line to be tested is on the same unit as the switched line.
4. When you are satisfied with your selections, click **OK**. The **Test Result** window will automatically open if the **Show results when received** checkbox is checked in the **Interface Tests** window.
5. Select **Data** → **Send To Node**.

Note

Test results are not stored between sessions. When you click on **Close** to close down the **Interface Tests** window, the log is emptied automatically.

- ▶ To perform ISDN loopbacks and patterns:
 1. In the **Configure Interface Tests** dialog box, select the **ISDN Loopbacks** tab. It is only possible to make this selection if ISDN cards are installed in the node and the selected interfaces do not have active tests running.




Figure 42 ISDN Loopbacks tab

2. In the **Unit Test Pattern** group box, select the required option. The selectable test pattern options are:
 - **No Test Pattern**
 - **All bits on**
 - **All bits off,**
 - **16 bit Fixed pattern**
 - pseudo random bit sequences based on **Polynomial** of orders 11 or 15.Each ISDN unit can have a different test pattern. Only one interface in an ISDN unit can use the test pattern.
3. In the **In result report show** box, select whether to show the results as an error ratio or as the absolute number of errored bits.

4. If you have selected a test pattern, the possible selections in the **Type of loopback** box are:
 - Loop1 (loop closed in the LT as close to the interface as possible)
 - Loop1A (loop closed in a repeater connected between the LT and NT)
 - Loop2 (loop closed in the NT).

The different positions of the loops in the network make it possible to determine the position of faults.

5. In the **Channels to loopback** box, select a channel for loopback. The default value is **b1b2d**.
6. In the **Test Conditions** group box, specify the action which should be taken if a customer call occurs when the line test is attempted:
 - cut call,
 - reject test
 - wait.

If there is a call attempt while the line tests are in progress and **Reject Test** has been selected, the call will fail.

If you select **Wait**, the test will be conducted normally if the line becomes free during the wait time selected. If the line keeps busy, the test will be rejected.

7. In the **Loopback Test Timeout** group box, set the timeout for each loopback.
8. When you are satisfied with your selections, click **OK**. The **Test Result** window will automatically open if the **Show results when received** checkbox is checked in the **Interface Tests** window.
9. Select **Data** → **Send To Node**.

Note

Test results are not stored between sessions. When you click on **Close** to close down the **Interface Tests** window, the log is emptied automatically.

► To perform ISDN remote tests:

1. In the **Configure Interface Tests** dialog box, select the **ISDN Remote** tab.
2. There are six possible remote ISDN tests in the **Test Type** group box:
 - **Node sends corrupt CRC to NT1 (ISDNUQ only)**
 - **NT1 sends corrupt CRC to node (ISDNUQ only)**
 - **Hold NT1 state (ISDNUQ only)**
 - **Node sends pulse mask to NT1**
 - **Partial activation test**
 - **Full activation test.**

All of the tests can be used with ISDN 2B1Q units. Only the last three tests can be used with ISDN 4B3T units. You can set up one remote test for an interface.

3. In the **Test Timeout**, set the timeout for each test. Note that there are no timeouts for the partial and full activation tests.
4. When you are satisfied with your selections, click **OK**. The **Test Result** window will automatically open if the **Show results when received** checkbox is checked in the **Interface Tests** window.
5. Select **Data** → **Send To Node**.

Note

When using NT+2ab, the full activation test can pass even if there was no telephone connected to the NT.

Note

Test results are not stored between sessions. When you click on **Close** to close down the **Interface Tests** window, the log is emptied automatically.

- To perform DIU loopback tests:
1. In the **Configure Interface Tests** dialog box, select the **DIU Loopback** tab.
 2. There are up to eight possible remote DIU tests in the **Type of loopback** group box (depending on the type of DIU selected):
 - **loop2** for V.xx interfaces
 - **loop3** for V.xx interfaces
 - **loop3C** for X.21 interfaces
 - **loop2B** for X.21 interfaces
 - **loop3B** for X.21 interfaces
 - **lineLoop** for G.703 interfaces
 - **equipmentLoop** for G.703 interfaces.
 3. In the **Loopback Test Timeout** group box, set the timeout for each test.
 4. When you are satisfied with your selections, click **OK**. The **Test Result** window will automatically open if the **Show results when received** checkbox is checked in the **Interface Tests** window.
 5. Select **Data → Send To Node**.

Note

Test results are not stored between sessions. When you click on **Close** to close down the **Interface Tests** window, the log is emptied automatically.

- To cancel a test (after it has been configured but not sent to the node):
1. In the **Interface Tests** dialog box, select the test.
 2. Click on the **No Request** button.
- To abort a test (after the test configuration has been sent to the node):
1. In the **Interface Tests** dialog box, select the test.
 2. Click on the **Abort/Remove Tests** button.

3.21.2 Scheduled tests

You can specify up to ten scheduled tests. For each scheduled test, you must specify:

- scheduled details (name, time periodicity)
- list of tests to be performed
- list of interfaces on which the test will performed.

► To create or edit a new scheduled test:

1. Select **Configure** → **Interface Tests...** → **Scheduled Tests** from the main menu. The **Configure Scheduled Tests** dialog box will open.




Figure 43 Configure Scheduled Tests dialog box

The **Test** tab presents the scheduled tests actually configured on the Eksos N20 node.

- The tests are identified by an **ID** and a **Name**.
 - The **State** column indicates if a test is enabled or disabled.
 - The **Result Available** column displays two values for each test. The first value indicates the completion of the test and the second indicates the proportion of the test results available on Node Manager.
 - The **Result Request** column indicates if you have requested some results to be downloaded to Node Manager.
 - The **State Request** indicates if the state of the test should be modified.
2. Click the **Add...** or **Edit...** button to create a new scheduled test. The **Add Scheduled Test** dialog box opens. The **Add Scheduled Test** dialog box is used to configure a new or existing test.

Select an interface and click the **Delete** button to delete a specific interface. In the **Test State Request** box, you can **enable** or **disable** a scheduled test. **None** is the default value.

3. Enter a name in the **Scheduled Test Name** box.
4. In the **Schedule** group box, select a starting date, time periodicity in days and hours. Also, select the maximum duration for the test.
 - **Start time** is the time at which the first test will be conducted.
 - **Stop time** is the time at which the scheduler will stop conducting the tests.
 - **Period** is the interval between tests.
 - **Duration** is the maximum time one test round takes.
 - **Wait time** is the time before the cases rejected during the first test round are tested again.
5. In the **Stop Time** group box, select the test to run continuously (**No Stop Time-work continuously**) or set a stop time and date (**Set Stop Time**).
6. In the **Test To Perform** group box, select the test you want to perform. Then click **OK**.

The tests that you can perform are:

- **Electrical Test**
- **Loop Resistance**
- **POTS diagnostics**
- **Dial Tone Test**.

The **POTS diagnostics** and **Dial Tone Test** can also be set on ISDN units, but the tests will not be run.

7. The **Scheduled Tests** dialog box will open. Click the **Interfaces To Test...** button. The **Interface In Schedule Test** dialog box will open.
8. In the **Interface In Schedule Test** dialog box, select the interfaces to test. In the **Available Interfaces** list, select an interface you want test and then click the **<= Add** button. The selected interface will appear in the **Interfaces To Test** list. Note that you can select more than one interface at a time.

Note

You cannot perform a line test on a leased line. If you select a leased line, the **<=Add** button is greyed out.

If you want to remove an interface from the **Interfaces To Test** list, select the interface and click the **Remove =>** button.

9. Click **OK**. After clicking **OK**, Node Manager will give an estimation of the total duration of the configured test and compare it to the given **Max Duration** in the **Add Scheduled Test** dialog box. If the times are not the same, Node Manager will give a warning on this.
10. Select **Data** → **Send To Node**.

- ▶ To view results of a scheduled tests:
 1. Select **Configure** → **Interface Tests...** → **Scheduled Tests** from the main menu. The **Configure Scheduled Tests** dialog box will open.
 2. In the the **Test Results Get** group box, select either **Get Failed** or **Get All** test information. The result can be viewed after the data has been sent to the node.
 3. Click **View Results**. The **View Results** dialog box will open.
 4. Click **Print** to print the available results. You can also clear the log by clicking **Clear Log**.
 5. When you are finished, click **Close** to close the **View Results** dialog box.

- ▶ To set a threshold for a scheduled test:
 1. Select **Configure** → **Interface Tests...** → **Scheduled Tests** from the main menu. The **Configure Scheduled Tests** dialog box will open.
 2. Select the **Threshold Sets** tab.

You can configure up to 10 sets of threshold values for one or more interfaces. The list displays the thresholds configured on the Eksos N20 node and indicates the number of PSTN and ISDN interfaces using the threshold.
 3. To create a new threshold value, click **Add Set...** If you want to change a threshold set that exists, select the threshold from the list and then click **Edit Set...** The **Add Threshold Set** dialog box will open.

If you want to remove a threshold set, select it from the list and click **Delete Set**.
 4. In the **Threshold Set Name** box, enter a name for the threshold set.
 5. To create a new test type, click **Add...** If you want to change the values of a test type that exists, select the test type from the list and then click **Edit...** The **Add threshold** dialog box will open.

If you want to remove a test type, select it from the list and click **Delete**.
 6. In the **Add threshold** dialog box, select the test from the **Test Type** box.

The different types of tests that are available are shown in Tables 10 and 11.
 7. Select the threshold type from the **Threshold Type** box. Then click **OK**.
 8. In the **Threshold Sets** tab, select the associated interfaces by clicking on the **Associate interface** button.
 9. In the **Interfaces In Schedule Test** dialog box, you can select the interfaces to test. Select from the **Available Interfaces** list an interface you want to test and then click the **<= Add** button. The selected interface will appear in the **Interfaces To Test** list. Note that you can select more than one interface at a time.

Note

You cannot perform a scheduled line test on a leased line. If you select a leased line, the **<=Add** button is greyed out.

If you want to remove an interface from the **Interfaces To Test** list, select the interface and click the **Remove =>** button.

10. Click **OK**. After clicking **OK**, Node Manager will give an estimation of the total duration of the configured test and compare it to the given **Max Duration** in the **Add Scheduled Test** dialog box.

11. Select **Data** → **Send To Node**.

► To view a summary of the scheduled tests:

1. Select **Configure** → **Interface Tests...** → **Scheduled Tests** from the main menu. The **Configure Scheduled Tests** dialog box will open.
2. Select the **Summary** tab. This tab gives a summary of the scheduled tests and threshold sets associated with each interface. This page is read-only.
3. To close the **Summary** page, click on the close button in the top right corner of the window.

3.22 Stopping Node Manager

Closing the connection to a node

► To stop managing the node, but without closing Node Manager:

1. Select **Node** → **Stop Managing** to end the management session.

Node Manager will now check if there are any unsent edits contained in any document windows. If there are, a warning message dialog box will be displayed telling you about the unsent edits.

2. Click **OK** and send the edits by selecting **Data** → **Send To Node**. Once this is complete, select **Node** → **Stop Managing** again.


When there are no document windows with unsent edits, a confirmation message dialog box will be displayed asking you to confirm that you really want to stop managing the node.

3. Click **Yes**. The connection to the node will be closed within a few seconds.

Closing document windows

When you choose to close down or refresh windows containing edited data which has not yet been sent to the node, Node Manager will always check first if you want to continue with the close or refresh, because you would lose the edits which you had made.

Closing down Node Manager

 **Caution**

It is important that you follow the procedure outlined below for closing down Node Manager. If you do not close down Node Manager using this procedure, data may be corrupted.

► To completely close down Node Manager:

1. Select **Node** → **Stop Managing**.

If Node Manager is managing a node when you try to close the manager, it will check if there are any document windows containing unsent edits. If there are, send the edits by selecting **Data** → **Send To Node**.

2. Close down Node Manager by one of the two following methods:
 - Select **Node** → **Exit**, or
 - Click the **Close** button (in the top right corner of the **Eksos Node Manager** window).

Node Manager itself will then close down. This may take a few seconds to complete.

3.23 Clearing node configuration data ('blasting' the node)



WARNING

Carrying out this procedure causes loss of any factory set operator configuration and any configurations you may have done yourself. Before blasting the node, you should save the configuration into a file.

If you are configuring a fresh node, please go to section 3.1.

If you are reconfiguring a node that has already been in use, clear first all of the existing node configuration data by carrying out the following steps.

► Follow this procedure to clear node configuration data:

1. Exit from Node Manager.
2. Turn off the power to the node.
3. Remove the NCU plug-in unit from the subrack.
4. Connect a jumper across the bottom two pins of the NR2K jumper area. The jumper area is located near to the processor IC (the largest IC on the NCU) and the bottom two pins are those nearest to the NR1S jumper area.
5. Insert the NCU unit into the subrack.
6. Turn on the power to the node.
7. After a short time, the LED indicator on the NCU will start flashing orange, and the LED on the PSTN unit will turn red. The LED indicator on the ISDN unit will first start flashing orange, then go very quickly from red to orange to green, and finally turn red for a short while before going back to flashing orange. Wait about 3 minutes after this.
8. Turn off the power to the node.
9. Remove the NCU unit from the subrack again.
10. Remove the jumper from the bottom two pins of the NR2K jumper area that was set in step 4.
11. Reinsert the NCU unit into the subrack.
12. Switch the power to the node back on.
13. The LED indicator on the NCU unit will briefly go from red to orange to green, then off for a few seconds. Finally it will flash green for a few seconds, then change to a steady green.
14. Proceed to section 3.2.

Chapter 4

Managing alarms

Eksos N20 does not require scheduled maintenance. Maintenance is necessary only when the equipment indicates a fault by means of an alarm.

This chapter provides information on how to obtain detailed alarm information and how to configure alarms.

- Sections 4.2 and 4.3 describe how the LED indicators and rack alarms are interpreted.
- Section 4.4 describes how Node Manager is used for reading and managing the alarms.

See Appendix A for a list of alarm messages and probable causes for the alarms. For further information, see the Node Manager online help.

4.1 Alarm severity

All alarms have been divided into four severity classes which indicate how serious the alarms are.

Critical alarm

A significant part of the node functions has been lost. Typically this alarm is caused by a power failure or a missing unit.

Major alarm

Some functions of the node have been lost, for example, a signal fails.

Minor alarm

A less serious fault condition, for example, a degraded signal.

Warning

A condition that may cause problems under certain circumstances.

Alarm severity		Station alarm	Unit LED	Colour codes in Node Manager
Critical	***	A	Red	Red
Major	**	A	Yellow	Orange
Minor	*	B	Yellow	Yellow
Warning	W	None	None	Blue

Table 14 Alarm severity mapping

4.2 LED indicators of plug-in units

The plug-in units have a multicolour LED indicator on their front edge. With the subrack cover closed, the LEDs can be seen through the subrack cover.

Normal operation

When the node is functioning properly and there are no alarms, only the LED of the NCU is active (green), indicating that it is working and that the power is on. In Node Manager, all units where alarm monitoring is in effect are shown green.

Green LED

The LED will be green on the working master unit and SAN unit, when the correct power is applied to the node and no alarms are active.

Yellow LED

The LED of a plug-in unit turns yellow when the unit detects an alarm, whether or not the fault concerns the unit itself. A plug-in unit with the yellow LED lit should not be taken out of the subrack until the source of the failure has been located.

Red LED

If the red LED of a plug-in unit is illuminated, the unit has a severe fault and cannot perform its main function. The unit can be removed without further disturbance to system function, and replaced with a functioning unit. However, if the battery voltage to the DC-PSA fails, the auxiliary +5V voltage activates all the red LEDs of the node, even though there is nothing wrong with the plug-in units.

The LED can turn red for the following reasons:

- If the unit's power block has failed or the battery voltage supply is missing. In this case the LED is illuminated by the reserve battery voltage generated by the power supply unit (DC-PSA).
- If the unit software has detected a fatal fault and is able to turn the red LED on. The failures which turn the red LED on are specific to each plug-in unit type.
- The NCU plug-in unit LED can turn red in case of critical external alarm.
- A unit that has not been commissioned can also have a red LED indication.

Flashing LEDs

The LED on a unit will flash when the unit is being installed with Node Manager, or if the unit is starting up, for example, after being inserted to the node.

When the LED of the NCU is flashing, the NCU is busy. For example, a unit has been inserted into the node or a unit is being installed.

LED colour and alarm severity

Alarms that have a direct physical mapping to a unit shall illuminate LEDs on the unit that they map to. This is called physical LED indication. Alarms that do not have a direct physical mapping to a unit shall illuminate LEDs on the node master unit. This is called logical LED indication. Because the unit is unable to display more than one colour simultaneously, only the highest colour severity alarm that maps to an LED shall be indicated.

4.3 Station alarm lamps and relays

Station alarms indicate problems in the Eksos N20 node or rack. When an alarm occurs, a lamp lights up on the feeding DC-PSA, so that you can quickly identify the node which is generating the alarm.

Each DC-PSA is provided with A, B and D relay outputs. In systems where a power supply adapter (DC-PSA) is used, the alarm relay information is forwarded to the alarm module of the power supply adapter. The alarm module then provides the combined A, B and D relay outputs to an external supervision system and to the corresponding rack alarm lamps. D is a reminder that the A and B alarms have been disabled with an Eksos N20 Node Manager setting.

The relay contact signal indicates an alarm by a closed contact. During normal operation, the A-alarm relay is continuously energised so that it can give an alarm even if the central battery voltage is interrupted or the power supply of the NCU fails.

Refer to the corresponding power supply documentation for more information on the function and connection options of the relay outputs.

Priorities

The station alarms have priorities A and B. The A-alarm is a prompt alarm, whose equivalence to the management system alarms is *critical* or *major*. The B-alarm is a deferred alarm, whose equivalence to management system alarms is *minor*. D-reminder indicates that A- and B-alarms have been disabled.

Disabling the station alarms

A and B station alarm indication for external alarms can be disabled with Node Manager. Select **Monitor** → **External Alarms**, which opens the **External alarms and station alarms** window where you can either enable or disable the station alarms. After they are disabled, the D-reminder becomes active and stays active until the A- and B- alarms are enabled.

4.4 Managing alarms with Node Manager

A number of different alarms can be generated by a node. For any alarm that has occurred on a node, Node Manager can provide the following information about the alarm:

- a descriptive text message about the alarm
- the severity of the alarm
- the classification of the alarm
- the time and date that the alarm occurred, if known. (This information is only available for alarms recorded in an Event history log.)

Along with a text message describing the alarm that occurred and the time of its occurrence, each alarm is *graded* to help identify how severe the alarm is. See section 4.1.

Using dynamic updating ensures that you are always aware of the severity of the most serious alarm on each unit in the node and that you are quickly warned when a serious alarm occurs on a unit. You can set dynamic updating on by checking the relevant options in the **Categories that Poll by Default** in the **Polling** window of the **Manager Options** menu.

Node Manager shows the alarm information in the following ways:

- The colour of the LED on the unit or functional block indicates the most severe alarm in that unit or block.
- **Alarm Status** area of the status bar shows the most severe alarm.
- The **Current Alarms List** window shows a list of current alarms for the node.
- Editable windows and all types of **Configure** windows show the alarms for the selected entity.
- The **Block Status** window shows the alarms and problems for a selected block.
- The **Event History Log** window shows the alarms and events chronologically with times and dates. See section 3.20.2.

When the Current Alarms window is open, it displays new alarms occurring on the node.

Note

AIS, RDI and SSF alarms only appear in the **Block Status** windows. These alarms are not shown in the **Current Alarms List** window.

When any type of configuration window is open, any new alarms will be displayed in the appropriate areas of the window.

When the **Subrack** window is open, it displays the most severe current alarm associated with each unit present in the subrack. Any new alarm occurring on a unit which is higher in severity than the current alarm shown will be dynamically updated.

When a new alarm occurs which is higher in severity than any alarm being shown, the Alarm Status area is updated.

Current Alarm List

Alarm information can be accessed via several windows, but if you want to view the current alarms in detail, select **Monitor** → **Current Alarms**.

Alarms are displayed in the window one per line, most recent at the top. Each line contains the severity and classification of the alarm followed by the long form of the descriptive text message about the alarm. The alarms can be sorted according to severity, type or name of the alarm.

Although the **Current Alarm List** window does not give you the date and time when the alarm occurred, you can obtain this information by setting up an Event History Log. For more information, refer to section 3.20.2.

Chapter 5

Upgrading

5.1 Adding and removing tributary units

Note

To ensure reliable operation, wait at least 5 seconds after removing a unit from a powered node for the unit power supplies to discharge before reinserting the unit.

Note

Do not add or remove units from the node while the green LED on the NCU is flashing. This LED flashes when the node is processing its internal data during node start-up, or after a change in the plug-in unit configuration. Note that the flashing does not always start immediately.

5.1.1 Adding tributary units

Note

When you add units, first remove the units from the configuration by selecting the **No unit** option and selecting **Data** → **Send to Node**. Then add the unit and send this information to the node.

- To add new tributary units to the Eksos N20 configuration, follow these steps:
1. Bring the new tributary unit into use. For instructions, see section 3.6.
 2. Check that the number of C-channels is adequate. See section 3.11.1.
 3. Configure the unit following the instructions given in sections 3.12, 3.13 and 3.18.

5.1.2 Removing tributary units

- ▶ To remove tributary units, perform the following steps:
 1. Remove the unit from the equipment configuration.
 2. Disconnect the signal cables and pull out the unit from the subrack.

5.1.3 Replacing tributary units

You may want to replace the existing unit with a new one, for example, when a hardware update is needed or there is a fault in the existing unit. There are two alternative ways to do the replacement depending on whether you want to restore the settings of the old unit to the new one or not.

Restoration of settings

When using this procedure, the new unit will have the same settings as the old one.

When the existing unit is replaced by a new one with the same hardware ID and the settings of the existing unit are also suitable for the new one, you should proceed as follows. No software-related configuration changes are needed.

- ▶ To restore settings:
 1. Disconnect the signal cables and pull out the existing tributary unit from the subrack.
 2. Insert a new unit to the same unit location and connect the cables.

You will get a unit mismatch alarm or compatibility failure message if the new unit is not fully compatible with the one removed. This happens if the units are of different type (if you try to replace a PSTN unit with an ISDN unit, for instance) or if the hardware versions are not compatible with each other.

No restoration of settings

When using this procedure, the new unit will have all settings at their default values.

- ▶ If you do not want to restore the settings of the existing unit or if the settings are not suitable for the new unit, proceed as follows.
 1. Connect Node Manager.
 2. Remove (with software command) the existing unit from the equipment configuration.
 3. Disconnect the signal cables and pull out the unit from the subrack.
 4. Insert the new unit in the subrack.
 5. Add (with software command) the new unit to the equipment configuration.
 6. Connect the signal cables.
 7. Check operation.
 8. Disconnect Node Manager.

5.2 Downloading software

Caution

Do not remove or install plug-in units while downloading software. This can cause the Eksos N20 node to crash.

Software can be downloaded to nodes using either the NMS Tools or Eksos N20 Node Manager. Node Manager should be used for downloading to just a few nodes.

There are two flash circuits on each unit, both of which can store software for one release. The software on one circuit is used whilst the other one is available for downloading new software to the unit. If the new software is found to be defective after activation, the old software can be taken back into use. The release of the currently used and reserve software can be seen using Node Manager.

Downloading with Eksos N20 Node Manager

Note

Software downloading should not be performed during busy hours.

Software download with Node Manager can be performed either locally or remotely. After the new software is downloaded to the units, the software can be activated using the Node Manager. The activation of the software will change the active flash circuit and start the new software.

Normally the software in the whole node, that is in every unit, is upgraded at the same time. The node software release is usually changed at the same time.

Full details for upgrading with Node Manager are given in the separate *Upgrade Instructions* document.

► To upgrade the software from C1.1 to C2.0, do the following:

1. Install the Eksos N20 Node Manager (release C2.0).
2. Connect to a C1.1 node.
3. Download the C2.0 software.
4. Activate the software:
 - In the **New Level** list box of the **Software Settings** window, select the EKN C2.0 release.
 - Select all units from the list box and check that the unit software product code versions are the ones that you want.
 - Click on the **Switch** button
 - Select **Data** -> **Send to Node**.
5. Disconnect from the node, then reconnect to the node.

6. Insert the new C2.0 units (DIU, TR2M4, new PSTN unit etc) in the subrack.

Full details for upgrading are given in the separate *Upgrade Instructions* document. See also *Eksos N20 Network Management Products, NMS Tools Product Overview*.

Appendix A

Installing and using Eksos N20 Node Manager

A.1 Installing Eksos N20 Node Manager

This section describes how to install the Eksos N20 Node Manager software on the Microsoft Windows NT 4.0 operating system.

In these instructions, we assume that:

- You are an ‘administrator’ as defined by Microsoft Windows NT 4.0. If you are not an administrator, you will not be able to install Eksos N20 Node Manager.
- The computer onto which Eksos N20 Node Manager is being installed fulfils the hardware and software requirements as detailed in *Product Description*.

A.1.1 Modifications to your Windows operating system

Files and directories created

The Eksos N20 Node Manager installation program creates the following folder structure on your computer:




Figure A-1 Installation folder structure

NOKIAMGR

This is the folder in which *all* Nokia Node Managers are installed so that they can share common files and directories.

The default name and location for this folder is C:\NOKIAMGR. You can change the default, but you should make sure that all subsequent releases of this Eksos N20 Node Manager and any other Nokia Node Manager products are also installed in this new folder.

If an earlier version of Node Manager or any other Nokia Node Manager product has been installed, the Eksos N20 Node Manager version will be installed into this directory existing directory.

EksosNM2.0

This is the folder which contains all files specific to the Eksos N20 Node Manager version you are installing. The default folder name is derived from the product and the version number of Eksos N20 Node Manager you are installing.

DATA

This folder contains all the data which you create using Eksos N20 Node Manager, such as saved configuration details.

NWD1.0

This folder contains the Network Downloader tool.

SYSTEM

This is the folder in which files and directories common to *all* Nokia Node Managers are installed. The name of this folder should *never* be changed.

DATABASE

This folder contains the Nokia database of all areas and nodes (other than those on the local LAN).

SYSTEM32

The same as SYSTEM (see above) but for 32-bit components.

INF

This is the folder in which all Nokia Node Manager information files are installed. They are for use by Nokia only. The name of this folder should *never* be changed.

Folders created (Windows NT 4.0)

The Eksos N20 Node Manager installation program creates the Programs folder *Nokia Applications*. This folder contains the Eksos N20 Node Manager application.

If you have installed any other Nokia applications on your computer, this folder window will have already been created. In this case, the Eksos N20 Node Manager application will be added to this group window.

Files changed

The ODBC registry settings are amended to add an entry for [DBS] if one is not already present. The ODBC files will be added to the WINNT\SYSTEM32 folder.

The Eksos N20 Node Manager installation program changes the Registry (part of Microsoft Windows NT; use **regedt32** to view it). The Registration sections entry for HKEY_LOCAL_MACHINE\SYSTEM\CurrentControlSet\Services has the following items:

- NokiaTP4
- StackMac.

A.1.2 Installation procedure

If you have any problems during the installation procedure described in this section, refer to Section A.1.6 which contains information on some of the more common problems that can be encountered.

► To install Eksos N20 Node Manager:

1. Switch ON your computer.
2. Start Windows NT 4.0 if it has not already started by logging in as described in your Windows NT user documentation.

Note

You must log in to Windows NT with administrator privileges to install the Eksos N20 Node Manager.

If you are unsure which login names have administrator privileges, log in to Windows NT 4.0 as an administrator and select, from the **Start** menu, **Programs** → **Administrative Tools** → **User Manager**. In the lower pane, double-click **Administrators** to list those users who have administrator privileges. You can use a different login name to run Eksos N20 Node Manager than you used when you installed Eksos N20 Node Manager.

3. Insert the Eksos N20 Node Manager installation CD. Then click the **Start** button at the bottom left of your screen.
4. Select **Run...** from the **Start** menu.
5. Enter **setup.exe** in the **Command Line** box and click **OK**.

The Eksos N20 Node Manager installation setup program will be initialised and then the Eksos N20 Node Manager installation program will start up.

The **Choose Destination Location** dialog box appears with a default folder name. (For more information on the Nokia Eksos NM2.0 folder, refer to section A.1.1.)

6. Enter a new folder name or leave the default folder name, and click **OK**. (The default location is recommended.)

Note

The folder name must not contain blank spaces. The setup program will not install Eksos N20 Node Manager into a folder whose name contains a blank space.

A dialog box will be displayed to ask you whether you want security to be enabled. Select either **Disable Security** or **Enable Security**, and then click **Next>**.

The installation program will then begin the installation. A dialog box will be displayed indicating the progress.

When the installation has been completed, the system will ask you whether you want it to install shortcuts on your desktop automatically. (Shortcuts are icons on your desktop.)

Note

If an earlier type of Nokia Node Manager using Q3 has been previously installed on your PC, you do not need to carry out steps 7. and 8.

- 7. A prompt will be displayed to remind you to install the Q3 stack.
- 8. Restart your PC.

The **Nokia TP4 NSAP Configuration** dialog box is displayed (Figure A-2). (TP4 NSAP refers to the four lower layers in the communications protocol.) If you want the PC to have the same address as it did before you installed this version of Eksos N20 Node Manager, click **Restore Previous Address**. (The **Restore Previous Address** button will not be displayed if this is the first time you have installed an Eksos N20 Node Manager.) All the empty address boxes will be filled in automatically. If you want to give the PC a different address, enter new details in the **IDI** and **Area Address** boxes. When the address details are correct, click **Apply**.




Figure A-2 NSAP Address dialog box

When you look in the **Start** menu, you will notice that a new group called **Nokia Applications** has been created, containing the Eksos N20 Node Manager application and the Configure PC Address application.

A.1.3 Changing the stack startup

The communications stack is installed so that it starts whenever Windows NT 4.0 is booted up. If you want to change the stack settings, run the **STACK configuration** application. In order to change the settings or manually start or stop the stack, you must have administrator privileges.




Figure A-3 Stack configuration dialog box

- To change the stack startup, do the following:

Select how the stack will be started by clicking on one of the option buttons in the **Startup Type** group and then click **Apply**.

If you wish to start or stop the stack manually, click either **Start Stack** or **Stop Stack**.

The configuration utility also allows you to view other NSAPs which have been located on the Local LAN. These NSAPs will include the addresses of the Eksos N20 Node Manager and other management systems, as well as nodes. Click **Refresh** or check **Auto Refresh** to update the NSAPs list. Select an item in the list to view its **Ethernet Address**.

Click **Close** after you have made any changes. If you have selected **Start when requested**, Eksos N20 Node Manager users must have administrator privileges.

A.1.4 Changing the NSAP address after installation

► To change the NSAP address after installation, do the following:

1. Run the **PCQ3 address** application to change the NSAP address.

You must not be running any Nokia applications that use the Q3 stack while you are changing the NSAP address.

2. Edit the address, then click **Apply** to save the changes.
3. To accept the changes, click **OK**. To exit without changing the PC's NSAP address, click **Cancel**.

A.1.5 Enabling security

Eksos N20 Node Manager offers a security feature, which the system administrator can choose to enable.

If security is enabled, the system administrator can control which users can make particular types of change to nodes. User privileges to make particular types of change are divided into five *user access levels*. A user's access level is set by the system administrator.

User access levels

As a user, you may be allowed to carry out a range of editing functions, depending upon your user access level.

Controls which are not available for a user to edit because of too low an access level are greyed out in Node Manager. If you require a higher user access level to the node, ask your system administrator to raise your user access level status.

There are five user access levels, which are set by the system administrator. The prefix NMS10 is necessary in order to maintain compatibility with Nokia NMS/10 network management system.

User access level	Level	Privileges
NMS10 Operator	1	<ul style="list-style-type: none"> – Read data from the node – Cannot edit settings on the node – Add nodes to the PC address database – Delete nodes from the PC address database – Print data and save data to a PC
NMS10 Basic	2	<ul style="list-style-type: none"> – Enable and disable collection of performance data for transmission interfaces – Clear Current Performance data – Delete Performance History records – Level 1 privileges
NMS10 Experienced	3	<ul style="list-style-type: none"> – Edit transmission-related variables within an existing network such as cross-connections and interfaces – Configure external alarms and station alarms – Level 1 and 2 privileges
NMS10 Network Administrator	4	<ul style="list-style-type: none"> – Change node addresses – Install and uninstall nodes – Configure synchronisation – Edit the DCN network – Level 1, 2 and 3 privileges
System Administrator	5	<ul style="list-style-type: none"> – Manage access rights – Level 1, 2, 3 and 4 privileges

Table A-1 User access levels

The rest of this chapter is for system administrators only. It deals with features and procedures to which level 1–4 users do not have access.

Security administration

If you are a system administrator, you can:

- enable security when Eksos N20 Node Manager is installed
- set, raise, or lower a user’s access level.

You need to be familiar with Windows NT 4.0’s own security features in order to act as a system administrator for Eksos N20 Node Manager.

Enabling security at installation

You can enable security to control which users can make changes to the node. Other users will be given warning messages when they connect to a node and also if they try to send data to the node.

► To enable security:

When the setup program asks you whether you want security enabled, select **Enable Security** and click **Next>**.

Setting a user's access level

► To set a user's access level:

1. Click the **Start** button and select **Programs**→**Administrative Tools (Common)**→**User Manager**.
2. If you are adding a new user, select **New User...** from the **User** menu. If you want to change the access level of an existing user, select that user's name from the list.
3. Select **Properties...** from the **User** menu. Click **Groups**. The **Group Memberships** dialog box will be displayed as shown in Figure A-4. If you are adding a new user, the four user access levels will already be listed in the **Not member of** list box. If you are editing the access level of an existing user, their current user access level will be shown in the **Member of** list box.




Figure A-4 Group Memberships dialog box

4. If you are adding a new user, select the user access level which you want to assign from the **Not member of** list box and then click **<-Add**. Click **OK**.
5. If you are editing the access level of an existing user, select the current access level from the **Member of** list box and then click **Remove->**. Select the user access level which you want to assign from the **Not member of** list box and then click **<-Add**. Click **OK**.

A.1.6 Frequently asked questions

This section contains information on some of the more common problems which you may encounter during the installation procedure.

How much disk space does Eksos N20 Node Manager require?

If you do not have enough free disk space on your PC, it will not be possible to install Eksos N20 Node Manager. You need a minimum of 10 MB of free disk space. If necessary, consult your system administrator for advice.

What should I do when the Q3 stack is not running?

Use the **STACK configuration** tool to ensure that the Q3 stack is started when Windows NT 4.0 is rebooted.

What should I do if Eksos N20 Node Manager does not start?

If the installation was successful, but you cannot start Eksos N20 Node Manager, ensure that the Q3 stack is running, using **STACK configuration**.

How much RAM does Eksos N20 Node Manager require?

If you have less than 128 MB of RAM, Eksos N20 Node Manager may function more slowly or not at all. If you have 128 MB, but are running several programs at the same time, you will also experience performance problems. Add more memory or run Eksos N20 Node Manager on its own.

Where can I find information about installing an Ethernet LAN card?

An Ethernet LAN card and supporting software is required. Consult the installation instructions that came with your card for details on how to install and configure it.

What should I do if I want to install an older version of the software?

If the version number of the files that are being installed is older than the version of files they are replacing, then a dialog box will be displayed indicating that a newer version of the software has been found.

Click **Yes**, if you wish to continue with the installation. Click **No**, if you wish to stop the installation program. (Choosing this option will mean that only a partial installation has taken place.) Select **Exit** to exit completely from the installation program.

You can also remove your old program files from the NOKIAMGR directories by using **Delete** from Windows NT Explorer.

A.2 Using Eksos N20 Node Manager

This section describes the design and basic operation of Eksos N20 Node Manager, and how it can be used to manage an Eksos N20 node.

For instructions on how to configure and take into use an Eksos N20 node, see the main body of the document.

A.2.1 Description of Eksos N20 Node Manager

The **Eksos Node Manager** window is the window that first appears when you start Eksos N20 Node Manager. From this window, you can reach any other window in Node Manager. Your screen shows this window during the whole management session.

The **Subrack** window is permanently present in the application window (either as a window or iconised) when Eksos N20 Node Manager is connected to a node.




Figure A-5 Eksos Node Manager window showing the Subrack window

The **Subrack** window has many uses:

- It identifies the type of node Eksos N20 Node Manager is connected to.
- It shows the type of units present in the node.
- It shows where the units are in the subrack.
- It shows what units should be present and what units are actually present in the current node type.
- It shows the most severe current alarms on each unit.
- It is used to install new units in the subrack.
- It is used to select units for subsequent node management operations. (For more information on selecting units, refer to Section A.2.2.)





Icon	Associated command
	Node→Manage...
	Node→Stop Managing
	Data→Send to Node
	Data→Refresh from Node
	Data→Load from File
	Data→Save to File
	Monitor→Current Alarms
	Monitor→ Event History Log
	Monitor→Block Status
	Monitor→Current Performance
	Monitor→Performance History
	Configure→Synchronisation
	Configure→Leased Lines
	Configure→Man. and Aux. Channels
	Configure→V5 interfaces
	Configure→Interface Usage
	Window→Cascade
	Help→Contents

Table A-2 Toolbar icons in Eksos Node Manager window

A.2.2 Operating Eksos N20 Node Manager

Selecting actions

To use Eksos N20 Node Manager, you can use these two methods:

- select a slot and then an action
- select an action.

Select a slot and then select an action

To select a slot in the **Subrack** window, either:

- click on the slot, or
- use the left and right cursor keys. The selected slot will appear to protrude from the subrack. Select a menu item or just press the **Spacebar** when the correct slot is selected.

For example, if you want to configure an ISDN interface in a node, select the slot containing the ISDN you want to configure, and then select **Configure** → **Interfaces**. This displays the **Configure ISDNUQ Ux** window (x stands for the slot number where the unit is installed).

In another example, if you want to add a PSTN unit to a node, select the slot where you want to add the unit, and then select **Configure** → **Unit Type...** from the Menu bar. This displays the **Unit Type** dialog box enabling you to install the unit.

Select an action

Some options are always available from the Menu bar, irrespective of the selection status of the subrack units. For example, the **Current Alarms** window can always be displayed while a node is being managed.

To select an action, first select a command from the Menu bar. For example, to configure synchronisation, select **Configure** from the Menu bar, and then select **Synchronisation** from the **Configure** menu.

Selecting the default window for a slot

Double-clicking on any of the slots in the **Subrack** window opens the most appropriate (default) window for the slot.

For example, if you double-click an ISDN unit, Eksos N20 Node Manager assumes that you want to configure the interfaces on the ISDN unit and so displays the **Configure ISDN** window.

If you double-click an empty slot, Eksos N20 Node Manager assumes that you want to install a unit in the empty slot and so displays the **Unit Type** dialog box.

Receiving data from the node

Updating windows manually

Most windows can be manually updated by choosing the command **Data→Refresh from Node**. This command updates the data being displayed in the currently active window. The data is requested from the node and the window is updated with the new data received from the node.

The **Data→Refresh from Node** command is especially useful if you have edited a window (but have not yet sent the changes to the node) and want to return to the original configuration or setting which is currently present on the node. You could also use **Data→Undo**.

Updating windows dynamically

Block status, external alarms, current performance, and synchronisation status are regularly updated when **Categories that Poll by Default** is selected for a window. To view and set up dynamic updating of the options in the **Polling** tab, select **Node→Manager Options...**

In practice this means that whenever a new alarm occurs which changes any of the current alarm information shown in the windows, they are dynamically updated.

Making changes to the node

If the Node Manager's security system has been enabled, you can make changes to the node only if your system administrator has granted you a high enough user access level.

When you edit data obtained from the node, the changes which you can see on your screen are not immediately applied to the node. To put the changes into effect, you must send the edited data to the node, using the **Data→Send to Node** command. This command updates the node with the changed data currently being displayed in the active window.

A.2.3 Using online Help

Eksos N20 Node Manager contains an online Help system which provides you with help information about how to use all aspects of Eksos N20 Node Manager. Help information is available at any time when you are using Eksos N20 Node Manager.

The online Help can be accessed in two main ways:

- by choosing a command from the **Help** menu on the Menu bar
- by pressing F1.

For more information on using online Help, refer to the Windows NT user documentation.

A.2.4 Saving and loading data as files

You can use files for three purposes:

- for copying configurations from one node to another
- to use an existing configuration as the basis of a more complex configuration
- as a simple way of backing up configurations.

Saving the whole node

► To save the configuration details of the whole node:

1. Close all windows except the **Subrack** window.
2. Select **Data** → **Save to File...** The **Save Configuration Data** dialog box will be displayed. The **Save All** box is checked and all the other check boxes appear greyed out. Do not change these settings if you want to save the whole node.

If you only want to save part of the node configuration, check the boxes for the details which you want to save.





Figure A-6 Save Configuration Data dialog box

3. Click **OK**. The **Saving Configuration Data** window will be displayed.

When Node Manager has read all the data to be saved from the node, the **Saving Configuration Data** window will be closed and the **Save As** window will be displayed.

4. In the **Save As** window, enter a file name in the **File name** box. The file extension .SNM will be added automatically.

 **Caution**

You must enter a file name (or select an existing file name) before you enter a name in the **Last edited by** box. If you enter the name of the person editing the file first, this name will be deleted automatically when you choose the file name.

5. When the details in the **Save As** window are as you want them, click **Save**. The details of the configuration of the whole node have now been saved under the file name which you specified in Step 4.

Note

Some details of the node configuration are not saved, either because they must not be copied from one node to another (such as the System ID), or because they consist of short-term information (such as current alarms).

The details which are not saved are:

- System ID
- Software Settings
- Maintenance State
- Current Alarms
- Event History Log contents
- Real Time Clock
- Current Performance
- Performance History.

Saving data from a window

► To save the data in a window:

1. Open the configuration window whose data you want to save,
2. Edit the data, then select **Data** → **Send to Node**.
3. Select **Data** → **Save to File...** The **Save As** window will be displayed.
4. Carry out Steps 4. and 5. from 'Saving the whole node' procedure. The procedure is the same, except that you will have saved only the configuration data in the window which was open.

Saving data in a window as text

The **Data** → **Save As...** command allows you to save data from a window as text (.TXT file).

Loading a whole node configuration from file

You can load data from a file into a node which has already been installed.

► To load a whole node configuration from file:

1. Close all windows except the **Subrack** window.
2. Select **Data** → **Load from File...** The **Open** window will be displayed.
3. Select the file which you want and click **Open**. The **Node Information** dialog box will be displayed, which is the first dialog box of the **Whole Node Load Wizard**.
4. Change the name of the node in the **Name** edit box, and the location of the node in the **Location** edit box, if required.

This depends upon whether you are recreating a node, or copying or cloning another node.

5. Click **Next>**. The **Subrack Information** dialog box is displayed.
6. All the boxes in this window are read-only. Eksos N20 Node Manager enters the details for you automatically.
7. Click **Next>**. The **Node Address** dialog box is displayed.
8. Select a name for the area to which the node is to belong, from the **Name** drop-down list. If the area name which you want does not appear in the list, click **Search Database...** The **Select Area** dialog box will be displayed.

You can use the **Select Area** dialog box to add a new area or edit an existing area. When you have finished, click **OK** to return to the **Whole Node Load Wizard**.

9. Enter the System ID of the node in the **System ID** box.
10. Click **Next>**. The **Configuration Data** dialog box is displayed.
11. If you do not want to load all the details which were saved, clear the boxes for the data which you do not want.

You cannot choose not to load the Subrack details, so the **Subrack** box is always selected and greyed out. Any details which were not saved in the configuration are also greyed out.

12. When the details are as you want them, click **Finish**. The **Loading Configuration Data** window is displayed.

Eksos N20 Node Manager begins loading all the data from the file, starting with the Subrack details, and sends it to the node to which it is connected. When the data has been sent, the **Loading Configuration Data** window closes, and the **Subrack** window is displayed. The loading of the node configuration is now complete and the node is ready for use.

Loading a window configuration from file

- To load a configuration from file:
1. Open the window into which you want to load the configuration details.
 2. Select **Data** → **Load from File...** The **Open** window will be displayed.
 3. Select the configuration file which you want and click **Open**. The **Choose Block Type** window is displayed.
 4. Select the block type which you want. The block type must match the type of the window which is currently open.
 5. Click **OK**. The configuration will be loaded into the window.
 6. Select **Data** → **Send to Node**.

A.2.5 Printing data

The contents of every document window displayed by Eksos N20 Node Manager can be printed by choosing **Data** → **Print**. This command sends the contents of the window to the DEFAULT printer, as configured by the Windows Print Manager.

For best performance, we recommend that you select the **Generic/Text Only** printer, and that you set the character width to 80 characters.

It is always useful to have a copy of some of the most important configuration data of the node for reference, in case anything happens to the node causing a loss of information.

The window data is printed out in a non-paginated form.

At the start of the printout, the following information is printed:

- the name of the node currently being managed
- the title of the window being printed
- the date and time the data was printed (read from the computer).

A.2.6 Frequently asked questions

What should I do if I change my mind after selecting an operation?

Some operations can be aborted before they finish by clicking on the **Abort** button.

Clicking on the **Abort** button will cause the operation to stop communicating with the node. The progress indicators will be removed and the window will be displayed again.

If you have edited a window (but have not yet sent the changes to the node) and want to return to the original configuration or setting which is currently present on the node, you can use **Data**→**Undo**.

What should I do if I cannot connect to node?

If the installation was successful, but you cannot connect to a node:

- Ensure that the node is connected to the PC's Ethernet port.
- Ensure that the node is switched on and operational, and that the PC's Ethernet is installed correctly.
- Ensure that you have defined a valid NSAP address for the PC. Note that the PC must have the same area address as the node to which you want to connect.

What happens if there is a communications failure?

When a communications failure occurs between the node and the computer, the **Data** → **Send to Node** and **Data** → **Refresh from Node** commands, and all the other commands which depend on access to the node, will be disabled until communication with the node is re-established.

If a communications failure occurs while you are communicating with the node (for example, sending information to a node, or reading information from a node), the operation will be terminated. Once the node has established connection again, you can then repeat the operation.

If the connection between the computer and the node fails for some reason, Eksos N20 Node Manager will automatically make one attempt to reconnect to the node.

The system will keep trying to reconnect to the node unless you click **Stop trying**.

What should I do if Node Manager finds no nodes?

If, after installation, there are no nodes displayed in the **Select Node** dialog box, the Q3 stack may not have been installed. Refer to the instructions on installing the Q3 stack and setting the NSAP address. You can also try stopping and restarting the stack. Also check the Ethernet connection.

A.2.7 Main menus of Eksos N20 Node Manager




Figure A-7 Main menus of Eksos N20 Node Manager

Appendix B

Alarm messages

The tables below list the alarms detected by Eksos N20 and show how the Eksos N20 nodes react to the alarms. Each table also gives a short description of the fault generating the alarm and provides some guidelines on how to rectify the fault.

The alarms are presented in alphabetical order according to the long alarm names. The alarm tables give the following information:

- **Table row** shows the long alarm name and also, in parentheses, the short name.
- **Severity** shows the severity class of the alarm as it appears in the Node Manager.
- **Unit** shows the plug-in unit indicating the alarm.
- **Block** shows the functional block indicating the alarm.
- **Type** shows the alarm type.
- **Consequence** shows whether an indication signal is sent upstream or downstream.
- **Meaning** gives the possible cause of the alarm.
- **Instructions** give instructions on how to rectify the fault.
- **Cancelling** gives instructions on how the alarm can be cancelled.

Alarm Indication Signal (2M-AIS)		
Severity: Warning	Unit: NCU, TR2M4	Block: E12/P12_A
Type: Communications	Consequence: AIS downstream, RDI	
Meaning: The incoming 2 Mbit/s signal is the AIS. The equipment indicating this alarm is not faulty, but the alarm is a consequence of a serious fault somewhere else in the network. This alarm does not show on the Current Alarms List; it is only displayed in the Block Status windows.		
Instructions: Locate the fault that is causing the AIS to be sent from the other end.		
Cancelling: The alarm is cancelled automatically when AIS disappears.		

Alarm Input		
Severity: Programmable	Unit: NCU; LMU	Block: Common
Type: Environment	Consequence: –	
Meaning: One of the programmable alarm inputs on either NCU or LMU has been activated. The alarm text and severity are defined by the user.		
Instructions: –		
Cancelling: The alarm is cancelled automatically when the fault is rectified.		

Alarm List Incomplete		
Severity: Minor	Unit: NCU	Block: Common
Type: Processing	Consequence: –	
Meaning: The alarm list cannot show all the active alarms due to the limited size of the alarm display stack. This message appears as the last item on the alarm list.		
Instructions: –		
Cancelling: –		

Backup Fail (BKUP)		
Severity: Major	Unit: NCU; ISDN; LMU	Block: Common
Type: Equipment	Consequence: –	
Meaning: Configuration data has been lost. If one plug-in unit is removed from the subrack and the same type of plug-in unit is inserted into the same slot, all functions will normally return to the unit without any additional actions from the user. However, a Backup Fail alarm may occur when several plug-in units are drawn away and then replaced with new, identical plug-in units.		
Instructions: Do not replace units while the yellow LED on the NCU is flashing. If the configuration data is lost, the units can be reconfigured using the back-up files.		
Cancelling: The alarm is cancelled automatically after 5 minutes.		

BCC Protocol Syntax Error (SYNT)		
Severity: Warning	Unit: NCU	Block: V5
Type: Communications	Consequence: –	
Meaning: A BCC (Bearer Channel Connection) protocol message field contains syntactically incorrect information. This alarm is shown in the event history log only.		
Instructions: –		
Cancelling: The alarm is cancelled automatically.		

Cessation of Flags on a C-channel (CCH)		
Severity: Minor	Unit: NCU	Block: V5-P0
Type: Communications	Consequence: –	
Meaning: Physical C-channels carry the transmit flag '0111 1110' when not transmitting L3 information. If this flag is not transmitted within 1 second, this alarm is generated.		
Instructions: Check that the C-channels are configured identically in the AN and LE. Also check that there is a 64k physical C-channel connection between the AN and LE.		
Cancelling: The alarm is cancelled automatically.		

Compatibility Failure (CMPF)		
Severity: Major	Unit: All	Block: Common
Type: Equipment	Consequence: –	
Meaning: The release of the unit software is not compatible with the node release currently in use. The unit is switched off (transmission is cut and no settings can be made, functionally the same as a Unit Mismatch). This alarm can also be raised if the unit hardware is incompatible with the software.		
Instructions: Download a new, compatible software to the node or change the unit hardware version.		
Cancelling: The alarm is cancelled automatically when the software or hardware is changed to compatible one.		

Control Protocol Syntax Error (SYNT)		
Severity: Warning	Unit: NCU	Block: V5
Type: Communications	Consequence: –	
Meaning: A Control protocol message field contains syntactically incorrect information. This alarm is shown in the event history log only.		
Instructions: –		
Cancelling: The alarm is cancelled automatically.		

Control Protocol Time Out (TOUT)		
Severity: Warning	Unit: NCU	Block: V5
Type: Communications	Consequence: –	
Meaning: Indication that a time-out error has occurred in Common Control protocol. This alarm is shown in the event history log only.		
Instructions: –		
Cancelling: The alarm is cancelled automatically.		

Critical Fan Failure (FAN)		
Severity: Critical	Unit: NCU	Block: Common
Type: Equipment	Consequence: –	
Meaning: Two or more fans of the Fan Unit have stopped working and hence correct operating temperature cannot be provided.		
Instructions: First check the fuses on the subrack's extension board. If the fuse has not blown, replace the broken Fan Unit with a working one.		
Cancelling: The alarm is cancelled automatically when the broken fan is replaced.		

Degraded Signal (DEG)		
Severity: Minor	Unit: NCU, TR2M4	Block: E12
Type: Communications	Consequence: –	
Meaning: Degraded incoming 2 Mbit/s signal (error ratio above 10^{-6}). This failure does not cut the service but its quality is decreased.		
Instructions: Check if there is a fault in the repeater or if the cable is faulty and generating disturbances on the 2M line.		
Cancelling: The alarm is cancelled automatically when the error ratio decreases below 10^{-7} .		

Degraded Signal (DEG)		
Severity: Minor	Unit: ISDN	Block: ISDN
Type: Communications	Consequence: –	
Meaning: Corrupted CRCs received. This failure does not cut the service but its quality is decreased.		
Instructions: Check if the ISDN subscriber cable is faulty and generating disturbances on the line.		
Cancelling: The alarm is cancelled when the error ratio decreases below 10^{-7} .		

Dying Gasp (GSP)		
Severity: Minor	Unit: ISDN	Block: NT
Type: Equipment	Consequence: AIS upstream	
Meaning: Both primary power and secondary power (if back-up battery is provided) on the NT are marginal or have failed. Voltage at the T-reference point is less than 34 V or reserved. The NT1 is likely to cease operation.		
Instructions: Check the operation of power supply both to the ISDN unit and the NT.		
Cancelling: The alarm is cancelled automatically when power is supplied again.		

Event Buffer Overflow (EBOF)		
Severity: Minor	Unit: NCU	Block: Node
Type: Processing	Consequence: –	
Meaning: This alarm is raised when the event buffer is full and new events are raised. The event buffer is used as a temporary store for events before they are sent to the registered user. This alarm does not show on the Current Alarms List; it is only displayed on the Event History Log.		
Instructions: –		
Cancelling: The alarm is cancelled manually by clearing the log or when EFD (Event Forwarding Discriminator) has sent all alarms to the NMS.		

Excessive Bit Error Ratio (EXC)		
Severity: Major	Unit: NCU, TR2M4	Block: W12
Type: Communications	Consequence: AIS downstream, RDI	
Meaning: Too many bit errors (error ratio above 10^{-3}) in the incoming 2 Mbit/s signal. This failure causes the quality of service to decrease so badly that the service cannot be used any more.		
Instructions: Check if there is a fault in the repeater or if the cable is faulty and generating disturbances on the 2M line.		
Cancelling: The alarm is cancelled automatically when error ratio decreases to approx. 10^{-4} .		

Fan Failure (FAN)		
Severity: Minor	Unit: NCU	Block: Common
Type: Equipment	Consequence: –	
Meaning: One of the six fans in the Fan Unit has stopped working.		
Instructions: Replace the broken Fan Unit with a working one.		
Cancelling: The alarm is cancelled automatically when the broken fan is replaced.		

Far End Block Error (FEBE)		
Severity: Minor	Unit: ISDN	Block: –
Type: Communications	Consequence: –	
Meaning: The far-end receiver is receiving errored blocks (i.e. corrupted CRCs).		
Instructions: Check if the cable is faulty and generating disturbances on the line.		
Cancelling: The alarm is cancelled automatically when a valid signal is received.		

Feeding Current Shortcut (FPS)		
Severity: Minor	Unit: ISDN	Block: –
Type: Equipment	Consequence: –	
Meaning: Interface-specific alarm.		
Instructions: Locate the short circuit or earth leakage in the cable or connection.		
Cancelling: The alarm is cancelled automatically when the short circuit is removed.		

Feeding Power Overload (FPO)		
Severity: Minor	Unit: ISDN	Block: –
Type: Equipment	Consequence: –	
Meaning: Unit-level alarm indicating that there is an overload on the power supply feeding the ISDN lines.		
Instructions: Check if the overload on the line is caused, for example, by an earth leakage or a wrong type of NT.		
Cancelling: The alarm is cancelled automatically when the overload is removed.		

Feeding Power Supply Failure (FPSF)		
Severity: Critical	Unit: ISDN	Block:
Type: Equipment	Consequence: –	
Meaning: There is a problem with the voltage supply of the unit. The measured voltage in the unit differs more than 5% from the selected value.		
Instructions: Set the voltage to 0 V and then back to the original value. If this does not clear the alarm, replace the unit with a new one.		
Cancelling: The alarm is cancelled automatically when the voltage is back to the allowed range.		

Feeding Voltage Failure (FVF)		
Severity: Minor	Unit: ISDN	Block: –
Type: Equipment	Consequence: –	
Meaning: Interface-specific alarm indicating that there is no power supply available.		
Instructions: Check if the cable is faulty and causing a short circuit. Also check the power supply on the ISDN unit: if it is faulty, replace the ISDN unit.		
Cancelling: The alarm is cancelled automatically when the power supply is available.		

General Problem DNT (GPD)		
Severity: Minor	Unit: ISDN	Block:
Type: Communications	Consequence: –	
Meaning: Indicates a far-end alarm from the DNT128 unit that is connected to an ISDN port.		
Instructions: Check the alarms in the DNT128 by using the Q1 management tool. Make sure that the DNT128 is not in test mode.		
Cancelling: The alarm is cancelled automatically as soon as the DNT128 is working again.		

Input Buffer Overflow/Underflow (IBOU)		
Severity: Warning	Unit: DIU	Block:
Type: Communications	Consequence: –	
Meaning: Indicates that there is a synchronisation problem. There are two counters that log input buffer over- and underflows and two specified thresholds. If there are more input over- or underflow errors per minute than has been specified with the respective thresholds, the alarm is raised. The Input Buffer Underflow alarm is also raised in case of an external clock failure. The alarms are raised only if the buffer slip reported attribute is set to true.		
Instructions: –		
Cancelling: The alarm is cancelled automatically when the number of input over- and underflow errors drops to the specified acceptable level.		

In Test (TEST)		
Severity: Major	Unit: NCU, TR2M4	Block: E12
Type: Equipment	Consequence: AIS upstream or downstream	
Meaning: The 2 Mbit/s interface has been looped with the Node Manager.		
Instructions: The loopbacks are used for troubleshooting. The loopbacks are automatically cancelled after a preset time-out, or you can cancel them immediately with a Node Manager command.		
Cancelling: The alarm is cancelled automatically when the test state ends.		

In Test (TEST)		
Severity: Major	Unit: DIU	Block:
Type: Equipment	Consequence: AIS upstream or downstream	
Meaning: The DIU interface has been looped with the Node Manager.		
Instructions: The loopbacks are used for troubleshooting. The loopbacks are automatically cancelled after a preset time-out, or you can cancel them immediately with a Node Manager command.		
Cancelling: The alarm is cancelled automatically when the test state ends.		

Interface Broken (PBKN)		
Severity: Major	Unit: PSTN	Block:
Type: Equipment	Consequence: –	
<p>Meaning: This alarm can mean two different alarm cases. If the alarm is given right after the start-up (within a few minutes after the POTS unit reset), one of the SLICs is broken. If the alarm is given during normal operation, there is a current leakage from wire a/b to ground (fault in the subscriber line).</p>		
<p>Instructions: If a SLIC is broken, the PSTN unit must be replaced. If there is a current leakage, the fault in the subscriber line must be corrected.</p>		
<p>Cancelling: The alarm is cancelled automatically when the unit is replaced with a new one (in case of a broken SLIC), or after the fault in the subscriber line has been cleared.</p>		

Link Control Protocol Syntax Error (SYNT)		
Severity: Warning	Unit: NCU	Block: V5–P12
Type: Communications	Consequence: –	
<p>Meaning: A Link Control protocol message field contains syntactically incorrect information. This alarm is shown in the event history log only.</p>		
<p>Instructions: –</p>		
<p>Cancelling: The alarm is cancelled automatically.</p>		

Link Control Protocol Time Out (TOUT)		
Severity: Warning	Unit: NCU	Block: V5–P12
Type: Communications	Consequence: –	
<p>Meaning: Indication that a time-out has occurred in Link Control Protocol. This alarm is shown in the event history log only.</p>		
<p>Instructions: –</p>		
<p>Cancelling: The alarm is cancelled automatically.</p>		

Log Overflow (LGOF)		
Severity: Minor	Unit: NCU	Block: Node
Type: Processing	Consequence: –	
<p>Meaning: Event history log overflow in the network element.</p>		
<p>Instructions: Clear the log (and, if applicable, change the log file settings so that new alarms are written over the old ones when the log gets full).</p>		
<p>Cancelling: The alarm is cancelled automatically when the problem is cleared in the node.</p>		

Loss of Frame (LOF)		
Severity: Major	Unit: NCU, TR2M4	Block: E12/P12
Type: Communications	Consequence: AIS downstream, RDI	
Meaning: Loss of frame in the incoming 2M signal (G.704). This failure causes the quality of service to decrease so badly that the service cannot be used any more.		
Instructions: Check if there is a fault in the repeater or if the cable is faulty and generating disturbances on the 2M line.		
Cancelling: The alarm is cancelled automatically when a valid frame is received.		

Loss of Frame (LOF)		
Severity: Minor	Unit: ISDN	Block: –
Type: Communications	Consequence: AIS upstream	
Meaning: Loss of frame in the ISDN signal.		
Instructions: Check if the cable is faulty and generating disturbances on the line.		
Cancelling: The alarm is cancelled automatically when a valid frame is received.		

Loss of Multiframe (LOM)		
Severity: Major	Unit: NCU, TR2M4	Block: E12/P12
Type: Communications	Consequence: RDI	
Meaning: Loss of multiframeframe in the ISDN signal.		
Instructions: Make sure that the remote end has been correctly configured.		
Cancelling: The alarm is cancelled automatically when a valid multiframe is received.		

Loss of Octet Timing (LOT)		
Severity: Minor	Unit: DIU	Block:
Type: Communications	Consequence: –	
Meaning: Octet timing is lost. This alarm concerns G.703 and X.21 interfaces only.		
Instructions: –		
Cancelling: The alarm is cancelled automatically when valid timing is received.		

Loss of V.110 Frame Synchronisation (LOFS)		
Severity: Major	Unit: DIU	Block:
Type: Communications	Consequence: –	
Meaning: Raised when V.110 Frame synchronisation is no longer detected. This causes a transition from Data Transfer State to Frame search State and further to Disconnect State. The alarm will be reported only if the V.110LOFVS Reported attribute has been set.		
Instructions: –		
Cancelling: –		

Loss of Signal (2M-LOS)		
Severity: Major	Unit: NCU, TR2M4	Block: E12
Type: Communications	Consequence: AIS downstream, RDI	
Meaning: This alarm indicates the loss of signal at 2 Mbit/s input.		
Instructions: Check if the 2M cable is broken, or if the repeater or transmitter are defective.		
Cancelling: The alarm is cancelled automatically when 2M signal is returned to the input.		

Loss of Signal (LOS)		
Severity: Major	Unit: NCU	Block: T12S1R
Type: Communications	Consequence: –	
Meaning: Loss of 2M synchronisation signal		
Instructions: Check if the synchronisation source has failed or if the cable is faulty.		
Cancelling: The alarm is cancelled automatically when a valid signal is received.		

Loss of Signal (LOS)		
Severity: Minor	Unit: ISDN	Block: –
Type: Communications	Consequence: AIS upstream	
Meaning: This indicates that no signal is being received by the receiver.		
Instructions: Check if the cable is broken or if the NT is missing.		
Cancelling: The alarm is cancelled when the signal is returned to the input.		

Loss of Signal (LOS)		
Severity: Minor	Unit: DIU	Block:
Type: Communications	Consequence: –	
Meaning: A signal is missing from an interface. The alarm is typically raised if no signal is connected to a Vxx/X.21 or G.703 interface.		
Instructions: Check if the cable is broken or if the DTE is missing		
Cancelling: The alarm is cancelled when the signal is returned to the input.		

Loss of Timing Information (LTI)		
Severity: Major	Unit: NCU	Block: SD/NS-SEL
Type: Equipment	Consequence: –	
Meaning: Generated when the associated 2 Mbit/s termination point has failed or no reference signal is connected to the node clock reference, that is, the node clock is in free-running or holdover mode. (This alarm is not generated if the internal clock has been defined as the only source for the node clock.)		
Instructions: Check if the synchronisation source has failed or if the cable is faulty.		
Cancelling: The alarm is cancelled automatically when a valid signal is received.		

Loss of Timing Information (LTI)		
Severity: Major	Unit: NCU	Block: SDINS-SEL
Type: Equipment	Consequence: –	
Meaning: Loss of external synchronisation source. Generated for external 2 MHz / 2 Mbit/s synchronisation output when the associated 2 MHz / 2 Mbit/s termination point has failed or no reference signal is connected to the node clock reference. (Generated only for interfaces that are on the synchronisation priority list.)		
Instructions: Check if the synchronisation source has failed or if the cable is faulty.		
Cancelling: The alarm is cancelled automatically when a valid signal is received.		

Maintenance State (MAIN)		
Severity: Minor	Unit: NCU	Block: Common
Type: Equipment	Consequence: –	
Meaning: The node has been set into maintenance state. Use this state to notify the network management system that you are going to perform some planned maintenance actions (for example, upgrading the software), and that some alarms will probably be generated.		
Instructions: After you have finished the maintenance actions, set the maintenance state off.		
Cancelling: The alarm is cancelled automatically when maintenance state is removed.		

Port Control Protocol Layer 3 Address Error (SYNT)		
Severity: Configurable as Non-alarmed or Warning	Unit: NCU (V5.2), TR2M (V5.1)	Block: V5
Type: Communication	Consequence: –	
Meaning: A mismatch in layer 3 addresses between the AN and LE (V5.2) or between the AN and the V5.1 equipment. Indicates that an L3 address has been received that has not been given to any existing PSTN or ISDN user port.		
Instructions: Check that the L3 addresses are correct.		
Cancelling: The alarm is cancelled automatically when the fault is rectified.		

Power Problem (POW)		
Severity: Critical	Unit: All	Block: Common
Type: Equipment	Consequence: AIS	
Meaning: The power supply block of the unit does not function correctly or the power supply is overloaded. If the plug-in unit is not identified, the alarm is generated on the NCU. The fault can relate to power supply adapters, batteries, or plug-in unit power blocks. The DC-PSA alerts with an A-alarm if the power supply of a plug-in unit fails.		
Instructions: Check to see if there is a short circuit which is overloading the power supply. If the power supply or a plug-in unit is faulty, replace it with a working one.		
Cancelling: The alarm is cancelled automatically when the fault is rectified.		

Primary Power Out (PPO)		
Severity: Minor	Unit: ISDN	Block: PISDNUBA
Type: Equipment	Consequence: –	
Meaning: Primary power on the NT is marginal or has failed. Secondary power (if back-up battery is provided) is normal. Voltage at the T-reference point is less than 34 V or reserved.		
Instructions: ISDN line feeding has failed or the cable is broken.		
Cancelling: The alarm is cancelled automatically when power is supplied again.		

Protection Protocol Syntax Error (SYNT)		
Severity: Warning	Unit: NCU	Block: V5
Type: Communications	Consequence: –	
Meaning: A Protection protocol message field contains syntactically incorrect information. This alarm is shown in the event history log only.		
Instructions: –		
Cancelling: The alarm is cancelled automatically.		

Protection Protocol Time Out (TOUT)		
Severity: Warning	Unit: NCU	Block: V5
Type: Communications	Consequence: –	
Meaning: Indication that a time-out error has occurred in Protection protocol. This alarm is shown in the event history log only.		
Instructions: –		
Cancelling: The alarm is cancelled automatically.		

Q1 Not Supported (Q1NS)		
Severity: Major	Unit: ISDN	Block: Common
Type: Equipment	Consequence: –	
Meaning: If an ISDN user port is configured for DNT128 usage (Q1 management over the D-channel), the C2.0 hardware is required. In case the ISDN unit is replaced with C1.0 hardware, this alarm appears to indicate that Q1 management is not possible.		
Instructions: Replace the ISDN unit with a unit containing the C2.0 hardware.		
Cancelling: The alarm is cancelled automatically.		

Remote Defect Indication (2M-RDI)		
Severity: Warning	Unit: NCU, TR2M4	Block: P12_TT
Type: Communications	Consequence: –	
Meaning: 2M Remote Defect Indication. The remote path termination has detected a fault in the incoming 2M signal. The equipment indicating this alarm is not faulty, but the alarm is a consequence of a serious fault elsewhere in the network. This alarm does not show on the Current Alarms List; it is only displayed in the Block Status windows.		
Instructions: Locate the fault that is causing the RDI to be sent from the remote end.		
Cancelling: The alarm is cancelled automatically when a valid signal is received.		

Remote Power Feeding Unit Overload (RPFO)		
Severity: Minor	Unit: ISDN	Block: Common
Type: Equipment	Consequence: –	
Meaning: Indicates that the actual drawn power of all interfaces is bigger than the configured power of all interfaces.		
Instructions: If the alarm is permanent, reconfigure the unit (the maximum power for each interface).		
Cancelling: The alarm is cancelled automatically.		

Restart Time Out (TOUT)		
Severity: Warning	Unit: NCU	Block: V5
Type: Communications	Consequence: –	
Meaning: Indication that a time-out has occurred in the PSTN restart. The PSTN restart has failed. This alarm is shown in the event history log only.		
Instructions: –		
Cancelling: The alarm is cancelled automatically.		

Secondary Power Out (SPO)		
Severity: Minor	Unit: ISDN	Block: PISDNUBA
Type: Equipment	Consequence: –	
Meaning: Primary power on the NT is normal, but the secondary power (if back-up battery is provided) is marginal, unavailable or has failed. Normal power is provided at the T-reference point.		
Instructions: Check if the NT has been accidentally disconnected.		
Cancelling: The alarm is cancelled automatically when power is supplied again.		

Server Signal Fail (2M-SSF)		
Severity: Warning	Unit: NCU, TR2M4	Block: P12_TT
Type: Communications	Consequence: AIS downstream, RDI	
Meaning: 2M Server Signal Failed. There is a severe fault upstream, e.g., 2M-LOS. This alarm does not show on the Current Alarms List; it is only displayed in the Block Status windows.		
Instructions: Locate the fault that is causing the SSF to be sent from the remote end.		
Cancelling: The alarm is cancelled automatically when a valid signal is received.		

Signalling Voltage Failure (SVF)		
Severity: Major	Unit: PSTN	Block:
Type: Equipment	Consequence:	
Meaning: +70 V, –70 V, –36 V and SV1 voltage failure.		
Instructions: If the alarm persists, replace the PSTN unit with a new one.		
Cancelling: The alarm is cancelled automatically when the fault has been rectified.		

Startup Failure (STP)		
Severity: Major	Unit: NCU	Block: V5
Type: Communications	Consequence: –	
Meaning: The V5 interface has not started up. The reason may be, for example, failures in the physical layer, a V5 configuration mismatch between the AN and LE, or the other end may not yet be ready to start the interface.		
Instructions: Check the configuration.		
Cancelling: The alarm is cancelled automatically when the interface starts up.		

Synchronisation Forced (FORC)		
Severity: Minor	Unit: NCU	Block: NS_C
Type: Equipment	Consequence: –	
Meaning: The node has been forced to use one of the signals on the synchronisation priority list.		
Instructions: –		
Cancelling: The alarm is cancelled automatically when the forced state is removed.		

Threshold Crossed (THC)		
Severity: Warning	Unit: LMU	Block:
Type: Quality of Service	Consequence: –	
Meaning: Indicates the first threshold violation of measured line values during a scheduled test round of a scheduled test.		
Instructions: Read the test results to find the problematic interfaces. According to the test results, take appropriate actions to resolve the problem(s)		
Cancelling: This alarm is sent as an event and cannot be cancelled. If all indicated problems have been solved, the alarm will not be raised again during the next scheduled test round.		

Time-out Activation Error (TAE)		
Severity: Major	Unit: ISDN	Block:
Type: Communications	Consequence: –	
Meaning: This alarm is raised if a leased line is configured and it is not possible to keep the line permanently active.		
Instructions: Make sure the line is OK. Check if the NT is connected. Make sure that the interface has been configured correctly, especially that the feeding voltage is correct.		
Cancelling: The alarm is cancelled automatically.		

Unit Failure (FAIL)		
Severity: Critical	Unit: NCU; ISDN; LMU	Block: Common
Type: Equipment	Consequence: AIS	
Meaning: A hardware failure has been detected.		
Instructions: Replace the faulty unit with a working one.		
Cancelling: The alarm is cancelled automatically when the failed unit is replaced.		

Unit Mismatch (MISM)		
Severity: Critical	Unit: All	Block: Common
Type: Equipment	Consequence: AIS	
Meaning: A wrong type of plug-in unit has been inserted into a unit slot, or a unit has been inserted into a slot which was not expecting a unit.		
Instructions: Install an expected unit to the slot that is causing the alarm.		
Cancelling: The alarm is cancelled automatically when a correct unit is installed.		

Unit Missing (MISS)		
Severity: Critical	Unit: All	Block: Common
Type: Equipment	Consequence: AIS	
Meaning: A plug-in unit is not present in its slot in the subrack. This alarm may also indicate that the communication between an NCU and a plug-in unit is not working.		
Instructions: Install the missing unit.		
Cancelling: The alarm is cancelled automatically when the unit is installed.		

V5 BCC Protocol Data Link Failure (DLF)		
Severity: Critical	Unit: NCU	Block: V5
Type: Communications	Consequence: –	
Meaning: Initialisation of LAPV5-DL fails for BCC (Bearer Channel Connection) protocol. Communication with BCC protocol between the AN and LE is not possible.		
Instructions: –		
Cancelling: The alarm is cancelled automatically.		

V5 BCC Protocol Time Out (TOUT)		
Severity: Warning	Unit: NCU	Block: V5
Type: Communications	Consequence: –	
Meaning: Indication that a time-out has occurred in BCC (Bearer Channel Connection) protocol. This alarm is shown in the event history log only.		
Instructions: –		
Cancelling: The alarm is cancelled automatically.		

V5 Common Control Protocol Syntax Error (SYNT)		
Severity: Warning	Unit: NCU, TR2M4	Block: V5
Type: Communication	Consequence: –	
Meaning: Indicates that a control protocol message with syntactically incorrect information is received. The alarm is shown in the event history log only.		
Instructions: –		
Cancelling: The alarm is cancelled automatically.		

V5 Control Protocol Data Link Failure (DLF)		
Severity: Critical	Unit: NCU	Block: V5
Type: Communications	Consequence: –	
Meaning: Initialisation of LAPV5-DL fails for Control protocol. Communication with Control protocol between the AN and LE is not possible.		
Instructions: –		
Cancelling: The alarm is cancelled automatically.		

V5 Link Control Protocol Error while “Out Of Service” (PROT)		
Severity: Warning	Unit: NCU	Block: V5–P12
Type: Communications	Consequence: –	
Meaning: Generated when a Link Control message is received from the LE when the Link Control L3 protocol entity in the AN is not ready to receive any messages. This alarm is shown in the event history log only.		
Instructions: –		
Cancelling: The alarm is cancelled automatically.		

V5 Link Control Protocol Layer 3 Address Error (L3AD)		
Severity: Warning	Unit: NCU	Block: V5
Type: Communications	Consequence: –	
Meaning: A mismatch in link IDs between the AN and LE. Indicates that an unknown link ID has been received. Each 2M link must have a unique ID and the IDs between AN and LE must match. This alarm is shown in the event history log only.		
Instructions: Check that the link IDs are identical in the AN and LE.		
Cancelling: The alarm is cancelled automatically.		

V5 Link Control Protocol Data Link Failure (DLF)		
Severity: Critical	Unit: NCU	Block: V5
Type: Communications	Consequence: –	
Meaning: Initialisation of LAPV5-DL fails for Link Control protocol. Communication with Link Control protocol between the AN and LE is not possible.		
Instructions: –		
Cancelling: The alarm is cancelled automatically.		

V5 Link Identification Failure (LID)		
Severity: Major	Unit: NCU	Block: V5–P12
Type: Communications	Consequence: –	
Meaning: Indicates that the V5 link identification check has failed.		
Instructions: Check the following points: (1) the link IDs are identical in the AN and LE, (2) link identification has not been disabled at the LE end, (3) TS0 has been connected transparently between the AN and LE.		
Cancelling: The alarm is cancelled automatically.		

V5 Persistent Link Control Protocol Layer 3 Address Error (L3AD)		
Severity: Warning	Unit: NCU	Block: V5
Type: Communications	Consequence: –	
Meaning: A mismatch in link IDs between the AN and LE. Indicates that an unknown link ID has been received. Each 2M link must have a unique ID and the IDs between AN and LE must match. This alarm is shown in the event history log only.		
Instructions: Check that the link IDs are identical in the AN and LE.		
Cancelling: The alarm is cancelled automatically.		

V5 Port Control Protocol Error while “Out of Service” (PROT)		
Severity: Warning	Unit: NCU, TR2M4	Block: V5
Type: Communication	Consequence: –	
Meaning: A port control message is received for a user port that is out of service. The alarm is shown in the event history log only.		
Instructions: –		
Cancelling: The alarm is cancelled automatically.		

V5 Port Control Protocol Layer 3 Address Error (L3AD)		
Severity: Warning	Unit: NCU	Block: V5
Type: Communications	Consequence: –	
Meaning: A mismatch in user ports between the AN and LE. Indicates that an unknown user port address has been received. Each user port must have a unique address and the addresses between the AN and LE must match. This alarm is shown in the event history log only.		
Instructions: Check that the user port addresses are identical in the AN and LE.		
Cancelling: The alarm is cancelled automatically.		

V5 Port Control Protocol Timer Expiration Error (TOUT)		
Severity: Warning	Unit: NCU, TR2M4	Block: V5
Type: Communication	Consequence: –	
Meaning: Indicates that a time-out error has occurred in V5 port control. The alarm is shown in the event history log only.		
Instructions: –		
Cancelling: The alarm is cancelled automatically.		

V5 Port Control Protocol Syntax Error (SYNT)		
Severity: Warning	Unit: NCU	Block: V5
Type: Communications	Consequence: –	
Meaning: A Port Control protocol message field contains syntactically incorrect information. This alarm is shown in the event history log only.		
Instructions: –		
Cancelling: The alarm is cancelled automatically.		

V5 Protection Protocol Data Link Failure (DLF)		
Severity: Critical	Unit: NCU	Block: V5
Type: Communications	Consequence: –	
Meaning: Initialisation of LAPV5-DL fails for Protection protocol. Communication with Protection protocol between the AN and LE is not possible.		
Instructions: –		
Cancelling: The alarm is cancelled automatically.		

V5 Protection Protocol Timer Expiration Error (TOUT)		
Severity: Warning	Unit: NCU	Block: V5
Type: Communication	Consequence: –	
Meaning: Indicates that a time-out has occurred in the protection protocol. The alarm is shown in the event history log only.		
Instructions: –		
Cancelling: The alarm is cancelled automatically.		

V5 Protection Protocol Syntax Error (SYNT)		
Severity: Warning	Unit: NCU	Block: V5
Type: Communication	Consequence:	
Meaning: Indicates that a protection protocol message with syntactically incorrect information is received. The alarm is shown in the event history log only.		
Instructions: –		
Cancelling: The alarm is cancelled automatically.		

V5 PSTN Protocol Data Link Failure (DLF)		
Severity: Major	Unit: NCU	Block: V5
Type: Communications	Consequence: –	
Meaning: Initialisation of LAPV5-DL fails for PSTN protocol. Communication with PSTN protocol between the AN and LE is not possible.		
Instructions: Check that the C-channel configuration for PSTN is identical in the AN and LE.		
Cancelling: The alarm is cancelled automatically.		

V5 PSTN Protocol Layer 3 Address Error (L3AD)		
Severity: Warning	Unit: NCU	Block: V5
Type: Communications	Consequence: –	
Meaning: A mismatch in user ports between the AN and LE. Indicates that an unknown user port address has been received. Each user port must have a unique address and the addresses between the AN and LE must match. This alarm is shown in the event history log only.		
Instructions: Check that the user port addresses are identical in the AN and LE.		
Cancelling: The alarm is cancelled automatically.		

V5 PSTN Protocol Syntax Error (SYNT)		
Severity: Warning	Unit: NCU, TR2M4	Block: V5
Type: Communication	Consequence: –	
Meaning: Indicates that a PSTN protocol message with syntactically incorrect information is received. The alarm is shown in the event history log only.		
Instructions: –		
Cancelling: The alarm is cancelled automatically.		

V5 PSTN Protocol Time Out (TOUT)		
Severity: Warning	Unit: NCU	Block: V5
Type: Communications	Consequence: –	
Meaning: Indicates that a time-out error has occurred in V5 Port Control protocol. This alarm is shown in the event history log only.		
Instructions: –		
Cancelling: The alarm is cancelled automatically.		

Appendix C

Windows for Data Interface Units

C.1 Subrack window

The subrack window shows the type of the DIU unit, which can be either DIU-GG, DIU-VV or DIU-VG.

C.2 Unit configuration window

Double-clicking on the DIU unit in the subrack view (or using the **Configure** -> **Interface** menu with the DIU unit selected) leads to the **Unit configuration** window:




Figure C-1 Unit configuration window

Functional blocks

In the **Unit Configuration** window, only one functional block is shown for each DIU interface.

The interface text is **Out of use** (that is, not in use by the cross-connect), **Leased Line** (that is, in use by the cross-connect) or **In use** (that is, the interface is in use but not used by the cross-connect).

Interface type

- On a DIU-GG unit, there are four G.703 interfaces.
- On a DIU-VV unit, there are four V.xx interfaces.
- On a DIU-VG unit, there are two interfaces of each type. Interfaces 1 and 2 are always V.xx interfaces and interfaces 3 and 4 are always G.703 interfaces.

C.3 Functional block settings window

The **Functional Block Settings** window is accessed from the **Unit Configuration** window either by double-clicking an interface button or by right-clicking an interface button and then selecting **Configure** from the resulting pop-up menu. The **Functional Block Settings** window allows setting the attributes that define the channel mode. Other attributes can be accessed via the **Advanced...** button.




Figure C-2 Functional Block Settings window

The **Also Apply To...** button copies all attribute settings (including those that are set through the **Advanced...** button) to all interfaces specified. The **In Use** checkbox affects the administrative state settings.

Permitted attribute combinations

Table C-1 shows which values are allowed with each other, and the resulting channel mode. The channel mode is not displayed to the user.

Possible values of interface standard	Possible values of interface timing	Possible values of interface conversion/adaptation	Channel mode
V.24 (D) V.35 V.36 EIA-530-A	Asynchronous	Sampling	1
		R111	2
		Transparent + V14 (D)	3 ^{1) 2)}
		V110 + V14 ¹⁾	4 ^{1) 2)}
	Synchronous codir. or contradir. (D)	Transparent (D)	5 ²⁾
		V110	6 ²⁾
X.21	Synchronous S.E.T (D)	Transparent (D)	11 ²⁾
	Synchronous octet	X30	12 ²⁾
	Synchronous external		
G.703	Synchronous codir. or contradir. (D)	Transparent	13
Notes: 1) In channel modes 3 and 4, V.14 is used to perform the async–sync conversion. These are the only modes that use V.14 (when the user rate is higher than 0.6 kbit/s). The Advanced... window has a separate tab for V.14 configuration. The text displayed is V.110+V.14 when the user rate is >0.6 kbit/s, and V.110 in all other cases. 2) In modes 3 to 12 (that is, in the V.xx and X21 modes), the user can choose whether or not to use V.13. (The Advanced... window includes the V.13 options on the V.xx and X.21 tabs.)			

Table C-1 Permitted attribute combinations

For **Interface standard**, the full range of possible values is always visible in the dropdown control. If the user sets the **Interface standard** to something which is not compatible with the existing setting of **Interface conversion/adaptation**, then the existing setting is replaced by the appropriate default value. The same applies to the interaction between **Interface standard** and **Interface timing**.

The **Interface standard** can be:

- V.24 (default setting)
- V.35
- V.36
- EIA-530-A
- X.21
- G.703.

For **Interface conversion/adaptation**, the values shown are the ones that are valid with the current setting of **Interface standard**.

The **Interface conversion/adaptation** can be:

- Sampling
- Transition coding (R111)
- Transparent
- V110 (for channel modes 4 and 6)/X.30 (for channel mode 12).

For **Interface timing**, the values shown are the ones that are valid with the current setting of **Interface standard**.

Interface timing is selected by the user; the text description appears automatically according to user selection. The possible options are listed in Table C-2.

Interface timing	Text description
Asynchronous	No timing circuits
Codirectional	– If interface standard is V.xx: Circuits 113/115 used for timing – If interface standard is G.703: No separate timing circuits
Contradirectional	– If interface standard is V.xx: Circuits 114/115 used for timing – If interface standard is G.703: One timing circuit in each direction
Signal element	Circuit S used for timing
Octet element	Circuits S and B used for timing
External	Circuits S and X used for timing

Table C-2 Interface timing options

The **User rate** may change according to selections in **Interface standard**, **Interface conversion/adaptation**, or **Interface timing**.

Note

Selections in the **Functional Block Settings** window may cause changes to the data in other windows, so that only valid combinations are displayed. For example, changes to **User rate** in this window may mean that only certain values are valid for **Signal 106 delay** in the **V.xx** tab. In every case where a field is reset, it is reset to its default value.

The possible values for the User Rate depend on the channel mode, as shown in Table C-3.

Internal representation	Rate	Channel mode								
		1	2	3	4	5	6	11	12	13
0	<0.6									
1	0.6									
2	1.2									
3	2.4									
5	4.8	(D)								
8 (1 x 8) ²⁾	8									
10	9.6									
16 (2 x 8) ²⁾	16									
20	19.2		(D)							
24 (3 x 8) ²⁾	24									
32 (4 x 8) ²⁾	32									
40 (5 x 8) ²⁾	40									
48 (6 x 8) ²⁾	48									
56 (7 x 8) ²⁾	56				(D)	(D)	(D)		(D)	
64 ²⁾	64			(D)				(D)		
N + 63 ²⁾	N x 64; N = 2–32					1)				

Notes: 1) Nx64 is not allowed for V.24, only for V.35, V.36 and EIA-530-A
2)For the nx8, nx64 bit rates, select the resulting bit rate from the list (for example, bit rate 24 for 3x8). The equivalent nx8, nx64 bit rate representation will be shown alongside the current selection as read-only text.

Table C-3 Correlation between user rate and channel mode. The default values are marked with D.

The **Cross-connect rate** is read only. It shows the rate to be used (or in use) for cross-connecting this interface (that is, intermediate rate plus, if necessary, POH). This value is calculated and updated automatically according to the current settings. When the user opens this window for the first time, this field shows the default value.

When editing this window (on a configured interface), the controls are all disabled if there is a cross-connect on the interface excluding the **Advanced...** button. In such a situation, it is possible to view the advanced settings, but not edit them.

C.4 Advanced interface settings tabs

The **Advanced...** button leads to a tabbed window. The tabs available depend on the channel mode, as shown in Table C-4. The **Advanced...** button is greyed out until the **Functional Block Settings** window contains a valid set of values for the selected interface.

If any selections are made within the advanced interface settings tabs and the **OK** button is pressed, the selection is automatically copied to the **Functional Block Settings** window and the selections contained within the **Settings** groupbox in the **Functional Block Settings** window will be greyed out. This is to prevent users from making changes in the tabs which are valid for one channel mode, returning to the **Functional Block Settings** window and changing the channel mode to another, for which the advanced settings may not be valid.

The tabs available depend on the channel mode as shown in Table C-4.

Tab name	Channel mode									
	1	2	3	4	5	6	11	12	13	
G.703										
X.21										
V.xx										
V.110 Adaptation ¹⁾										
X.30 Adaptation ²⁾										
Input buffer										
Sampling										
V.14										
POH										
Bitmasks										
Number of visible tabs	4	3	3	4	4	4	4	4	4	2
Notes: 1) V.110 Adaptation when V.xx or EIA-530-A, that is, when the channel mode is 4 or 6 2) X.30 Adaptation when X.21, that is, when the channel mode is 13										

Table C-4 Tabs available for different channel modes

C.4.1 G.703 tab

This tab is available only when the channel mode is 13 (that is, when the Interface standard is G.703).




Figure C-3 G.703 tab

Attribute (UI term)	Possible values	Default
Monitor (Rx)	Enabled, Disabled, Not supported	Disabled
Sent (Tx)	Fixed On, Fixed Off, Alarm Controlled	Fixed On

Table C-5 Possible values and default values for the G.703tab

C.4.2 X.21 tab

This tab is available only when the channel mode is 11 or 12 (that is, when the interface standard is X.21).




Figure C-4 X.21 tab

Attribute	Possible values	Default
Interface termination	Enabled/Disabled	Enabled
Circuit C	Fixed On, Fixed Off, Enabled	Enabled
Circuit I	Fixed On, Fixed Off, Enabled	Fixed Off
Circuit R	Fixed On, Fixed Off, Enabled	Enabled
Circuit T	Fixed On, Fixed Off, Enabled	Enabled
Loopback indication pattern	0101..., 0000...	–

Table C-6 Possible values and default values for the **X.21** tab

Circuit usage

The possible circuit state values are **On**, **Off**, **Toggling** and **Not applicable** for all circuits. It is not possible to set Circuit X.

Note

The circuit state values shown are a snapshot of the current value read from the node at the moment when the user accesses the **Unit configuration** window. These values are not dynamically updated. If an up-to-date value is required, the window has to be refreshed by selecting the **Refresh from node** command. Refreshing can be done only if the window is closed.

V.13 usage and POH tab

The V.13 usage selections appear also on the **V.xx** tab, but the **X.21** tab and the **V.xx** tabs are never visible at the same time.

Generally, if any conversion/adaptation other than V.110 is used, the V.13 usage selections are available.

Note

The V.13 selections and the selections within the **Control signal** groupbox on the POH tab are mutually exclusive. That is, V.13 usage is selected, then the POH **Control signal** selections are not available. Conversely, if the **Control signal** selection is made on the POH tab, the V.13 selections on the X.21 tab are not available.

If the X.30 conversion/adaptation is selected, only the **V.13 upstream** checkbox is available. The **V.13 downstream** checkbox and the POH **Control signal** selections will not be available.

C.4.3 V.xx tab

This tab is available only for channel modes 1 to 6.




Figure C-5 V.xx tab

Attribute	Possible values	Default
Circuit 103	Fixed On, Fixed Off, Enabled	Enabled
Circuit 104	Fixed On, Fixed Off, Enabled	Enabled
Circuit 105	Fixed On, Fixed Off, Enabled	Enabled
Circuit 106	Fixed On, Fixed Off, Local Enabled, Remote Enabled	Local Enabled / Remote Enabled ¹⁾
Circuit 107	Fixed On, Fixed Off, Enabled	Enabled
Circuit 109	Fixed On, Fixed Off, Enabled	Enabled
Notes: 1) If the interface is in V.110 mode, the default value is Remote Enabled, otherwise Local Enabled.		

Table C-7 Possible values and default values for circuit usage

Circuit labels

When the **Interface standard** is EIA-530-A, the circuits are labelled as shown in Table C-8:

V.24, V.35, V.36	EIA-530-A
104	BB
106	CB
107	CC
109	CF
114	DB
115	DD
142	TM
–	–
103	BA
105	CA
108	CD
113	DA
140 (not for V.36)	RL
141 (not for V.36)	LL

Table C-8 Circuit labels when the **Interface standard** is EIA-530-A

Note

The circuit state values shown are a snapshot of the current value read from the node at the moment when the user accesses the **Unit configuration** window. These values are not dynamically updated. If an up-to-date value is required, the window has to be refreshed by selecting the **Refresh from node** command. Refreshing can be done only if the window is closed.

The circuit states are read-only.

Signal 106 delay is fixed in the following two cases:

- When V.13 is in use (that is, when either of the checkboxes in the **V.13 Usage** groupbox in this window is checked) **Signal 106 delay** is fixed at **8 bits**.
- When V.110 is in use, **Signal 106 delay** is fixed at **24 bits**.

In the above two cases, the actual delay depends on the **User rate**, which is visible on the original **Unit configuration** window. Node Manager calculates the actual delay based on the **User rate** and the number-of-bits delay.

In all other cases, the delay can be selected within the limits given in Table C-9.

Rate	Range, in ms	Step size, in ms
mx 8 where m=1–7, nx64 where n=1–8	0–240	1
nx64, where n=9–32	0–60	1
All other rates	0–240	1

Table C-9 Possible values for **Signal 106 delay**

Attribute (UI term)	Possible values	Default
Use V.13 for downstream control signal transfer	True, False	False (unchecked)
Use V.13 for upstream control signal transfer	True, False	False (unchecked)
Note: When one of these selections is checked, the Signal 106 delay in the Circuit usage groupbox is set to 8 bits and cannot be changed. These selections are not available in channel modes 1 and 2.		

Table C-10 Possible values and default values for **V.13 Usage**

V.13 usage and the POH tab

The V.13 usage selections appear also on the X.21 tab, but the X.21 tab and the V.xx tabs are never visible at the same time.

Generally, if any conversion/adaptation other than V.110 is used, the V.13 usage selections are available.

Note

The V.13 selections and the selections within the **Control signal** groupbox on the POH tab are mutually exclusive. That is, V.13 usage is selected, then the POH **Control signal** selections are not available. Conversely, if the **Control signal** selection is made on the POH tab, the V.13 selections on the X.21 tab are not available.

If the V.110 conversion/adaptation is selected, only the **V.13 upstream** checkbox is available. The **V.13 downstream** checkbox and the POH **Control signal** selections will not be available.

C.4.4 V110 Adaptation tab

This tab is available only for channel modes 4 and 6, that is, when the interface standard is V.xx or EIA-530-A. (For channel mode 12, the tab is called X.30 Adaptation and the circuits are labelled differently; see Section C.4.5.)




Figure C-6 V.110 Adaptation tab

When the **Interface standard** is EIA-530-A, the circuits are labelled as shown in Table C-11.

V.xx	EIA-530-A
Circuit 104 (D-bits)	Circuit BB
Circuit 107	Circuit CC
Circuit 108	Circuit CD
Circuit 105	Circuit CA
Circuit 109	Circuit CF
Circuit 106	Circuit CB

Table C-11 Circuit labels when the **Interface standard** is EIA-530-A

In channel modes 4, 6 and 12, the user can also control some of these circuits from the V.xx tab.

Attribute (UI term)	Possible values	Default
V110 operation ¹⁾	Duplex (Simplex Tx, Simplex Rx, Half duplex are not supported in release C2.0)	Duplex
Report LOVFS alarms	True, False	True (checked)
AIS on local loopback	Continue, Terminate	Continue (checked)
Adaptation of 56 kbit/s ²⁾	Use S and X bits(True), No control circuits (False)	True (Use S- and X-bits)
Circuit 104 (D-bits)	Normal, Fixed On, Fixed Off	Normal
Circuit 107	Normal, Fixed On, Fixed Off	Normal
Circuit 108	Normal, Transparent, Not in Use	Transparent
Circuit 105	Normal, Not in Use	Normal
Circuit 109	Normal, Fixed On, Fixed Off	Normal
Circuit 106 (X-bits)	Normal, Fixed On, Fixed Off	Normal
Notes: 1) The V.110 operation box contains only Duplex in release C2.0. 2) The control Adaptation of 56 kbit/s is enabled only when the user rate is 56 kbit/s		

Table C-12 Possible values and default values for **V.110 Adaptation** tab

Note

The circuit state values shown are a snapshot of the current value read from the node at the moment when the user accesses the **Unit configuration** window. These values are not dynamically updated. If an up-to-date value is required, the window has to be refreshed by selecting the **Refresh from node** command. Refreshing can be done only if the window is closed.

C.4.5 X.30 Adaptation tab

This tab is available for channel mode 12 only. It is similar in behaviour to the V.110 Adaptation tab, but has fewer fields and different field labels.




Figure C-7 X.30 Adaptation tab

C.4.6 Input buffer tab

This tab is available for channel modes 5 to 13, that is, for the synchronous modes.




Figure C-8 Input buffer tab

Attribute (UI term)	Possible values	Default
Report IBO/IBU alarms	True, False	True (checked)
Threshold for IBO	1 to 255	3
Threshold for IBU	1 to 255	3
IBO = Input buffer overflow; IBU = Input buffer underflow		

Table C-13 Possible values and default values for **Input buffer** tab

The tab also displays the number of underflow/overflow errors reported by the node. Note that this information is read from the node and is not updated after the window is accessed. To get the up-to-date value, refresh the window by selecting the **Refresh from node** command.

C.4.7 Sampling tab

This tab is available for channel mode 1 only, that is, when sampling is in use.

This tab contains just one control, a check box labelled **Filter error bursts**.



Figure C-9 Sampling tab

Attribute (UI term)	Possible values	Default
Filter error bursts	True, False	False (unchecked)

Table C-14 Possible values and default values for **Sampling** tab

C.4.8 V.14 tab

This tab is available for channel modes 3 and 4.




Figure C-10 V.14 tab

Attribute (UI term)	Possible values	Default
Character length	8–11	8
Tolerance	Basic (–2.5 to +1%), Extended (–2.5 to +2.3%)	Basic (–2.5 to +1%)

Table C-15 Possible values and default values for **V.14** tab

C.4.9 POH tab

This tab is not available for channel modes that use V.110, that is for modes 4, 6 and 12.




Figure C-11 POH tab

Note

If either of the V.13 checkboxes in the X.21 or V.xx tabs has been checked, these selections are not available. Conversely, if the **Control signal** selection is made on the POH tab, the V.13 selections on the X.21 tab are not available.

C.4.10 Bitmasks tab

This tab is available for all other channel modes except 3 and 13. It shows the up-/downstream bitmask, which is fixed and determined by the intermediate rate.

If the intermediate rate is 64 kbit/s or higher

When the intermediate rate is 64 kbit/s or higher, the following applies:

- The selections on this tab are read-only.
- The bitmask is fixed with all bits set (that is, 11111111).
- The “Left shift” controls are not available.



Figure C-12 Bitmasks tab when the intermediate rate is 64 kbit/s or higher

If the intermediate rate is less than 64 kbit/s

When the intermediate rate is less than 64 kbit/s, the following applies:

- The “Left shift” controls are available.
- User can specify a left shift for the displayed bitmask.

The default value for the left shift is zero. The maximum value will vary according to the bitmask, but still prevents users from losing the set bits of the mask by shifting them to far left. So, for example, in Figure C-13, the left shift range is 0 to 6. If the bitmask was 00011111, the range would be 0 to 3.




Figure C-13 Bitmasks tab when the intermediate rate is less than 64 kbit/s

SYSTEM RELEASE ITEM LIST

13-FEB-03

Eksos N20 C2.0.1 DEU

Approved: TLö 13-FEB-03

Product Name	Product Code	Release	Dependent Item	Release
T30813 Fan Unit Operating Instructions	C33461.20	C		
T30810.02 Fuse Terminal Operating Instr.	C33508.20	A		
T35025.xx OSI-DCN Adaptor User Manual	C33585.20	B		
Eksos N20 C2.0 Upgrade Instructions	C33836.22	B		
ETSI Rack (E30528.***) Inst. Instr. (E)	C33912.20	B		
DC-PIU Operating Instructions	C33976.20	A		
T30810.01/.11 DC-PSA Operating Instr.	C33983.20	A		
Eksos N20 C2.0 DEU User Manual	C33993.20	B		
RJ45 cable connector set, 10 pcs	E30419.05	A		
EKSOS N20 Wall Mounting Set	E30444.01	A		
EKSOS N20 Wall Mounting Set	E30444.01	B		
EKSOS N20 Wall Mounting Set	E30444.01	C		
EKSOS Service Conn. Panel	E30444.02	A		
ETSI-Connection Bar Frame (LSA-Profil)	E30444.03	A		
Connection Bar Frame (LSA-Profil)	E30444.04	A		
NCU 4x2M 75ohm Cable Acc. Set	E30445.01	A		
NCU 4x2M 75ohm Cable Acc. Set	E30445.01	B		
NCU 4x2M 120ohm Cable Acc. Set	E30445.02	B		
NCU 4x2M 120ohm Cable Acc. Set	E30445.02	C		
NCU 4x2M 75/120ohm Cabling Acc. Set	E30445.03	A		
NCU 4x2M 75/120ohm Cabling Acc. Set	E30445.03	B		
NCU/SAN CORE2M 120ohm Adapter Cable	E30445.04	A		
Eurocon. 2x32(ww) Cabling Acc.Set, 2pcs	E30445.11	A		
Eurocon. 3x7(ww) Cabling Acc.Set, 8pcs	E30445.12	A		
Eurocon. 2x32(ww) Cabling Acc.Set, 1pcs	E30445.21	A		
Eurocon. 3x7(ww) Cabling Acc.Set, 4pcs	E30445.22	A		
DIU 2x(3x7) Shdl Cabl. Acc.Set 4pcs	E30445.41	A		
Jumper Cable Pair POTS (32ch.-con.bar)	E30447.02	A		
Jumper Cable ISDN-U (16ch.-con.bar)	E30447.03	A		
Fan Interface Cable Eksos N20	E30804.14	A		
Power/Sign.Volt Cable NTM 0.5m	E30805.05	A		
Power/Sign.Volt Cable NTM 0.5m	E30805.05	B		
Power/Sign.Volt Cable NTM 1m	E30805.10	A		
Power/Sign.Volt Cable NTM 1m	E30805.10	B		
Power/Sign.Volt Cable NTM 1.5m	E30805.15	B		
Power/Sign.Volt Cable NTM 2m	E30805.20	A		
Power/Sign.Volt Cable NTM 2m	E30805.20	B		
Power/Sign.Volt Cable NTM 2.5m	E30805.25	B		
Power/Sign.Volt Cable NTM 3m	E30805.30	A		
Power/Sign.Volt Cable NTM 3m	E30805.30	B		
Power/Sign.Volt Cable NTM 3.5m	E30805.35	A		
Power/Sign.Volt Cable NTM 3.5m	E30805.35	B		
Station Alarm Cable NTM 0.5m	E30806.05	A		
Station Alarm Cable NTM 0.5m	E30806.05	B		
Station Alarm Cable NTM 1m	E30806.10	A		
Station Alarm Cable NTM 1m	E30806.10	B		
Station Alarm Cable NTM 1.5m	E30806.15	B		
Station Alarm Cable NTM 2m	E30806.20	A		
Station Alarm Cable NTM 2m	E30806.20	B		
Station Alarm Cable NTM 2.5m	E30806.25	B		
Station Alarm Cable NTM 3m	E30806.30	A		
Station Alarm Cable NTM 3m	E30806.30	B		
Station Alarm Cable NTM 3.5m	E30806.35	A		
Station Alarm Cable NTM 3.5m	E30806.35	B		
Power Branching Cable NTM 0.5m	E30815.05	A		
Power Branching Cable NTM 1.5m	E30815.15	A		
TC POTS 17-32 N20- 10M	E32847.10	B		
TC POTS 17-32 N20 -15M	E32847.15	B		
TC POTS 17-32 N20- 20M	E32847.20	B		
TC POTS 17-32 N20- 25M	E32847.25	B		
TC POTS 17-32 N20- 35M	E32847.35	B		

SYSTEM RELEASE ITEM LIST

13-FEB-03

Eksos N20 C2.0.1 DEU

Approved: TLö 13-FEB-03

Product Name	Product Code	Release	Dependent Item	Release
TC POTS 17-32 N20- 40M	E32847.40	B		
TC POTS 17-32 N20- 50M	E32847.50	B		
TC POTS 17-32 N20- 70M	E32847.70	B		
TC ISDN/POTS 1-16 N20- 10M	E32848.10	B		
TC ISDN/POTS 1-16 N20- 15M	E32848.15	B		
TC ISDN/POTS 1-16 N20- 20M	E32848.20	B		
TC ISDN/POTS 1-16 N20- 25M	E32848.25	B		
TC ISDN/POTS 1-16 N20- 35M	E32848.35	B		
TC ISDN/POTS 1-16 N20- 40M	E32848.40	B		
TC ISDN/POTS 1-16 N20- 50M	E32848.50	B		
TC ISDN/POTS 1-16 N20- 70M	E32848.70	B		
Locks and Frame for Euroconnector	E32899.10	A		
Coax Carrier	E32899.11	A		
C2.0 ISDN BRA Unit (2B1Q,16ch) Func.	P35232.30	E		
C2.0 ISDN BRA Unit (2B1Q,16ch) Func.	P35232.30	F		
C2.0 ISDN BRA Unit (4B3T,16ch) Func.	P35232.31	E		
C2.0 ISDN BRA Unit (4B3T,16ch) Func.	P35232.31	F		
C2.0 LMU Unit Functionality	P35232.40	E		
C2.0 LMU Unit Functionality	P35232.40	F		
C2.0 TR2M4 Unit Functionality	P35232.50	E		
C2.0 TR2M4 Unit Functionality	P35232.50	F		
C2.0 DIU Unit Functionality	P35232.60	E		
C2.0 DIU Unit Functionality	P35232.60	F		
C2.0 Node Feature Set DEU	P35286.01	E		
C2.0 Node Feature Set DEU	P35286.01	F		
C2.0 NCU Unit DEU Functionality	P35286.10	E		
C2.0 NCU Unit DEU Functionality	P35286.10	F		
C2.0 POTS Unit 32ch DEU Functionality	P35286.20	E		
C2.0 POTS Unit 32ch DEU Functionality	P35286.20	F		
OSI DCN Adaptor Feature Set	P35295.01	E		
OSI DCN Adapter Functionality	P35295.10	E		
EKSOS N20 C3.0 Node Manager	P35304.01	A		
C3.1 EKSOS N20 Node Manager	P35305.01	A		
ETSI RACK WITH BACK PLATES (2,2x0,6x0,3M)	T30400.01	A		
ETSI RACK WITHOUT BACK PLATES (2,2x0,6x0,3M)	T30400.02	A		
Node Manager Cable (Ethernet)	T30404.21	C		
Ethernet Cable, 50cm	T30405.01	A		
80 cm Eth. cable (Subrack-Subrack)	T30405.08	F		
50 ohm Ethernet Line Termination	T30405.10	F		
T-BNC Connector with protective cover	T30405.11	F		
120 cm Ethernet Cable (Rack-Rack)	T30405.12	F		
ETSI Rack with back plate (300 mm deep)	T30406.01	F		
ETSI Rack wo back plate 2.2 m, d=300 mm	T30406.02	F		
Side Plate Set for ETSI Rack (one side)	T30406.03	E		
Top Mounting Set	T30406.04	C		
Back Plate Set for ETSI Rack	T30406.06	F		
Inst. Acc. for next to wall/floor inst.	T30406.09	H		
STAND SET FOR ETSI RACK	T30406.10	H		
CABLE SUPPORT SET	T30406.11	G		
CABLE SUPPORT SET	T30406.11	J		
NTM 1-slot blank front plate	T30426.01	D		
NTM Plastic cover 19 in./ETSI	T30426.02	D		
NTM Plastic cover 19 in./ETSI	T30426.02	E		
NTM Fibre quidance set	T30426.03	D		
NTM Fibre quidance set	T30426.03	E		
NTM unit repair set	T30426.08	C		
Eksos N20 Subrack 17-slot	T30427.01	C		
Eksos N20 Subrack 17-slot	T30427.01	D		
Eksos N20 Subrack 17-slot	T30427.01	E		
Eksos N20/SAN Subrack 17-slot	T30427.03	C		
Eksos N20/SAN Subrack 17-slot	T30427.03	D		

SYSTEM RELEASE ITEM LIST

13-FEB-03

Eksos N20 C2.0.1 DEU

Approved: TLö 13-FEB-03

Product Name	Product Code	Release	Dependent Item	Release
Eksos N20/SAN Subrack 17-slot	T30427.03	E		
19 in. shelf	T30432.01	E		
ETSI 500mm shelf	T30432.02	E		
19in./ETSI-2U Air Deflector	T30433.01	D		
19in./ETSI-2U Air Deflector	T30433.01	E		
19in./ETSI-5U Air Deflector	T30433.02	D		
19in./ETSI-5U Air Deflector	T30433.02	E		
19 in./ETSI-2U Air Deflector with Grill	T30433.04	D		
19 in./ETSI-2U Air Deflector with Grill	T30433.04	E		
19 in./ETSI-5U Air Deflector with Grill	T30433.05	D		
19 in./ETSI-5U Air Deflector with Grill	T30433.05	E		
NTM Dual Ethernet Cable 1m	T30436.01	A		
NTM Dual Ethernet Cable 3m/0,5m	T30436.02	A		
Adapter for NTM Ethernet Cable	T30436.03	A		
EKSOS N20/SAN Cartridge 8-slot	T30500.01	A		
EKSOS N20/SAN Cartridge 8-slot	T30500.01	B		
EKSOS N20 NAN Cardtridge 8-Slot	T30500.02	A		
EKSOS N20 NAN Cardtridge 8-Slot	T30500.02	B		
Power Cable NTM 2.5m	T30803.03	A		
Alarm Cable NTM & STM-16 2.5m	T30803.04	A		
Power Cable NTM 1.5m	T30803.05	A		
Alarm Cable NTM 1.5m	T30803.06	A		
Sign. Voltage Cable NTM 2.5m	T30803.09	A		
Fan Interface Cable Eksos	T30803.14	A		
DC-PSA 19 in./ETSI	T30810.01	B		
DC-PSA 19 in./ETSI	T30810.01	C		
DC-PSA 19 in./ETSI	T30810.01	D		
Fuse Terminal 19 in./ETSI	T30810.02	A		
Fuse Terminal 19 in./ETSI	T30810.02	C		
Fuse Terminal 19 in./ETSI	T30810.02	D		
Extension Unit 1U 19 in./ETSI	T30810.03	C		
Capacitor Unit 19 in./ETSI	T30812.01	A		
Fan Unit 19 in./ETSI	T30813.01	B		
Fan Unit 19 in./ETSI	T30813.01	C		
DC-PIU 48V/800W W25mm NTM	T30814.01	C		
Decor. Cover DC-PSA 19in./ETSI	T30827.02	B		
Decorative Cover 2U NTM	T30827.05	D		
Decorative Cover 1U NTM	T30827.10	D		
NCUA 75 ohm	T35010.01	A	P35286.10	E
NCUA 75 ohm	T35010.01	B	P35286.10	E
NCUA 75 ohm	T35010.01	C	P35286.10	E
NCUA 75 ohm	T35010.01	D	P35286.10	E
NCUA 75 ohm	T35010.01	D	P35286.10	F
NCUA 120 ohm	T35010.11	A	P35286.10	E
NCUA 120 ohm	T35010.11	B	P35286.10	E
NCUA 120 ohm	T35010.11	C	P35286.10	E
NCUA 120 ohm	T35010.11	D	P35286.10	E
NCUA 120 ohm	T35010.11	D	P35286.10	F
NCUA 75 ohm w/ 120 ohm synch.	T35010.21	A	P35286.10	E
NCUA 75 ohm w/ 120 ohm synch.	T35010.21	B	P35286.10	E
NCUA 75 ohm w/ 120 ohm synch.	T35010.21	C	P35286.10	E
NCUA 75 ohm w/ 120 ohm synch.	T35010.21	D	P35286.10	E
NCUA 75 ohm w/ 120 ohm synch.	T35010.21	D	P35286.10	F
OSI DCN adaptor 75 ohm	T35025.01	C	P35295.10	E
OSI DCN adaptor 120 ohm	T35025.11	C	P35295.10	E
TR2M4a 75 OHM	T35030.01	A	P35232.50	E
TR2M4a 75 OHM	T35030.01	B	P35232.50	E
TR2M4a 75 OHM	T35030.01	B	P35232.50	F
TR2M4a 120 ohm	T35030.11	A	P35232.50	E
TR2M4a 120 ohm	T35030.11	B	P35232.50	E
TR2M4a 120 ohm	T35030.11	B	P35232.50	F

SYSTEM RELEASE ITEM LIST

13-FEB-03

Eksos N20 C2.0.1 DEU

Approved: TLö 13-FEB-03

Product Name	Product Code	Release	Dependent Item	Release
Subscriber i/f (POTS 32ch) unit	T35050.01	B	P35286.20	E
Subscriber i/f (POTS 32ch) unit	T35050.01	B	P35286.20	F
Subscriber i/f (POTS 32ch) unit	T35050.03	F	P35286.20	E
Subscriber i/f (POTS 32ch) unit	T35050.03	G	P35286.20	E
Subscriber i/f (POTS 32ch) unit	T35050.03	H	P35286.20	E
Subscriber i/f (POTS 32ch) unit	T35050.03	H	P35286.20	F
EKSOS N20 DataInterfaceUnit 4x VX Ports	T35106.01	A	P35232.60	E
EKSOS N20 DataInterfaceUnit 4x VX Ports	T35106.01	B	P35232.60	F
EKSOS N20 DataInterf.Unit 4x G.703 Ports	T35106.02	A	P35232.60	E
EKSOS N20 DataInterf.Unit 4x G.703 Ports	T35106.02	B	P35232.60	F
EKSOS N20 DataIFUnit 2xV&X&2xG.703 Ports	T35106.03	A	P35232.60	E
EKSOS N20 DataIFUnit 2xV&X&2xG.703 Ports	T35106.03	B	P35232.60	F
ISDN BRA U-i/f (2B1Q 16 ch) unit	T35111.11	A	P35232.30	E
ISDN BRA U-i/f (4B3T 16 ch) unit	T35111.12	A	P35232.31	E
ISDN BRA U-i/f (4B3T 16 ch) unit	T35111.12	A	P35232.31	F
ISDN BRA U-i/f (2B1Q 16ch DN) unit	T35111.21	B	P35232.30	E
ISDN BRA U-i/f (2B1Q 16ch DN) unit	T35111.21	C	P35232.30	E
ISDN BRA U-i/f (2B1Q 16ch DN) unit	T35111.21	C	P35232.30	F
ISDN BRA U-i/f (4B3T 16ch DN) unit	T35111.22	B	P35232.31	E
ISDN BRA U-i/f (4B3T 16ch DN) unit	T35111.22	C	P35232.31	E
ISDN BRA U-i/f (4B3T 16ch DN) unit	T35111.22	C	P35232.31	F
Line Measurement Unit	T35140.01	A	P35232.40	E
Line Measurement Unit	T35140.01	B	P35232.40	E
Line Measurement Unit	T35140.01	C	P35232.40	E
Line Measurement Unit	T35140.01	C	P35232.40	F

Nokia Eksos N20

Narrowband Multiservice Access Node

System Release Notes for C2.0 HA.1

29 Jan 2003

1 About this document

Chapter 2 describes briefly the principles of node compatibility. It also lists the related products, either Nokia's or other vendors', that are compatible with Eksos N20 system release C2.0.

Chapter 3 lists the new features of C2.0 system release.

Chapter 4 gives instructions for upgrading from C1.1 to C2.0.

Chapter 5 describes the corrected defects.

Chapter 6 describes the known defects and recommended remedies.

Chapter 7 provides a key to reading the System Release Item List.

2 Compatibility

Eksos N20 products are under continuous development. In order to indicate and manage the functionality and compatibility levels, all products are included in system releases.

2.1 Internal compatibility

The System Release Item List explicitly shows the node compatibility of Eksos N20 products. All products which belong to the same compatibility level (EKN20 C2.0 HA.1) of the system release are guaranteed to be compatible.

2.1.1 Compatibility with other products

This section describes the compatibility of Eksos N20 system release C2.0 nodes with related products.

SAN

Eksos N20 C2.0 is compatible with SYNFFONET Access Node (SAN) system release C1.5 or newer.

SYNFONET

Eksos N20 C2.0 is compatible with all products of the SYNFONET family.

3 New features, units, mechanical structures and applications introduced in C2.0

Support for the following features has been added to system release C2.0:

- V5 support:
 - four V5.2 interfaces in one node
 - max. 16 x 2 Mbit/s links under one V5.2 interface
 - max. V5.2 user port capacity 1440 user ports through converter
 - 64 kbit/s semi-permanent leased line connections via PSTN and ISDN BRA tributary interfaces under V5.2
 - 64 kbit/s semi-permanent leased line connections via V5.1 PSTN and ISDN BRA tributaries under V5.2
 - free association of 2 Mbit/s links into different V5.2 interfaces
 - free association of tributary user ports into different V5.2 interfaces
 - V5.2 multihosting
 - V5.1 tributaries under V5.2
 - multislot BCC for BRA
 - partial provisioning of ISDN BRA ports
 - C-paths for P-type data
- semi-permanent leased lines:
 - via PSTN, ISDN BRA; either directly or via V5.1 tributary
 - preconnected bearer channel
- line testing:
 - scheduled line testing
 - line test threshold management
 - dial tone test
 - V.xx and X.yy for DIU loopbacks
- data interfaces:
 - X.21, V.24/V.28, V.35, V.36, EIA-530, G.703 co-/contradirectional
 - V.110 support in data interface unit
 - DNT128 interface via ISDN-U unit (2B1Q)
- local DCN and overhead data access:
 - asynchronous V.11 interface
- Q3 DCN:
 - 64 kbit/s V.11 auxiliary interface to 2 Mbit/s TSx channel (synchronous)
- Q1 DCN:
 - Q1 summing points in TSx
 - 64 kbit/s V.11 Q1/Auxiliary interface to 2 Mbit/s TSx channel (asynchronous)
- cross-connect at n x 64 kbit/s granularity
- leased lines outside V5
 - n x 64 kbit/s leased line support for ISDN BRA interfaces, data interfaces, 2 Mbit/s tributaries and V5.1 tributaries

- new units:
 - TR2M4 unit: 4 x 2 Mbit/s tributary, basic n x 64 kbit/s and V5
 - PSTN unit: 32 channels, basic features, service switch support
 - ISDN-U BRA Unit: 16 channels, 2B1Q, with service switch and DNT128 support
 - ISDN-U BRA Unit: 16 channels, 4B3T, with service switch and DNT128 support
 - Data Interface Unit (DIU): 4 x G.703, 64 kbit/s
 - Data Interface Unit (DIU): 4 x V.xx / X.yy
 - Data Interface Unit (DIU): 2 x G.703 64 kbit/s and 2 x V.xx / X.yy
- new mechanical structures:
 - Eksos N20 8-slot cartridge
 - Eksos N20/SAN 8-slot cartridge
 - new air deflectors and cable tray
- new applications:
 - n x 64 kbit/s leased line cross-connect services
 - data services
 - V5.1 tributary for remote sub nodes
 - V5.1/V5.2 converter
 - service switch functionality
 - n x 64 kbit/s DXC.

4 Upgrading from earlier releases

Upgrading from C1.1 using Node Manager

► To upgrade the software from C1.1 to C2.0, do the following:

1. Install the Eksos N20 Node Manager (release C3.0).
2. Connect to a C1.1 node.
3. Download the C2.0 software.
4. Activate the software:
 - In the **New Level** list box of the **Software Settings** window, select the EKN C2.0 release.
 - Select all units from the list box and check that the unit software product code versions are the ones that you want.
 - Click on the **Switch** button.
 - Select **Data** → **Send to Node**.
5. Disconnect from the node, then reconnect to the node.
6. Insert new C2.0 units (DIU, TR2M4, new PSTN unit etc) in the subrack.

Full details for upgrading are given in the separate *Upgrade Instructions* document.

5 Corrected defects

Sometimes the scheduled test time is shown incorrectly in test results

The “V5 Data Link Failure” alarm is active/inactive for a few minutes

One of the 2M links kept on sending the “V5 Data Link Failure” alarm message continuously so that the alarm was active less than a second and a new alarm was activated after 0.5 to 1 minute. This situation lasted about 50 minutes and the case was solved by restarting the NCU unit.

Synchronisation source will not recover after a 2M link break

When the incoming 2M signal is selected as the synchronisation source and a 2M fault occurs, synchronisation is not always recovered to the normal operation. Eksos node gives the 'Loss of timing' indication even when the 2M signal is in the normal operational state and the timing should recover to the incoming 2M signal.

Feeding current short cut alarm sticks in interface 2 on ISDNUQ

Sometimes one of the ISDN unit's (ISDNUQ units of HW versions A4, A5, A6, A7) interfaces did not recover from a feeding current short cut fault. The feeding current short cut alarm stayed on.

No flag in C-channel TS15 when V5.2 is stopped

When the V5 interface was stopped, there was a C-channel flag in vital TS16 and in vital standby TS16, but not in vital TS15. In the same case, an unnecessary protection switch occurred. This has no effect on the PSTN or ISDN traffic.

Scheduled line test stability improved

Enabling the register recall function

During a call, it was possible with some switch to activate the register recall function only once.

6 Special instructions, known defects and abnormal situations

This section lists the known functional discrepancies between the Eksos N20 documents and the actual behaviour of the equipment. The known defective functionality is also described.

Node Manager may crash particularly when the interface is started and stopped

If Node Manager crashes, start it again.

Service switch and ADSL

When a temporary service switch is done, the transmission quality may slightly degrade in extreme circumstances. For ADSL, the speed determined by handshaking may slightly decrease.

Number of user ports

The number of user ports is limited approximately to 1100.

V5.1/V5.2 interface is shown as “disabled starting” while it should be “enabled started”

Node Manager may indicate this state, but the interface is functioning normally.

Modifying V5 interfaces

When modifying or removing V5 alarm reports, Node Manager can indicate an incorrect state and give an error message “An error occurred while trying to modify V5 configuration on the node”.

Semi-permanent POTS lines do not work after a NCU software restart

If you have a node with two NCU units and two V5.2 interfaces, restarting the node master NCU causes disabling of the other V5.2 interface and all of its user ports.

Action

You should stop the V5.2 interface and start it again.

DIU: Activating a Remote Loop in the DTE

When a Remote Loop is activated in the local DTE, synchronisation is momentarily lost in the remote DTE.

Action

Make sure that the **Remote user can set loop to network2** box has been checked at the remote end.

The synchronisation is recovered automatically.

Activating a Remote Loop with POH for data interfaces

When a Remote Loop with POH is activated for data interfaces, the control signals are not looped back if the **Remote user can set loop to network2** box has been checked at the remote end.

Time slots for n x 64 kbit/s cross-connects

The time slots for n x 64 kbit/s cross-connects must be consecutive ones.

Setting up leased lines

The DIU cross-connect capacity to a 2M interface may be limited if the 2M interface is in V5 use as it may have signalling configured in time slot 15, 16 or 31. In this case, the maximum cross-connection capacity for the DIU units is 15 x 64 kbit/s. This is because TS 16 is always used for Vital signalling at the V5 interface and, consequently, cannot be used for cross-connection purposes.

Setting default settings for DIU interfaces

It is not possible to set the default settings for individual data interfaces by Node Manager.

Action

If you want to set the default settings for all interfaces of the DIU unit, uninstall the unit by selecting **No Unit** in the **Unit Type** dialog box. Then install the unit again as described in the *Commissioning & Maintenance* document.

Viewing capacity of DIU.XX

The capacity of DIU.XX is shown incorrectly when the leased line dialog box is opened for the first time.

Action

Select **Data** -> **Refresh from Node** when an active leased line window is open.

Updating the value for the 'State' field in Advanced DIU Interface dialog box

The value shown in the 'State' field is not updated after the window is opened.

Action

To update the field, do the following:

1. Close the **Advanced DIU Interface settings** window by clicking on **OK**.
2. Close the **Configure DIU_xxUx** window by clicking on **OK**.
3. Select **Data** -> **Refresh from Node**.
4. Double-click on the desired interface in the **Configure Unitx** window.

5. Click on **Advanced** to view the state in the 'State' field.

Regenerator loop at ISDN interface

The ISDN interface stops working if a regenerator loop test is activated.

Action

The interface starts working again when the U-interface cable is disconnected and reconnected.

You can also reset the interface with Node Manager:

1. Select the ISDN unit by clicking on it in the **Subrack** window.
2. Select **Configure** → **Interface** to open the **Ux ISDNUQ** dialog box (x stands for the slot number where the unit is installed).
3. Select the interface by clicking on it, then right-click **Configure**. The **Configure ISDNUQ Ux** dialog box opens.
4. Select the **Power Feeding** tab.
5. In the **Interface Power Feeding** group box, set the maximum power to 0.
6. Send the data to the node.
7. Wait for about one minute.
8. Set the maximum power back to the original value.

Configuring DIU settings

It is not recommended to configure DIU settings when the interface is in use. Otherwise Node Manager may get stuck.

Handling of input buffer overflow / underflow alarms

Handling of input buffer overflow/underflow alarms is not correct in Node Manager. If there are input buffer overflow/underflow alarms in the current alarms list when the interface is in out of use state, you can clear these by setting the Interface Timing on the DIU unit to something else than **Codir, External**. This has to be done when the interface is out of use.

The Cancel button does not function correctly in the DIU Bitmask tab

Node Manager does not send the SET requests for attributes unless they have been changed with Node Manager. Clicking **OK** is assumed by Node Manager to signify a change to be made; clicking **Cancel** is not. Before creating leased lines, make sure that the local and remote end bitmask sets are the correct ones.

7 Key to System Release Item List

The System Release Item List provides a table of all the products (that is, sales items) that belong to system release C2.0. In addition to the products (for instance, T35010.01), the list also shows the product releases (for instance, T35010.01 release B).

Because the products are under constant development, the list shows just the latest situation of the system release compatibility. The document is being constantly updated to cover new product releases.

The item list may also contain several releases of the same product, which indicates that the product releases in question are compatible and interchangeable.

The “Dependent Item” column shows if two products are dependent on each other. An example of this is the program for a unit.

The functionality and compatibility levels can be read from the system release code appearing in the item list header.




Figure 1 Interpreting the system release code

Nokia Eksos N20

Narrowband Multiservice Access Node System Release C2.0

Product Description

NOKIA

The information in this document is subject to change without notice and describes only the product defined in the introduction of this documentation. This document is intended for the use of Nokia Networks' customers only for the purposes of the agreement under which the document is submitted, and no part of it may be reproduced or transmitted in any form or means without the prior written permission of Nokia Networks. The document has been prepared to be used by professional and properly trained personnel, and the customer assumes full responsibility when using it. Nokia Networks welcomes customer comments as part of the process of continuous development and improvement of the documentation.

The information or statements given in this document concerning the suitability, capacity, or performance of the mentioned hardware or software products cannot be considered binding but shall be defined in the agreement made between Nokia Networks and the customer. However, Nokia Networks has made all reasonable efforts to ensure that the instructions contained in the document are adequate and free of material errors and omissions. Nokia Networks will, if necessary, explain issues which may not be covered by the document.

Nokia Networks' liability for any errors in the document is limited to the documentary correction of errors. Nokia Networks WILL NOT BE RESPONSIBLE IN ANY EVENT FOR ERRORS IN THIS DOCUMENT OR FOR ANY DAMAGES, INCIDENTAL OR CONSEQUENTIAL (INCLUDING MONETARY LOSSES), that might arise from the use of this document or the information in it.

This document and the product it describes are considered protected by copyright according to the applicable laws.

NOKIA logo is a registered trademark of Nokia Corporation.

Any other trademarks mentioned in the documents are the property of their respective companies, and they are mentioned for identification purposes only.

Copyright © Nokia Corporation 2000-2002. All rights reserved.

Document History

Document	Date	Comment
C33836008SE_00	14 Dec 2000	
C33836008SE_A0	9 Apr 2001	
C33836008SE_A1	4 Jan 2002	

Contents

Chapter 1	
About this document	1
Chapter 2	
Introduction to Nokia Eksos N20	3
Chapter 3	
Features	5
3.1 Integrated SDH	6
3.2 V5 interfaces	7
3.3 Multihosting V5	7
3.4 V5.1 to V5.2 conversion	8
3.5 Leased line applications	9
3.6 Remote service switching	12
3.7 Fault tolerance	13
3.8 Line testing	13
3.9 Hot insert	19
3.10 External alarms	19
Chapter 4	
Application planning	21
4.1 Requirements for all applications	22
4.2 V5.2 multiplexer	22
4.3 V5.1 to V5.2 converter	24
4.4 Service switch	24
4.5 Leased line applications	25
4.6 Scheduled line testing applications	26

Chapter 5	
Management	27
5.1 Eksos N20 Node Manager	28
5.2 Nokia NMS	28
5.3 Eksos N20 Network Management Products	29
5.4 OSI-DCN Adaptor	30
5.5 Eksos Q3 DCN	31
Chapter 6	
Construction and power supply	33
6.1 Interface types	33
6.2 Node architecture	34
6.3 Installation options	35
6.4 Power supply options	36
6.5 Thermal management principles	36
6.5.1 General principles	37
6.5.2 Guide-lines for open rack installations	40
6.5.3 Guide-lines for cabinet installations	42
Chapter 7	
Eksos N20 products	43
7.1 Common units	43
7.1.1 Node Control Unit	43
7.1.2 Line Measurement Unit	44
7.2 Interface units	44
7.2.1 STM-1 CORE2M unit	44
7.2.2 PSTN interface unit (32-channel)	44
7.2.3 ISDN BRA U-interface unit	45
7.2.4 Data Interface Unit	45
7.2.5 TR2M4 unit	46
7.3 Power supplies, subracks and accessories	47
7.3.1 DC-PSA	47
7.3.2 Extension Unit	47
7.3.3 Capacitor Unit	47
7.3.4 Eksos N20 17-slot subrack	47
7.3.5 Eksos N20/SAN 17-slot subrack	48
7.3.6 Eksos N20 8-slot cartridge	48
7.3.7 Eksos N20/SAN 8-slot cartridge	49
7.3.8 Fan Unit	49
7.3.9 Air deflectors	49
7.3.10 Cable trays	50
7.3.11 Wall Mounting Set	50
7.4 Software products	51
7.4.1 Node software	51

7.4.2	Eksos N20 Node Manager	51
7.4.3	Software upgrade kits	51

Chapter 8

Technical specifications	53
8.1 Interfaces	53
8.1.1 2 Mbit/s interfaces	53
8.1.2 PSTN interface	54
8.1.3 ISDN BRA U-interfaces	54
8.1.4 Data interfaces	55
8.1.5 STM-1 interfaces	55
8.1.6 Synchronisation	55
8.1.7 Management interfaces	56
8.1.8 Auxiliary interfaces	56
8.1.9 External supervisory interfaces	56
8.2 Line testing	57
8.2.1 PSTN tests	57
8.2.2 ISDN BRA tests	58
8.3 Power consumption	59
8.4 Mechanical specifications	59
8.4.1 Subrack extension board connectors	59
8.4.2 Cartridge extension board connectors	60
8.4.3 Mechanical dimensions	60
8.4.4 Weights	61
8.5 Environmental specifications	62
8.5.1 EMC Immunity	63
8.5.2 EMC Emission	64
8.6 Eksos N20 Node Manager system requirements	66
8.7 International recommendations	67
8.7.1 2 Mbit/s interface specifications	67
8.7.2 V5.1/V5.2 specifications	67
8.7.3 SDH specifications	68
8.7.4 Synchronisation	68
8.7.5 Miscellaneous	69
8.7.6 ISDN BRA (U) interfaces	69
8.7.7 PSTN voice frequency specifications	69
8.7.8 Data interface unit	70
8.7.9 HDSL	71
8.7.10 Optical fibre	71
8.7.11 Power supply	71
8.7.12 Network	71
8.7.13 Environmental	72
8.7.14 Management	73

Chapter 1

About this document

This document provides a general level description of Nokia Eksos N20 Narrowband Multiservice Access Node and covers the following topics:

- An introduction to Eksos N20 (Chapter 2)
- The features of Eksos N20 (Chapter 3)
- The requirements for Eksos N20 applications (Chapter 4)
- The principles of node management (Chapter 5)
- Eksos N20 construction and power supply (Chapter 6)
- The functions of the individual Eksos N20 units (Chapter 7)
- Technical specifications (Chapter 8).

Instructions for installing and commissioning Eksos N20 are given in their own documents. Both the *Nokia Eksos N20 User Manual* and *Nokia Eksos N20 Product Overview* are available on CD-ROM.

For brevity, *Eksos N20* is used in place of Nokia Eksos N20 Narrowband Multiservice Access Node.

Chapter 2

Introduction to Nokia Eksos N20

Nokia Eksos N20 is an optimised multiservice access node that provides Public Switched Telephone Network (PSTN) and Integrated Services Digital Network (ISDN) services, with efficient packing density and high reliability, to telecom operators. Eksos N20 offers digital cross-connect with a variety of data interface units. Subscriber interfaces can be upgraded remotely for cost-efficient migration from PSTN to ISDN and narrowband to broadband. Eksos N20 supports the use of either an integrated SDH add-drop multiplexer or terminal multiplexer.




Figure 1 Eksos N20 in a 17-slot subrack

The switch interface is concentrating V5.2. Eksos N20 can gather small, non-concentrating V5.1 links into larger V5.2 interfaces, thus performing V5.1 to V5.2 conversion. This V5.1 to V5.2 conversion is implemented with the TR2M4 plug-in unit.

Eksos N20 also supports multihosting, where subscribers from one access node are connected to different local exchanges (LE) or different V5.2 interfaces. The Eksos N20 node can also extract data connections to a data network.

Eksos N20 supports test-in and test-out line tests without any external cabling. Also, scheduled line tests can be run on selected lines and interfaces.

With the Data Interface Units (DIU), Eksos N20 supports direct data connections, providing leased line services for both residential and business customers. Data connections to remote locations can be provided over copper lines with a High bit rate Digital Subscriber Line (HDSL) or ISDN Digital Subscriber Line (IDSL) line terminal.

Non-switched data or voice-frequency (VF) and switched PSTN/ISDN services can be combined in the same node by making use of the non-blocking cross-connection feature. This enables efficient and flexible capacity grooming and redirecting of information on request.

Eksos N20 can be installed in 17-slot subracks or 8-slot cartridges either on its own or together with SYNFO NET Access Node (SAN). With all installation options, all cable connections for the interfaces are available on the front panel.

Chapter 3 Features

Eksos N20 is a modular product consisting of several plug-in units and software options. These elements can be combined to build different node types with specific functionalities.




Figure 2 Eksos N20 as a part of network

Based on its modular structure, Eksos N20 includes the following features:

- integrated SDH
- V5.2 interfaces
- multihosting V5.2
- V5.1 to V5.2 conversion
- local and remote data interfaces
- remote service switching
- line testing
- hot insert
- external alarms.

3.1 Integrated SDH

Eksos N20 supports integrated SDH connections; it can act as an SDH add-drop multiplexer or terminal multiplexer. The integrated SDH is implemented with the optional SYNFFONET Access Node, which can be installed in the same subrack as Eksos N20 units, to provide SDH STM-1 interfaces. The basic application for PSTN and ISDN BRA (Basic Rate Access) services is shown in Figure 3.




Figure 3 Integrated SDH service

Additional 2 Mbit/s interfaces can be used for data services or for carrying additional V5.2 traffic to a second access node. A single subrack equipped with SDH, ISDN and PSTN units can serve up to 448 PSTN customers or 224 ISDN BRA customers.

3.2 V5 interfaces

V5 is an ETSI/ITU-T standard for a signalling interface between the access network and local exchange. There are two variants of the standard, V5.1 and V5.2, both based on the use of 64 kbit/s interfaces and 2 Mbit/s links.

V5.1 is a single 2 Mbit/s interface which supports PSTN and ISDN BRA user ports. In V5.1, bearer channels for user ports are allocated statically. In V5.2, dynamic bearer channel allocation, that is, concentration, is included in the design.

- Eksos N20 supports V5.2 interfaces and tributary V5.1 interfaces.
- Eksos N20 supports up to 16 x 2 Mbit/s links per V5.2 interface.
- Eksos N20 node sizes are flexible and each node can be built to support up to:
 - 512 local PSTN subscribers under a V5.2 interface
 - 1440 PSTN subscribers behind V5.1 tributary interfaces.

3.3 Multihosting V5

The multihosting V5 capability gives operators the freedom to connect subscribers from one Eksos N20 node to any of the several V5.2 interfaces configured to the node. The subscribers can be connected to the node either locally or remotely via the V5.1 interface. Eksos N20 can behave as a V5.2 concentrating multiplexer with up to four logical V5.2 interfaces that are provided by the same or different local exchanges (LE).




Figure 4 Multihosting V5.2 interfaces to different local exchanges

Multihosting is implemented with additional Node Control Units (NCU). Each interface requires at least one NCU, and may need more depending on the number of 2 Mbit/s links that are needed for the application. There can be up to four V5.2 interfaces in one Eksos N20 node.

Multihosting may be necessary for load balancing between local exchanges or for taking advantage of the services offered by the various exchanges. Some exchanges may offer only basic PSTN and ISDN services, while some offer also advanced services, such as CENTREX.

3.4 V5.1 to V5.2 conversion

Eksos N20 supports tributary V5.1 to aggregate V5.2 conversion. Conversion from V5.1 to V5.2 provides a way to introduce concentration into those parts of the network that were originally built with V5.1. The conversion allows you to upgrade your network and continue to connect to V5.1, for example, in business premises. Conversion from V5.1 to V5.2 is implemented with the TR2M4 unit, which supports up to 4 x 2 Mbit/s V5.1 tributary interfaces.




Figure 5 Conversion of V5.1 interfaces to V5.2 interfaces

In larger V5.2 interfaces, it is possible to use higher concentration ratios, thus making the application more cost-effective.

This multiple V5.1 to V5.2 concentration is general in nature. Hence, it can also be applied to the concentration of V5.1 interfaces from other types of access multiplexers such as Nokia ACM2. Local PSTN and ISDN interfaces are also supported under the same (or a second, if required) V5.2 interface. Eksos N20 also supports efficient and flexible capacity grooming.

3.5 Leased line applications

In addition to on-demand connections and semipermanent POTS/ISDN leased lines under V5.2, Eksos N20 provides flexible leased-line functionality and cross-connection capability.

Although the data applications are shown in Figure 6 separately, both leased line data and V5.x functionality can be combined in the same node.




Figure 6 Fixed data network for providing leased line data services

Eksos N20 supports LL connections via two-wire PSTN interfaces, ISDN interfaces, fractionally used G.703/G.704 2 Mbit/s interfaces, local data interfaces via the Data Interface Units (DIU) and remote data interfaces. The last mentioned can be established via stand alone modems, DNT128 using ISDL (practically an ISDN U-interface (2B + D)), DNT2M through HDSL equipment ACL2 and ACL4, and DNT2M-G (for in-house use with TR2M4). Also, support for remote

access MUX (Nokia ACM2) is offered through the 2M tributary interface combining V5.1 and LL services under the same 2M links.

Eksos N20 has a general-purpose 64 kbit/s cross-connect function. This allows effective grooming of data into the minimum number of 2 Mbit/s aggregate links towards the leased line network. Also local cross-connections between the tributary interfaces of Eksos are supported. Eksos N20 can behave as a basic non-blocking 68 x 2 Mbit/s cross-connect node with $n \times 64$ kbit/s granularity.

Cross-connection functionality also supports carrying leased lines under V5 links if the V5.2 switch supports this.

Support for multiple cross-connection configuration sets

Eksos N20 supports two parallel configuration sets (banks) for the leased lines. Each bank is a complete set of leased lines. Only one bank is active at a time. Banks can be used for different profiles, for example, one bank for daytime and the other for night-time operations.

Banks can also be used for efficient defragmentation of 2 Mbit/s interfaces. The 2 Mbit/s interfaces of the provisioned leased lines may contain many small gaps with free time slots. If a customer requests a higher-capacity leased line, the necessary time slots may be available, but they may not be consecutive. The existing leased lines can now be copied to the inactive bank and edited to obtain a large block of free time slots. The new, edited leased line can then be provisioned in the inactive bank, and finally the banks are switched.

Bank switching causes the minimum possible disturbance to the ongoing traffic. Those leased lines that are identical in both banks are not affected at all. The leased lines with one of the endpoints different will encounter a short interruption lasting for a couple of seconds.

Local LL interfaces

For PSTN and ISDN-U interfaces, Eksos N20 supports semipermanent leased lines under the control of V5.2. Both types of interfaces can also be configured as permanent leased lines. For ISDN-U, the options for different connections include 1B, 2B and 2B+D. For the 1B leased line, partial provisioning is supported, allowing the B- and D-channel to be provisioned for on-demand use under V5.2. If both B-channels are used for leased lines, the D-channel can be used for packet applications under V5, provided that the LE supports this.

Data Interfaces are supported via Eksos Data Interface Units (DIU), which come in three variations:

- A DIU-VV unit has four V.x/X.21 interfaces. Each of these can be configured as EIA530A, V.24, V.35, V.36 or X.21 interface.
- A DIU-GG unit has four G.703 interfaces of 1x64 kbit/s each.
- A DIU-VG unit has two V.x/X.21 interfaces and two G.703 interfaces.

Using a DIU, it is possible to collect data users near an Eksos. The maximum distance depends on the data interface used. If data users are further away, then network terminals are the best way to collect them to an Eksos N20 node, see “Remote LL interfaces” below.

2 Mbit/s G.703 interfaces are available through NCU and TR2M4 units, which both have four 2 Mbit/s interfaces. Time slots (excluding TS0) can be freely allocated for leased lines, V5 applications or management channels.

Remote LL interfaces

Network terminals provide a highly functional, operationally efficient and cost-effective end-to-end access network solution. They can fulfil customers’ needs in various data access applications.

Eksos N20 supports three different types of network terminals. DNT128 is supported via Eksos ISDN-U IF units. DNT2M is connected to TR2M4 via ACL4 HDSL equipment and DNT2M-G directly.

- **DNT128** is Nokia’s stand-alone terminal providing a maximum of 2 x 64 kbit/s leased lines over the ISDN-U interface (IDSL).

The supported data interfaces are V24/V.28, V.11/V.36, V.35, X.21/V.11, G.703/64 kbit/s, EIA-530-A, and 10Base-T (Router/Bridge). Rate adaptation for different bit rates is supported. For more information, refer to *DNT128 User Manual*.

With the DNT128 terminal, the D-channel can be used for Q1 management traffic from DNT128 to the Q1 management system (NMS10).

- **DNT2M** is a 2 Mbit/s stand-alone HDSL network terminal for n x 64 kbit/s (n = 1...31) transport over the subscriber loop using two twisted copper pairs. The supported data interfaces are V24/V.28, V.11/V.36, V.35, X.21/V.11, G.703/64 kbit/s, G.703/2M, G.704/2M, EIA-530-A, and 10Base-T (Router/Bridge).
- **DNT2M-G** is a 2 Mbit/s stand-alone G.703/G.704 network terminal, with HDB3 line coding, for n x 64 kbit/s (n = 1...31) transport over the subscriber loop using two twisted copper pairs. The supported data interfaces are V24/V.28, V.11/V.36, V.35, X.21/V.11, G.703/64 kbit/s, G.703/2M, G.704/2M, EIA-530-A, and 10Base-T (Router/Bridge).
- **ACL4** is a line terminal for E1 transport over twisted copper pairs. It provides two separate user data interfaces and an ETSI-compliant framing structure. The total capacity is 2 x 2 Mbit/s. The user data is conveyed either transparently or in a G.704/2M frame structure. For further information, please see *ACL4 Line Terminal User Manual*.

Network topologies utilising a remote access multiplexer under Eksos N20 are supported via NCU/TR2M4 2M interfaces. In addition to V5.1 connection delivered through TR2M4, the leased line time slots can also be configured under tributary 2M interfaces and further terminated at the local interfaces of the remote multiplexer.

3.6 Remote service switching

Remote service switching provides operators with a fast, convenient and cost-effective way of upgrading subscriber services without immediate visit to the equipment site. The site visits can be planned and optimised independently, so that when normal maintenance visits are made to the site, subscriber lines that have been reconfigured using the service switch feature can be permanently reassigned to a suitable interface type, thus freeing the capacity for further remote service switches.




Figure 7 Principle of service switch. POTS to ISDN upgrade as an example

There are several options for configuring and utilising the service switch functionality to give an optimum value for different site applications. For an optimum run-time flexibility, the actual configuration can even be done by reconfigurable wiring at the site distribution frame. For those cases where more static configurations are preferred, point-to-point cables can offer a compact and quick-to-build solution. For optimum life time performance and cost, it is important to consider the use and advantages of the service switch already when the installation procedures are being planned.

Subscribers may be upgraded, under network management control, as follows:

- PSTN to ISDN
- PSTN to ADSL
- ISDN to ADSL
- PSTN to combined ADSL + PSTN
- ISDN to combined ADSL + ISDN.

As there is a certain amount of flexibility in utilising and configuring the service switch service on the site, the management functionality of the node offers support for modelling the installed configuration into the node database. With this feature on place, the service switch and its status can be easily managed through the remote management system.

3.7 Fault tolerance

The reliability of Eksos N20 is increased by the use of a decentralised power supply system, in which all units are equipped with their own, unit level power supplies.

Configuration backup is provided by all Eksos N20 units, except PSTN units. Any unit, including the NCU, can be replaced without loss of configuration data.

The reliability of data transmission can be enhanced by installing two NCUs in Eksos N20, providing change-over equipment at the other end, or routing the signals through different routes or via SDH.

3.8 Line testing

Line testing reduces the cost of access network maintenance by enabling efficient remote fault tracking. Eksos N20 allows testing of copper lines to monitor the quality of the lines, detect and track faults, and predict the availability of the lines for the planned services.

Eksos N20 supports both on-demand and scheduled line testing. Scheduled line tests can be run on selected lines and interfaces. This feature allows discovery and correction of degraded performance before it becomes apparent to subscribers.

Line tests can be run without any external cabling using a Line Measurement Unit (LMU) in the subrack. LMU measures the subscriber lines, including the terminal equipment, that are routed through the PSTN or ISDN units. ISDN loopback and activation or deactivation tests can be done without any additional units.

Eksos N20 Node Manager is the primary tool used for configuring tests and for collecting, storing and analysing the test results. Nokia NMS provides a centralised line test management interface for the Eksos N20 access network and can be integrated in the operator's own line test management system.




Figure 8 Eksos N20 line test application

Test control and result management

Eksos N20 offers two alternative methods for activating the test functions.

On-demand activation is intended for applications where activation of the test is always directly initiated by external resources, such as service personnel or a line test management system.

Scheduled activation utilises an in-built timing function in Eksos N20. This allows test timing to be defined independently of the running of the test. This feature is specifically useful for proactive measurements run periodically during night time. The idea of proactive measurements is to find out beforehand about possible problems on the subscriber lines.

Depending on the type of the test, the results read from the node are either **Pass/Fail** type indications or more complex arrays of numerical values.

To simplify the management of the measurement results, **configurable thresholds** can be set for measurements producing numeric values. Typically, **Min/Max** definitions are allowed. When users upload the results, they are offered an option of filtering out those results that do not exceed the set limits (option **Get failed**). It is also possible to upload all results (option **Get all**).

Eksos N20 allows several independent tests, including various schedules, measurements and threshold sets that can be configured simultaneously for different sets of interfaces. This allows for enhanced monitoring of different types of interfaces.

Tests can be run using **Reject test**, **Wait if busy** or **Cut call** criteria. The first two of these do not allow ongoing calls to be interrupted. If the **Reject test** criterion is used, the test attempt is cancelled for the active interfaces. If the **Wait if busy** criterion is used, the test in case is activated if the interface is released within a configurable wait time. The **Cut call** criterion allows activation of the test even if there was an ongoing phone call on the line. In this case, the measurement results

can differ from normal results, since the subscriber line is active at least in the beginning of the measurement period. For PSTN lines, call attempts originating during the test can be detected.

Test-out (subscriber cable measurements)

Test-out tests include measurement of the basic cable parameters of PSTN and ISDN subscriber lines. The results are numerical values. These values can be further processed on the node, based on user-configurable thresholds.

Test type	Result format	Criteria, thresholds	Activation
Basic test-out (electrical tests), including measurements for the following subtests: – AC _{RMS} voltage (a–gnd, b–gnd, and a–b) – DC voltage (a–gnd, b–gnd, and a–b) – Capacitance (a–gnd, b–gnd, and a–b) – Leakage resistance (a–gnd, b–gnd, a–b, b–a, a–batt, and b–batt)	Pass, Fail. Subtests: Value & status	All subtests' status OK. Subtests configurable: Low, High	On-demand/ scheduled
Loop resistance measurement R _{a-b}	Value & status	Configurable Low, High	On-demand/ scheduled

Table 1 Supported test-out measurements

The overall status of the test is reported as **OK**, **Overvoltage**, **Access-Fail**, or **Off-hook**.

An overvoltage check is run before each measurement is started. If the detected foreign voltages are higher than the protection limit in the LMU, the test session is terminated and no other tests are run.

The measurement-specific status can be **OK** or **Not meas**. Some of the measurements may report **Not meas** to indicate a value that cannot be measured because of non-linear parameters or excessive external voltages.

Test-in

Test-in tests include measurements to verify and diagnose the equipment, or even the network, in the aggregate direction. As these tests verify the functioning of the equipment itself, it is possible to make decisions according to measurement results based on pre-defined parameters. Thus, these measurements typically deliver **Pass/Fail** results instead of numerical values.

PSTN Test-in tests	Result format	Criteria, thresholds	Activation
PSTN interface diagnostic test, including the following subtests: – Feeding voltage test – Feeding current test – Loop detection test – Ring trip detection test – Ringing current test – Private meter pulse test – CODEC test	Pass, Fail. Subtests: OK/ NOK	All subtests OK. Subtests: fixed value	On-demand/ scheduled
Dial tone test	Pass, Fail	Dial tone detected	On-demand/ scheduled

Table 2 Supported PSTN test-in measurements

PSTN diagnostic test uses the in-built circuitry to stimulate and verify the condition of signalling and voice handling of the interface.

The dial tone test is run by activating a test loop on a PSTN interface (simulating an originating call), which activates the call establish procedure towards the LE.

Functional ISDN tests

Eksos N20 offers several mechanisms to support functional ISDN fault tracking.

Faults can be located by running ISDN loopback tests. The loopback tests can separately check the condition of the interface and the line. A timer can be set to deactivate the loop after a certain period. The following tests, specified in ETS 300 012, are available:

ISDN loopback tests	Result format	Criteria, thresholds	Activation
Loop1 (in line termination (LT))	Pass/Fail	1)	On-demand
Loop1A (in repeater (REG))	Pass/Fail	1)	On-demand
Loop1A (in regenerator (REG))	Pass/Fail	1)	On-demand
Loop2 (in NT1)	Pass/Fail	1)	On-demand
1) A selectable test pattern can be inserted and compared with the signal received through the loop. The criteria for comparing the received data is stated in Node Manager as Percentage of error seconds . There is a fixed threshold that will define the result of loopback test as Fail if more than 5% of the seconds during the loopback activation time are erroneous.			

Table 3 Supported ISDN loopback tests




Figure 9 Different loopbacks available in Eksos N20 ISDN unit

With Loop2, it is possible to loop either the B1 or B2 channel separately or both at a same time. For Loop1/1A, only the B1B2 loop is available.

Further analysis can be done by means of ISDN remote tests, which have been designed basically for the same purpose as the ISDN loopback tests. They can be used for more detailed troubleshooting purposes by an experienced technician.

ISDN Remote tests	Result format	Criteria, thresholds	Activation
Partial activation test	Pass/Fail	NT confirmation	On-demand
Full activation test	Pass/Fail	NT confirmation	On-demand
Node sends corrupt CRC to NT1 *)	Pass/Fail	FarEndBlockError alarm	On-demand
NT1 sends corrupt CRC to node *)	Pass/Fail	NearEndBlockError alarm	On-demand
Hold NT1 state *)	Pass/Fail	NT confirmation	On-demand
Node sends pulse mask to NT1	Pass/Fail	NA	On-demand
*) only with ISDNQ			

Table 4 Supported ISDN remote tests




Figure 10 Remote tests available in Eksos N20 ISDN unit

Full activation test

Full activation test activates the ISDN interface from the node up to the terminal equipment. This test passes only if there is a running TE connected to the S-interface of the NT and the U-interface between the NT and LT is working correctly.

Partial activation test

Partial activation test activates the ISDN interface up to the NT. This test passes if the U-interface between the NT and LT is working correctly. By running both tests, it is possible to check if the problem under investigation is located somewhere in the terminal equipment.

Node sends corrupted CRC to NT

The ISDN interface (LT) starts to send corrupted CRC, which will be detected by the NT. As a result, the NT will set the FEBE (FarEndBlockError) bit active in the U-interface. For detecting the FEBE alarm, the performance monitoring function must be switched ON.

NT1 sends corrupted CRC to LT

The ISDN interface (LT) requests the NT to send corrupted CRC to upstream direction. The LT will set the NEBC (NearEndBlockCounter) active. For detecting the NEBC alarm, the performance monitoring function must be switched ON.

Hold NT state

The EOC processor of the NT can be set into HOLD state when running this test.

Node sends signal pulse mask to NT

The ISDN interface will send single pulses to the U-interface. The pulses are issued at 1.5 ms intervals and with the duration of 12.5 μ s.

Other services

External Test Access can be utilised to access the cable pairs through the external test access interface of the LMU unit. This access point can be used as a connection point for external instruments used by the service staff or as an inter-system connection point for an external measurement head.

Dry loop can be activated for a selected channel to disconnect the PSTN and ISDN speech and signalling circuitry from the line if the service operation requires this.

Cable pair identification tone can be sent to a selected channel.

3.9 Hot insert

Eksos N20 supports a hot insert feature. Owing to this feature, Eksos N20 is able to detect and, after configuration, use hardware that has been added to Eksos N20 while it is actively running.

3.10 External alarms

At any one time, up to fourteen external alarms can be defined. The severity and alarm text for each input and output are user-defined. After the alarms have been defined, they will be shown in the alarm lists.

The NCU and LMU each have the following External Alarm inputs:

- 3 x Digital Inputs (PAIx)
- 2 x Digital inputs/Outputs (PAIOx)
- 2 x Analog Inputs (IAVx).

Consequently, if a node contains one NCU and one LMU, it will contain:

- 6 x Digital Inputs (PAIx)
- 4 x Digital inputs/Outputs (PAIOx)
- 4 x Analog Inputs (IAVx).

Chapter 4

Application planning

Eksos N20 can be used for a variety of purposes. The following describes the typical node applications.

The Eksos N20 node connects basic PSTN/ISDN users to the local exchange (LE) through the ETSI standard V5.2 interface, as shown in Figure 11. Conversion from V5.1 to V5.2 interface is supported, and this provides an effective growth path, via V5.2 interfaces, to those parts of the network that were originally built with V5.1.

Eksos N20 supports also data users. A multiple non-blocking 64 kbit/s cross-connection service is provided within the node, and various interfaces can be added to provide data services. Different traffic types can be combined, split or groomed as required.

The aggregate interface to the network can be either a standard 2 Mbit/s interface or STM-1.




Figure 11 Typical application of Eksos N20 system

4.1 Requirements for all applications

For all node applications, you will need at least the following:

- a minimum of one NCU unit
 - in slot one if Eksos N20 subrack/cartridge is used
 - in slot three if Eksos N20/SAN subrack or cartridge is used
- node (NSAP) address to identify the node in the network
- node name and its location information
- information about synchronisation sources
- information about the time slots used for Q3 traffic
- local exchange (LE) information.

Each NCU provides four 2 Mbit/s links that can be associated with any V5.2 interface. One 2 Mbit/s link can carry up to 30 (or 31 if time slot 16 is not used for signalling) simultaneous phone calls.

In addition to the above, additional units and information is needed according to the application used. These requirements are listed in sections 4.2 to 4.6.

Restrictions

There can be up to four V5.2 interfaces in a subrack; each V5.2 interface requires at least one NCU.

4.2 V5.2 multiplexer

Requirements

The configuration of the V5.2 interface must be exactly the same in Eksos N20 and local exchange. In one subrack, there can be up to four V5.2 interfaces.

For a V5.2 multiplexer, you will need the following:

- plug-in units
 - a minimum of one NCU in slot one (Eksos N20 subrack/cartridge) or slot three (Eksos/SAN subrack or cartridge); one NCU is needed for each V5.2 interface
 - PSTN and ISDN units for subscriber interfaces; each PSTN unit has 32 interfaces, each ISDN unit has 16 interfaces
- configuration information about the V5.2 interfaces at the LE
 - interface ID and provisioning variant
 - IDs for the 2M links used to connect to the LE
 - time slots and IDs for the communication channels
 - time slots used to provide protection
 - L3 and EF addresses for user ports (= subscriber interfaces).

Each NCU provides four 2 Mbit/s links that can be associated with any V5.2 interface. One 2 Mbit/s link can carry up to 30 (or 31 if time slot 16 is not used for signalling) simultaneous phone calls.

Example

An example configuration is shown in Figure 12.




Figure 12 Example configuration for a V5.2 multiplexer

In the example of Figure 12, you could also slightly increase the concentration so that only four links (that is, one NCU) were needed. This would leave room for another subscriber unit in the subrack. If you use two NCUs, the remaining three links can be used to provide leased lines or to reduce concentration (notice, however, that this requires more capacity on the LE, too). The remaining three links can also be used to build up a second V5.2 interface for multihosting purposes.

4.3 V5.1 to V5.2 converter

Requirements

The configuration at both ends of a V5 interface must always match. In the converter application, the configuration of the V5.2 interface must match the configuration information at the local exchange (LE) and the configuration of the V5.1 interfaces must match the configuration information in the V5.1 node.

For a V5.1/V5.2 converter, you will need the following:

- plug-in units
 - a minimum of one NCU in slot one (Eksos N20 subrack/cartridge) or slot three (Eksos/SAN subrack or cartridge)
 - a minimum of one TR2M4 unit to provide a V5.1 interface to the V5.1 node (one TR2M4 unit can connect to four V5.1 nodes)
- configuration information about the V5.2 interfaces at the local exchange (LE)
 - interface ID and provisioning variant
 - IDs for the 2M links used to connect to the LE
 - time slots and IDs for the communication channels
 - time slots used to provide protection
 - L3 and EF addresses for user ports (= subscriber interfaces)
- configuration information about the V5.1 multiplexers
 - physical 2 Mbit/s used for Eksos N20
 - time slots for the communication channels
 - time slots used for user ports and their addresses
 - information about possible leased lines on the V5.1 node.

4.4 Service switch

Requirements

For a service switch, you will need the following:

- plug-in units
 - a minimum of one NCU in slot one (Eksos N20 subrack/cartridge) or slot three (Eksos/SAN subrack or cartridge)
 - PSTN and/or ISDN units
 - to provide ADSL services, broadband equipment should be available.
- application specific installation and cabling
 - the service switch cabling must be in place
- configuration information
 - configuration information of the V5.2 user ports and their addresses
 - information about the service switch cabling. It is often logistically efficient to standardise the configurations for sets of node types.
 - cabling information about other equipment, such as broadband equipment.

Phases

Switching a service is done in three phases:

1. Preparing the service switch cabling. This phase is the most efficient when the service switch is taken into account in the initial installation. The cabling information is also configured in the node.
2. Switching services for one or more subscriber lines. This is done when a customer requests upgrading to ISDN or ADSL. Switching is done remotely, without visiting the site.
3. Changing the temporary service switches into permanent ones and releasing the resources for new remote service switches. This should be done during the first site visit after the service upgrade.

Restrictions

When configuring the service switch, take into consideration the following restrictions:

- one service switch connection per plug-in unit
- each plug-in unit can access one out of two accessible bus lines
- up to eight service switch connections for PSTN units per subrack
- up to eight service switch connections for ISDN units per subrack
- service switch connections are not activated during ongoing line tests
- line tests have higher priority than service switch connections if the **Super Cut Call** option is used in line testing.

4.5 Leased line applications

Requirements

For leased line applications, you will need the following:

- mandatory plug-in units
 - a minimum of one NCU in slot one (Eksos N20 subrack/cartridge) or slot three (Eksos/SAN subrack or cartridge)
- optional plug-in units
 - depending on the leased line utilised, either PSTN, ISDN, Data or TR2M4 units
 - ISDN unit in ISDL mode for remote application via DNT128
 - in case of remote application, you may use Nokia HDSL line cards to provide the high speed connection over subscriber cable pairs. ACL4 can be installed in the Eksos subrack, whereas ACL2 needs its own mechanics. At the remote end, you have the choice of Nokia stand-alone terminals and plug-in ACL4/ACL2 line terminals, for example, in the case of a remote access multiplexer.
- configuration information about the leased lines
 - configuration information about the interfaces and time slots that will be used for leased lines

- configuration information about other equipment
 - configuration information of the data terminals.

Special care must be taken to ensure that the configuration of leased line data interface parameters, bit allocations to time slots and possible bit masks are the same at both ends of the leased line connection.

Restrictions

A full ISDN leased line reserves three time slots: two for B-channels, each 1 x 64 kbit/s, and one for D-channel, 1 x 16 kbit/s. Although the D-channel has a bit rate of 16 kbit/s, it is cross-connected at the 64 kbit/s level.

In case of $n \times 64k / n > 1$ connections, all time slots used for a single leased line must be consecutive ones. For example, a single leased line can use time slots 11, 12 and 13, but not 11, 12 and 14.

4.6 Scheduled line testing applications

Requirements

For an application for scheduled line testing, you will need the following:

- plug-in units
 - a minimum of one NCU in slot one (Eksos N20 subrack or cartridge) or slot three (Eksos N20/SAN subrack or cartridge)
 - an LMU
 - PSTN or ISDN units
- information about tests
 - how often and when are the tests run
 - list of tests to be run
 - list of interfaces on which the test will be run.

Restrictions

The lines to be tested must be in V5 use. The configuration at both ends of a V5 interface must always match. The configuration of the V5.2 interfaces must match the configuration information at the local exchange (LE) and the configuration of the V5.1 interfaces must match the configuration information in the V5.1 node.

Up to ten scheduled tests can be specified.

One LMU is needed for each Eksos N20 subrack.

Although the POTS diagnostic test has a good coverage, it cannot guarantee full functionality.

Chapter 5 Management

Eksos N20 is supported by a suite of management tools, which can be used either separately or as an integrated system.

Eksos N20 has an ITU-T specified interface (Q3) for Nokia Network Management System (NMS) and Eksos N20 Node Manager. The nodes are interconnected using a time slot x in the E1 or direct network management (Q3 Ethernet) connections. Local and remote access are supported simultaneously.




Figure 13 Management for Access Network

Software upgrades can be done by downloading new software versions to the node via the network management interface. This can be done locally or remotely.

Eksos N20 provides features to implement the Q1 DCN (Data Communication Network) to manage Q1-managed equipment in the network.

Eksos N20 also acts as Q1 router and supports the building of the Q1 DCN for Q1-managed equipment. Due to this, the management information from, for example, DNT128, DNT2M or ACM2, can be brought via the Eksos N20 node to the Q1 management system.

5.1 Eksos N20 Node Manager

Eksos N20 Node Manager provides control over all the configuration and operation details of a single Eksos N20 network element, including download and activation of software upgrades. Node Manager is a Windows NT application program which runs on a standard PC.

Node Manager is used for the following functions:

- bringing units into use, and providing each unit and individual channel with the appropriate settings required for the application
- obtaining status information from an Eksos N20 node, including information about any alarms which have been generated on the node
- reconfiguring an Eksos N20 node to modify its role in the network
- subscriber line testing and fault reporting, provided that an LMU is included in the configuration.

Node Manager manages a node interactively. When Node Manager is managing a node, it can request various data from the node about its current state. For example, Node Manager can request from the node a list of its current alarms or a list of its cross-connections.

Eksos N20 Node Manager incorporates an optional security feature. The system administrator can allocate each user to an access level which determines what changes, if any, that particular user can make to the node.

5.2 Nokia NMS

Nokia Network Management System (NMS) provides higher-level integration for the element managers of Eksos N20 and other network elements. Nokia NMS supports fault, performance, configuration and security management for access and transmission networks.

Management of Eksos N20 with Nokia NMS/10

NMS/10 is an element-level management system, which can be used either for small transmission networks or as part of the management solution for larger networks.

Nokia NMS/10 supports management of Eksos N20 from Nokia NMS/10 release C5.1 onwards.

The NMS/10 System Release consists of a core program, the System Frame, and separate agents, mediators and node managers. Agents collect alarms and performance data from various network elements. For Eksos N20 management, Q3 Agent C2.0 component is used.

NMS/10 System Frame provides a network-level user interface and database system management. NMS/10 System Frame runs on top of Hewlett Packard's OpenView Network Node Manager for Windows NT product. HP OpenView NNM has been extended by Nokia to provide a generic user interface for networks consisting of Nokia's network elements.

Q3 Agent C2.0 is a software program that collects alarms and performance data from Eksos N20 nodes on the network. Alarm information is stored in the "run-time" memory of the computer on which the Q3 Agent is running, and the destination management systems are notified via SNMP. Performance data is saved to disk files on the Q3 Agent computer and it can be separately retrieved via FTP.

Eksos N20 Node Manager is used to configure the nodes. Node Manager is an independent program. The System Frame integrates Eksos N20 (and other) node managers by making them available for launch. This can be done by, for example, double-clicking a node symbol on a submap.

5.3 Eksos N20 Network Management Products

Nokia NMS can be complemented with optional management applications that support Eksos N20 management. These products facilitate the maintenance of the access network and certain service management functions. The products utilise the V5 fragment of Nokia NMS database, which is also accessible to the operator's system. The following functionalities are available:

- Remote software download of Eksos N20
- Backup of entire node configuration (automatic)
- Backup of V5 data in the database (automatic)
- Database reports
- Remote service upgrade
- V5.1 tributary management
- Line test management.
 - A Line Test Manager is available for customisation with the operator's information systems. The connection to the operator's database describing relations of directory numbers, V5 attributes and physical interfaces must be tailored at each system deployment, as there are no standard solutions available.

For further information of these products, refer to *Eksos N20 Network Management Products NMS Tools Product Overview*.

5.4 OSI-DCN Adaptor

OSI-DCN Adaptor is used for building the management DCN network between Eksos N20 sites and the central network management site.

OSI-DCN Adaptor is connected, via an Ethernet interface, between the Nokia NMS network to the local exchange (LE) or a digital cross-connect system which is in front of the local exchange. The 2 Mbit/s interface of the OSI-DCN Adaptor can provide up to 30 x 64 kbit/s Q3-connections to Eksos N20 nodes. Each OSI-DCN Adaptor has one 2 Mbit/s interface and one active Ethernet interface.




Figure 14 Example of a DCN network for Eksos N20 node management

OSI-DCN Adaptor is a unit that fits into the same mechanics as Eksos N20. It can be installed into the same subrack as Eksos N20, or into a separate subrack.

For further information, refer to the *OSI-DCN Adaptor User Manual*.

5.5 Eksos Q3 DCN

Q3 is a message-based management protocol. Q3 management can be conveyed in a payload 64 kbit/s time slot, using E1, or in the Ethernet connection.

Q3 time slots are cross-connected into E1s, which are connected to Nokia OSI-DCN adaptors. From an OSI-DCN adaptor, they are further connected to an OSI router through the Ethernet port.

At bigger sites, there can be direct access to a router network via the local LAN, using the Ethernet connection in Eksos.

The B-channels of the V5 E1 links cannot be used for management because most of the local switches do not support fractional E1 links, where some of the B-channels are outside the V5 E1. On the other hand, Q3 cannot be inside V5 E1, because without an existing V5 connection there is no management connection available.




Figure 15 Q3 DCN using cross-connection close to the local switch

If there are leased line connections configured in Eksos N20, the E1s of these leased lines are used to carry also the Q3 management time slots.

If no permanent leased lines are used, dedicated E1 links need to be reserved for DCN communication.

Leased lines are connected forward to the leased line network, and the Q3 management channel time slots are regrouped to a new E1, which is then

connected to the OSI-DCN adaptor. The OSI-DCN adaptor takes one E1 in and routes the Q3 management data via the Ethernet interface upwards for the OSI routers.

All Eksos nodes within one rack can be connected together using local Ethernet management interfaces. From one of the nodes there has to be one or two Q3 channels upwards, the actual number depending on whether DCN connection protection is used.

If a Nokia DX200 local switch is used, Q3 management channels can be routed in V5 E1 links but outside V5. DX200 supports both fractional V5 and semipermanent connections. Up to 30 Q3 management channels can be connected through the switch to an E1, which is connected to an OSI-DCN adaptor.

Eksos has the OSI stack, which is why OSI routers have to be used for routing.

An OSI-DCN adaptor can support about 100 elements in a level 1 area. There can be two level 1 areas per router. Normally, 100 routers can be connected together in a WAN, thereby providing support for 20000 network elements.

Q3 management channels generate a very small load into a router network. For 100 to 200 elements, the load is typically a few kbit/s. The maximum value is about ten times higher, that is, a few dozen kbit/s.

Chapter 6

Construction and power supply

This chapter briefly describes the interface types, node architecture, installation options and power supply options which are available for Eksos N20. It also describes the thermal management principles for the various installation options.

6.1 Interface types

Eksos N20 nodes are composed of the following types of interfaces:

- PSTN interface
- ISDN Basic Rate Access (BRA) U-interface (2B1Q and 4B3T)
- 2 Mbit/s interface (4 x 2M)
- Data Interface Unit (DIU) interfaces
- STM-1 interface.

6.2 Node architecture

Tributary and aggregate interface units are connected to a common high-speed bus. The main hardware unit, the Node Control Unit (NCU), provides the required core functionality, V5 control functions, node synchronisation, Q3 interface, auxiliary data channel and four 2 Mbit/s aggregate interfaces.

The Line Measurement Unit (LMU) supports on-demand and scheduled line testing.

Various tributary interface units are supported, including PSTN, ISDN BRA U and data (high and low speed); 2 Mbit/s and various other interface types such as STM-1 ADM or TM functionality are also supported.




Figure 16 Node architecture; the basic components of an Eksos N20 node

6.3 Installation options

Eksos N20 units can be installed alternatively in Eksos N20 8-slot cartridges, Eksos N20/SAN 8-slot cartridges, Eksos N20 17-slot subracks or Eksos N20/SAN 17-slot subracks. The cartridges and subracks, in turn, can be mounted into:

- 19" rack according to IEC 297-1 and IEC 297-2
- 600 mm wide rack according to IEC 917, IEC 917-2 and IEC 917-2-1
- 600 mm wide rack according to ETS 300 119-2.

In addition, the 17-slot subracks can be mounted:

- into Nokia Indoor or Outdoor Access Cabinets
- on a wall using the Wall Mounting Set or Nokia Indoor Site.

Nokia Indoor Access Cabinets are intended to be located in basements, corridors, attics or other customer premises. Nokia Outdoor Access Cabinets are compact and reliable solutions for outdoor installations and can also be used in tropical environments.

The wall mounting option is useful when space is limited or when Eksos N20 is installed, for example, in an office.




Figure 17 Eksos N20 node showing the 17-slot subrack and main connectors

6.4 Power supply options

Eksos N20 uses a decentralised power supply system, in which all units are equipped with their own, unit-level power supplies. All units require a 48 V (nominal) supply voltage, distributed to the units through the extension board and the subrack motherboard. This voltage can be supplied direct from the central battery through the DC-PSA.

The power supply options are:

- the DC Power Supply Adapter (DC-PSA): nine outputs; auxiliary voltage, station alarms and storage capacitors
- the DC-PSA plus the Extension Unit: 13 outputs; auxiliary voltage, station alarms and storage capacitors.

One DC-PSA can feed three subracks per rack, whereas the combination of DC-PSA plus Extension Unit can feed four subracks per rack.

RFI/EMI-filtering is provided by means of an extension board, which is fitted to each subrack. The extension board also transfers power to, and station alarms from, the subrack.

A Fan Unit and Capacitor Unit are available as optional accessories.

6.5 Thermal management principles

The temperature of air leaving the installation should always be less than +70 °C.

The thermal behaviour of the node in a subrack is dependent on the particular configuration, the location of the subrack in the installation and the ambient temperature. Every installation type should therefore be examined separately.

Special attention must be paid to the routing of cables so that they do not obstruct the airflow through the installation. Cable routing should be carefully planned and large cable bundles should be avoided in the airflow path.

In nodes with high numbers of PSTN subscribers, the actual traffic density defines the thermal load generated by the system. In more extreme cases, load sharing between several interface units can help to lower the maximum power dissipated by each unit, and hence, lower the peak thermal load.

Note

For detailed information about units' heat dissipation values, see the country-specific document in this manual.

6.5.1 General principles

For the purpose of thermal planning, the system can normally be considered as a “black box” which is defined by certain parameters as shown in Figure 18.




Figure 18 Thermal model

The speed of airflow through each installation is dependent on many factors, including the cabinet structure and, where fitted, the size and speed of fans. Therefore, we recommend that installations which differ from the examples given here are verified with temperature measurements. These measurements should include inlet and outlet air temperatures under both normal and worst case operating conditions.

To achieve reliable operating conditions, the following parameters must be managed:

- the temperature of the air flowing into the system
- the speed of the airflow through the system.

In addition to these parameters, when a system is installed above other systems, the incoming air temperature is affected by the distance between the systems and the effect of air mixing. See Figure 19.




Figure 19 Effect of space between subracks

The distance between the systems contributes significantly to air mixing. The larger the distance is, the more effectively the surrounding cool air can mix with air flowing from the lower subrack to the upper one.

If the subracks are very close to each other, the temperature rise within each subrack will accumulate upwards as shown in Figure 20. When several subracks are installed above each other, ensure that the speed of airflow is increased accordingly.




Figure 20 Cumulative temperature increase

Two types of cooling methods can be used: natural convection or forced convection.

The operation of natural convection systems is based on the physical phenomenon of warmer air having a smaller density than colder air. The restrictions in the use of this cooling method are related to the physical properties of air. In practice, natural convection cooling can induce air velocities of 0.1 – 0.2 m/s through a well-ventilated system. See Figure 21.

Forced convection is based on using some external agency to maintain the airflow. By utilizing Fan Units in the installation, the airflow through the system can be increased and enhance the cooling efficiency of the installation. See Figure 22. Forced convection should always be used if broadband units are likely to be installed in the node.

6.5.2 Guide-lines for open rack installations

For installation dimensions and further details, see the *Installation* document.

Natural convection cooling

The natural convection cooling system should be constructed using 19"/ETSI 4U Air Deflectors and 1U Cable Trays as shown in Figure 21.

The heat dissipation in a natural convection system should not exceed 250 W per subrack (17 slots) and 15 W per plug-in unit. (See the *Specific Instructions for XX* in this manual for detailed heat dissipation values.)




Figure 21 Natural convection cooling system

If wanted, the cooling system can be enhanced by installing fan units in the rack.

Forced convection cooling

The forced convection cooling system should be constructed using 19"/ETSI 1U Air Deflectors, 19"/ETSI Fan Units, and 1U Cable Trays as shown in Figure 22.

The heat dissipation in a forced convection system should not exceed 450 W per subrack (17-slot) and 25 W per plug-in unit. (See the *Specific Instructions for XX* in this manual for detailed heat dissipation values.)



Caution

Forced convection should always be used if broadband units are likely to be installed into the node.




Figure 22 Forced convection cooling system

6.5.3 Guide-lines for cabinet installations

The cabinet must be capable of handling the total thermal load. The total thermal load is affected by the following factors:

- thermal load of the system being considered
- thermal load of all other systems installed in the same cabinet
- thermal load of the systems to be installed into the cabinet in the future
- external thermal load, such as direct sunshine.

If the cabinet is placed in a dirty environment, ensure that the closing degree (Ingress Protection rating) of the cabinet is appropriate.



Caution

Do not obstruct the airflow through the “air channels” of the cabinet.

Indoor cabinet installations

The airflow through the system depends on the overall cabinet design. In general, the integration density and, consequently, the cost efficiency of the site can be greatly enhanced by using Fan Units together with a well-designed cabinet.

The air temperature of the subrack in an indoor cabinet installation is mainly defined by the following factors:

- total power dissipated inside the cabinet
- thermal efficiency of the cabinet
- airflow arrangements inside the cabinet.

Outdoor cabinet installations

The cabinet must be able to handle the total thermal load. The use of a heat exchanger or other method of efficient circulation of external air is recommended for all installations.

The air temperature of the subrack in outdoor cabinet installations is mainly defined by the following factors:

- solar radiation (leading to a significant temperature rise inside the cabinet)
- total power dissipated inside the cabinet
- thermal efficiency of the cabinet
- airflow arrangements inside the cabinet.

Chapter 7

Eksos N20 products

This chapter briefly describes the plug-in units, mechanics, power supplies and software products which are available for Eksos N20. For information about such general mechanics as racks and cabinets, see their own separate instructions.

7.1 Common units

7.1.1 Node Control Unit

The Node Control Unit (NCU) contains a CPU environment for all of the common control functions inside the Eksos N20 node. The NCU contains the core functionalities such as the V5 control functions and node synchronisation. This unit also has a Q3 interface for network management and 4 x 2 Mbit/s interfaces for aggregate use. At least one NCU is always required in each Eksos N20 node.

Each Eksos N20 node can support up to four V5.2 interfaces and there must be at least one NCU per each V5.2 interface.

The NCU supports the following interfaces:

- 4 x 2 Mbit/s interface, 120 Ω or 75 Ω
- synchronising input 120 Ω or 75 Ω
- Q3 interface, 10Base-T and 10Base2
- digital and analog inputs and digital outputs for external alarms.

The NCU supports the following features:

- V5.2 interfaces
- multihosting
- leased line services
- adding NCUs to increase aggregate capacity
- external interfaces to network management (Q1/Q3)
- auxiliary data channel interfaces.

7.1.2 Line Measurement Unit

The optional Line Measurement Unit (LMU) makes it possible to test the condition of copper access lines remotely. It operates in conjunction with the test access relays in the interface units. Also, additional alarm inputs and outputs are available through the LMU.

The LMU supports the following features:

- scheduled tests
- line tests for PSTN and ISDN
- high-accuracy measurement of line parameters such as capacitance, foreign voltage and leakage resistance
- external test access (for testing the lines using external test equipment)
- cable-pair identification-tone test for all line types
- dry loop test
- external alarm inputs (digital and analog) and outputs (digital).

7.2 Interface units

7.2.1 STM-1 CORE2M unit

The STM-1 aggregate can be provided using the SAN CORE2M interface module. This SDH module has 8 x 2 Mbit/s capacity for site connections and it is available with either add/drop or terminal multiplexer functionality.

The STM-1 CORE2M unit supports the following interfaces:

- 8 x 2 Mbit/s interface, 120 Ω or 75 Ω
- synchronising inputs and outputs, 120 Ω (or 75 Ω when using an adapter)
- Q3 interfaces, 10Base2
- one (TM) or two (ADM) STM-1 interfaces for short or long haul applications. Optical connector options available.

7.2.2 PSTN interface unit (32-channel)

The standard PSTN unit provides 2-wire analog interfaces for telephone subscribers. Its flexible architecture supports different national mappings and user port requirements.

Each interface is provided with test access relays, which allow subscriber line tests to be run with a test unit integrated into the Eksos N20 subrack or with an external test unit.

The PSTN interface units support the following features:

- 32 x 2-wire subscriber interfaces
- integrated test access
- switching facilities for upgrading subscriber lines to future services
- low power consumption in standby state (power down mode).

7.2.3 ISDN BRA U-interface unit

There are two variants of ISDN Basic Rate Access (BRA) U-interface units, one supports 2B1Q and the other one supports 4B3T line coding. The U-interface operates in line termination (LT) mode. The interfaces are provided with line test relays enabling the connection of the lines to the test bus for testing the subscriber loop condition.

Power feeding from the ISDN unit to the NT, NT_{ab} or repeaters may be adjusted within the limits of the total power which may be fed to the line from the unit. Power consumption is continuously monitored to ensure that operation is within safe limits.

The ISDN BRA U-interface units support the following features:

- 16 x 2-wire U-interfaces (2B1Q or 4B3T)
- IDSL interfaces (2B1Q) to DNT128 including Q1 management
- configuration back-up for the NCU
- integrated test access
- switching facilities for upgrading subscriber lines to future services
- intelligent power feeding control for each channel.

7.2.4 Data Interface Unit

There are three different Data Interface Units (DIU) which can be installed into the Eksos N20 node.

- Data Interface Unit with 4 x V.xx/X.21 n x 64 kbit/s interfaces
- Data Interface Unit with 4 x G.703 64 kbit/s interfaces
- Data Interface Unit with 2 x V.xx/X.21 interfaces and 2 x G.703 interfaces.

Data interface units are used for leased line networks. Synchronous bit rates at n x 64 kbit/s (up to 1.984 Mbit/s) and asynchronous slow speed data (v64 kbit/s) are supported with various bit rates.

IF Unit	IF standard	Timing	Conversion/adaptation	Advanced settings
V.xx/X.21	– V.24/V.28 – V.35 – V.36 – EIA-530A	Asynchr.	– Sampling	– V.54
			– R.111	– V.54
			– Transparent	– V.14 (>0.6 kbit/s), V.13, V.54
			– V.110	– V.14 (>0.6 kbit/s), V.13
V.xx/X.21	– V.24/V.28 – V.35 – V.36 – EIA-530A	Synchr. co- or contradirectional	– Transparent	– V.13, V.54
			– V.110	– V.13, V.54
V.xx/X.21	X.21	– Synchr. signal element – Synchr. octet element – Synchr. external	– Transparent	– V.13, X.150
			– X.30	– V.13, X.150
G.703	G.703 (ETS 300 288/9)	Synchr. co- or contradirectional	– Transparent	

Table 5 DIU features

In addition to features presented in Table 5, an extensive set of configuration options, such as various bit masks and control signal definitions, are supported. For more detailed information please refer to the *Commissioning and Maintenance* document.

7.2.5 TR2M4 unit

There are two different 4 x 2 Mbit/s interface units (TR2M4) which can be installed in the Eksos N20 node.

- TR2M4 unit 75 Ω asymmetric
- TR2M4 unit 120 Ω symmetric.

The TR2M4 unit connects four 2048 kbit/s signals to the Eksos N20 node. Each interface has a transmitter and receiver, which fulfils G.703/G.704 specifications and is terminated in the unit. The TR2M4 unit adapts to the Eksos N20 internal cross-connection bus; cross-connections are made at 64 kbit/s time slot level.

One or more of the 2M interfaces can be used as V5.1 tributary links. With the TR2M4 unit, the Eksos N20 node can convert incoming V5.1 signalling from the tributary side to V5.2 signalling that is used on the aggregate side towards the local exchange. With the TR2M4 unit, it is possible to connect, for example, ACM2 V5.1 nodes, to the Eksos N20 node.

7.3 Power supplies, subracks and accessories

7.3.1 DC-PSA

The DC-PSA (DC Power Supply Adapter) contains power input connectors, separation diodes, transient protection circuitry and circuit breakers for nine outputs. The DC-PSA is recommended for use in most installations. For further details, see the *DC-PSA Operating Instructions*.

The DC-PSA supports the following features:

- circuitry for station alarms, energy storage capacitors and an auxiliary +5 V feed for supervision of unit power supplies within subracks
- connectors for Extension Unit, Capacitor Unit and auxiliary outputs
- two auxiliary battery voltage outputs.

7.3.2 Extension Unit

The Extension Unit provides four additional output connectors for the DC-PSA. The Extension Unit is 1U high with cabling and is intended to be installed directly under the DC-PSA. For further details, see the *DC-PSA Operating Instructions*.

7.3.3 Capacitor Unit

The Capacitor Unit should be used when the maximum power requirement is more than 1000 W. Used in conjunction with the DC-PSA, it increases the holdup times during short battery voltage input failures. The unit features transient protection and a class B station alarm output via the DC-PSA for capacitor failure situations. The capacitor unit has also a LED that indicates these failures. For further details, see the *DC-PSA Operating Instructions*.

7.3.4 Eksos N20 17-slot subrack

The Eksos subrack has 17 slots and it can be installed into 19" and 600 mm wide racks. There are very few equipping restrictions associated with this subrack. An extension board on the top of the subrack allows all cabling to be performed from the front of the subrack. The extension board has connectors for battery voltage, signalling voltage, alarms, service switch, test bus, SV1 measurement, overvoltage protection and fans. A decorative front cover is available, through which it is possible to see the unit LEDs.




Figure 23 Dimensions (in millimetres) of the Eksos N20 17-slot subrack

7.3.5 Eksos N20/SAN 17-slot subrack

The Eksos N20/SAN subrack is identical to the Eksos subrack, except that slots 1 and 2 are exclusively reserved for the installation of a SAN CORE2M unit.

7.3.6 Eksos N20 8-slot cartridge

The cartridge can be used for small Eksos N20 nodes, and it allows broadband units to be fitted alongside the cartridge in the same 19" equipping space. Alternatively, for upgrade purposes, two 8-slot cartridges may be fitted side by side. These combinations can share power feeding from the same DC-PSA.

The 8-slot cartridge can be installed on a mounting shelf in 19" and 600 mm wide racks. The extension board on top of the cartridge has connectors for battery voltage, signalling voltage, alarms, service switch, test bus, SV1 measurement, overvoltage protection and fans.




Figure 24 Dimensions (in millimetres) of the 8-slot cartridge

7.3.7 Eksos N20/SAN 8-slot cartridge

The Eksos N20/SAN cartridge is identical to the Eksos N20 cartridge, except that slots 1 and 2 are exclusively reserved for the installation of a SAN CORE2M unit. Slot 3 is reserved for the installation of an NCU. There are no equipping restrictions for the remaining slots.

7.3.8 Fan Unit

The Fan Unit is designed to be used in installations which require forced cooling. For further details see the *Fan Unit Operating Instructions*. The Eksos N20 subrack has a combined power and alarm connector which connects to the fan unit.

7.3.9 Air deflectors

Air deflectors are available in 1U, 2U, 4U and 5U heights, with or without front grilles (the 1U version is only available without grille). The 1U and 2U versions are designed for use in installations where forced cooling is implemented, while 4U and 5U versions are intended for natural convection installations. The 1U and 4U versions are intended for use in installations with cable trays.

7.3.10 Cable trays

The use of cable trays improves the thermal management of the node installation and keeps cables tidy. Each node requires the use of two 1U cable trays, one above and one below the node. Cables are guided from the front of the node directly into the front of the cable trays where they are secured with strain reliefs. Cables are guided to the side of the node and into the rack's cabling space.

7.3.11 Wall Mounting Set

The Wall Mounting Set is ideal for mounting 17-slot Eksos N20 nodes in small locations where space is a premium. In addition to the subrack, the Wall Mounting Set can also accommodate a DC-PSA, fan unit and cross-connection panel.




Figure 25 Eksos N20 can be installed using a Wall Mounting Set

7.4 Software products

7.4.1 Node software

The Eksos N20 node has release-specific software which provides the node functionality. The software can be upgraded to later releases.

In addition, depending on their usage, units are provided with unit specific software.

7.4.2 Eksos N20 Node Manager

The Eksos N20 Node Manager is a Windows NT 4.0 application program and runs on a standard PC. This is the basic tool for installation and operation purposes. It is also used for controlling the line test functionality.

7.4.3 Software upgrade kits

The Eksos N20 node can be upgraded from an earlier system release to a later system release. Some new features introduced in a later system release are available with existing plug-in units and a functionality upgrade kit. The upgrade kit includes the required software and upgrade instructions for upgrading the Eksos N20 node to a later system release.

Chapter 8

Technical specifications

This chapter briefly describes the technical specifications of the Eksos N20 in the following order:

- interfaces
- line testing
- power consumption
- mechanical specifications
- environmental specifications
- Eksos N20 Node Manager system requirements
- international recommendations.

8.1 Interfaces

8.1.1 2 Mbit/s interfaces

2 Mbit/s interfaces	
2048 kbit/s	ITU-T G.703/G.704, 75 Ω unbalanced or 120 Ω balanced
Connector types	75 Ω coaxial 8 x 1.0/2.3 50M (male) straight (DIN 41626/2)
	120 Ω 1/2-3 x16 pin Euroconnector
	120 Ω interface, C/2 3 x 16M (male) Pressfit

8.1.2 PSTN interface

Analog 2-wire subscriber line interface	
Connector	C/1-2 x 16 pin Euroconnector
Voice-frequency specification	
Based on recommendation	ITU-T Q.552
Basic PSTN signalling	
Subscriber line feeding	Yes
Decadic dialling	Yes
Ringing signal and cadence	Yes
Ring trip detection	Yes
Current feed	Yes
Resistance feed	Yes
Polarity reversal	Yes ¹⁾
Metering	Yes ¹⁾
Calling Line Identification	Yes ¹⁾
Loop start	Yes ¹⁾
EMC compatibility	With unshielded cables
1) Provided that the PSTN mapping used supports these features.	

8.1.3 ISDN BRA U-interfaces

ISDN BRA U-interfaces	
Information transfer rate of 144 kbit/s, 2B+D	160 kbit/s
Line code	2B1Q or 4B3T
Connector	C/1-2 x 16 pin Euroconnector

8.1.4 Data interfaces

Data interfaces	
Electrical interfaces V/X	n x 64 kbit/s ITU-T V.24/V.28, V.35, V.36, X.21/V.11, EIA-530-A Asynchronous slow speed data ≤ 64 kbit/s: – asynchronous to synchronous conversion using: – V.14 asynch. rates up to 56 kbit/s – sampling up to 4.8 kbit/s – sampling and filtering up to 4.8 kbit/s – transition coding up to 19.2 kbit/s – adaptation function including V.110 and transparent transmission up to 56 kbit/s – adaptation function including V.110 at 48 kbit/s and 56 kbit/s synch.
Electrical interfaces G.703	64 kbit/s ITU-T G.703, ETS 300 288/9
Data	Synchronous codirectional or contradirectional, or asynchronous
Connector	C/2 2 x (3 x 7) pin Euroconnector

8.1.5 STM-1 interfaces

Transmission interfaces	
STM-1	155.520 Mbit/s, ITU-T G.707, S1.1: short haul 1300 nm 155.520 Mbit/s, ITU-T G.707, L1.1: long haul 1300 nm (ETSI VC-12 mapping scheme)
Connector types	SC or FC/PC options

8.1.6 Synchronisation

Synchronisation	
System clock accuracy	4.6×10^{-6}
Synchronisation source	external 2048 kHz signal or incoming 2048 kbit/s or STM-1 aggregate signal or incoming 2048 kbit/s or STM-1 tributary signal or internal frequency (hold over and free running)
Synchronisation output	external 2048 kHz interface

8.1.7 Management interfaces

Management interface	
Connector type	10Base-T: Shielded RJ45 10Base2: BNC
Electrical interfaces	10Base-T: IEEE 802.3, except §14.3.1.1 (Isolation requirement)
	10Base-2: IEEE 802.3

8.1.8 Auxiliary interfaces

Auxiliary data channel interfaces are provided, which may be used to extend either a Q3 or Q1 type network management DCN (Data Communications Network).

Auxiliary data channel interfaces	
Q1	V.11 4-wire interface, 0 - 9600 bit/s, asynchronous
AUX Data	V.11, synchronous 64 kbit/s, codirectional or contradirectional
Connectors	Shielded RJ45

8.1.9 External supervisory interfaces

External supervisory inputs/outputs on each NCU or LMU	
Connector type	Shielded RJ45
Digital inputs	Three with E&M signalling
Digital input/output	Two with E&M (input mode), open drain (output mode)
Analog input (2)	One with -70 - 0 V range One with 0 - +5 V range

8.2 Line testing

8.2.1 PSTN tests

Basic metallic test out:	Range and accuracy
AC _{RMS} voltage measurement (a-gnd, b-gnd, and a-b)	0 - 2 V ± 0.1 V 2 - 50 V ± 5% ¹⁾
DC voltage measurement (a-gnd, b-gnd, and a-b)	0 - 5V ± 0.1 V 5 - 70 V ± 2% ¹⁾
Capacitance measurement (a-gnd, b-gnd, and a-b)	0 - 100 nF ± 3 nF 100 nF - 1 μF ± 3% 1 μF - 10 μF ± 10%
Leakage resistance measurement (a-gnd, b-gnd, a-b, b-a, a-batt, and b-batt)	0 - 1 kΩ ± 20 Ω 1 kΩ - 1 MΩ ± 2% 1 MΩ - 10 MΩ ± 10%
Loop resistance measurement R _{a-b}	0 - 1 kΩ ± 20 Ω 1 kΩ - 1 MΩ ± 2% 1 MΩ - 10 MΩ ± 10%
1) On older PSTN units, the maximum measured AC voltage is limited to 50 V and maximum DC to 70 V.	

Test in:	Test criteria
Feeding voltage test	The parameters are tested against fixed threshold values. As a result of each test an OK/NO_OK indication is given.
Feeding current test	
Loop detection test	
Ring trip detection test	
Ringing current test	
Private meter pulse test	
CODEC test	

8.2.2 ISDN BRA tests

Test out:	Range and accuracy
AC _{RMS} voltage measurement (a-gnd, b-gnd, and a-b)	0 – 2 V ± 0.1 V 2 – 100 V ± 5%
DC voltage measurement (a-gnd, b-gnd, and a-b)	0 – 5 V ± 0.1 V 5 – 140 V ± 2%
Capacitance measurement (a-gnd, b-gnd, and a-b)	0 – 100 nF ± 3 nF 100 nF – 1 µF ± 3% 1 µF – 10 µF ± 10%
Leakage resistance measurement (a-gnd, b-gnd, a-b, b-a, a-batt, and b-batt)	0 – 1 kΩ ± 20 Ω 1 kΩ – 1 MΩ ± 2% 1 MΩ – 10 MΩ ± 10%

ISDN tests	
Loopbacks	Faults can be located by making ISDN loopback tests. The loopback tests can separately check the condition of the interface and the line. The following tests specified in ETS 300 012 are available: – Loop1 to loop in line termination (LT) – Loop1A to loop in repeater (REG) – Loop2 to loop in NT
Remote tests	– Partial activation test – Full activation test – Node send corrupt CRC to node – NT1 send corrupt CRC to node – Hold NT1 state – Node send pulse mask to NT1

8.3 Power consumption

The power consumption depends on many factors including traffic figures and subscriber loop lengths.

Typical power consumption of Eksos N20 units

Product	Average power consumption
17-slot Eksos N20 subrack (fully equipped)	250 W
Eksos N20 8-slot cartridge (fully equipped)	120 W
NCU	10 W
LMU	12 W
PSTN	16 W
ISDN	11 W
DIU	10 W
TR2M4	10 W
SAN CORE2M	17 W

8.4 Mechanical specifications

8.4.1 Subrack extension board connectors

Connector function	Connector type
Power connectors P1 and P2	AMP Mate'n'lok
Signalling voltage connector P3	AMP Mate'n'lok
Station alarm outputs connector P4	15-pole male D-connector
Fan power and alarm connector J5	9-pole female D-connector
Test bus connectors J3A C and D	RJ45
SV1 measurement connectors J3A A and B	RJ45
Service switch connectors J2A A to D	RJ45
Connectors J11, J12 and J13	Phoenix mini-combicon

8.4.2 Cartridge extension board connectors

Connector function	Connector type
Power connectors P1 and P2	AMP Mate'n'lok
Signalling voltage connector P3	AMP Mate'n'lok
Station alarm outputs connector P4	15-pole male D-connector
Fan power and alarm connector J5	9-pole female D-connector
Test bus connectors J3A C and D	RJ45
SV1 measurement connectors J3A A and B	RJ45
Service switch connectors J2A A to D	RJ45
Connectors J1 and J2	Phoenix mini-combicon

8.4.3 Mechanical dimensions

Product	Dimensions (h x w x d) excluding mounting brackets	
Subrack 17-slots (without cover)	330 x 450 mm x 240 mm	
Subrack 17-slots (with cover)	340 x 450 mm x 300 mm	
Cartridge 8-slots	345 x 211 mm x 240 mm	
Mounting shelf for 8-slot cartridge (ETSI)	108 x 534 mm x 242 mm	
Mounting shelf for 8-slot cartridge (19")	104 x 482 mm x 242 mm	
Wall mounting set	810 x 560 mm x 300 mm	
DC-PSA	110 mm x 483 mm x 225 mm	
1U Extension unit	44 mm x 483 mm x 160 mm	
1U Capacitor unit	43 mm x 483 mm x 120 mm	
1U Cable tray	43 mm x 448 mm x 280 mm	
1U Fan unit	43 mm x 448 mm x 280 mm	
1U Air Deflector	44 mm x 445 x 254 mm	
2U Air Deflector	88 mm x 445 x 254 mm (without grille) 88 mm x 445 x 270 mm (with grille)	
4U Air Deflector	170 mm x 445 x 254 mm (without grille) 170 mm x 445 x 270 mm (with grille)	
5U Air Deflector	222 mm x 445 x 254 mm (without grille) 222 mm x 445 x 270 mm (with grille)	
Plug-in units	SAN CORE2M	265 mm x 50 x 210 mm
	Other units	265 mm x 25 x 210 mm

8.4.4 Weights

Product	Weight
SAN CORE2M	980 g
NCU	490 g
LMU	475 g
PSTN	1050 g
ISDN	640 g
DIU	600 g
TR2M4	415 g
Eksos N20 Subrack 17-slot	5400 g
Eksos N20 8-slot cartridge	2585 g
1U Air deflector (without grille)	1230 g
2U Air deflector (without grille)	1050 g
2U Air deflector (with grille)	1300 g
4U Air deflector (without grille)	1560 g
4U Air deflector (with grille)	2030 g
5U Air deflector (without grille)	1900 g
5U Air deflector (with grille)	2500 g
Fan unit	2925 g
Cable tray	955 g
Capacitor unit	2000 g
Extension unit	2350 g
DC-PSA	5500 g
OSI-DCN adapter	470 g
Wall mounting set	7400 g

8.5 Environmental specifications

Recommendation	ETSI specification prETS 300 019-1-1/2/3		
	Operation, class 3.2	Transportation, class 2.3	Storage, class 1.2
Low air temperature	-5 °C	-40 °C	-25 °C
High air temperature ¹⁾	+45 °C ²⁾	-	+55 °C
Low relative humidity	5 %	-	10 %
High relative humidity ³⁾	95 %	95 %	100 %
Low absolute humidity	1 g/m ³	-	0.5 g/m ³
High absolute humidity	29 g/m ³	60 g/m ³	29 g/m ³
Low air pressure	70 kPa	70 kPa	70 kPa
High air pressure	106 kPa	-	106 kPa
OPERATION:			
Biological conditions		class 3.2	
Chemically active substances		class 3.2	
Mechanically active substances		class 3.2	
Mechanical conditions		class 3.2	
1) High air temperature and low air pressure not prevailing simultaneously			
2) Extended temperature range +55 °C with forced convection			
3) Condensation and icing is not allowed on the electronics parts or product package			

8.5.1 EMC Immunity

Electrostatic discharge (ESD) EN 61000-4-2		
Contact discharge	Air discharge	Compliance criterion
6 kV	8 kV	A
8 kV	15 kV	Loss of function (self recovery)

Surge immunity EN 61000-4-5	
Voltage	Compliance criterion
Indoor cables: 500 V	B
Outdoor cables: 1.0 kV	B, differential mode
1.5 kV	B, common mode
4.0 kV	B, with primary protection

Electrical fast transients/bursts (EFT) EN 61000-4-4		
Cable	Voltage	Compliance criterion
DC power cables	1 kV	A
	2 kV	Loss of function (self recovery)
Signal cables	500 V	A
	1 kV	Loss of function (self recovery)


Radio frequency electromagnetic field disturbances EN61000-4-6		
Frequency	Voltage	Compliance criterion
0.15 - 80 MHz	3 V	A
	10 V	Loss of function


Radio frequency electromagnetic field disturbances EN 61000-4-3		
Frequency	Electric field strength	Compliance criterion
80 - 1000 MHz (AM)	3 V/m	A
	10 V/m	B
1.4 - 2.0 GHz (AM)	3 V/m	A
	10 V/m	B

Radio frequency electromagnetic field disturbances ENV 50204		
Frequency	Electric field strength	Compliance criterion
900 MHz (PM)	3 V/m	A
	10 V/m	B
1.890 GHz (PM)	3 V/m	A
	10 V/m	B

8.5.2 EMC Emission

Conducted emission, power leads EN 55022 class A 1995, ETS 300 386-1		
Frequency	Quasi-peak dB (μV)	Average dB (μV)
20 - 150 kHz	79	–
0.15 - 0.5 MHz	79	66
0.5 - 30 MHz	73	60





8.6 Eksos N20 Node Manager system requirements

The hardware and software requirements for the computer running the Eksos N20 Node Manager are given below.

System requirements	
Operating system	Microsoft Windows NT Version 4.0
Computer	Any PC capable of running the required version of Microsoft Windows NT
RAM	128 MB minimum, preferably 192 MB or more
Hard disk space	100 MB minimum
Floppy disc drive CD-ROM drive	3.5" high-density (for installation purposes) CD-ROM drive (for installation purposes)
Display	Colour (at least 16 colours) or grey scale (16 shades of grey)
Pointing device	Mouse, tracker ball or equivalent with the necessary controlling software
Printer (optional)	Microsoft Windows NT compatible printer
Interface ports	-Ethernet port for Q3 communication to the node -Serial port or Parallel port for printer -Mouse port (if a mouse is used as the pointing device)

8.7 International recommendations

This is a list of recommendations referred to in technical specifications.

8.7.1 2 Mbit/s interface specifications

ITU-T	Recommendation name
G.703	Physical electrical characteristics of hierarchical digital interfaces
G.704	Synchronous frame structures used at primary and secondary hierarchical levels
G.706	Frame Alignment and Cyclic Redundancy Check (CRC) Procedures Relating to Basic Frame Structures Defined in Recommendation G.704

ETSI	Recommendation name
ETS 300 418	2048 kbit/s digital unstructured and structured leased lines (D2048U and D2048S)
ETS 300 419	2048 kbit/s digital structured leased lines (D2048S); Connection characteristics
ETS 300 420	2048 kbit/s digital structured leased lines (D2048S); Terminal equipment interface

8.7.2 V5.1/V5.2 specifications

ITU-T	Recommendation name
G.964	V-interfaces at the digital local exchange (LE) – V5.1-interface (based on 2048 kbit/s) for the support of access network (AN)
G.965	V-interfaces at the digital local exchange (LE) – V5.2-interface (based on 2048 kbit/s) for support of access network (AN)

ETSI	Recommendation name
EN 300 324-1	Signalling Protocols and Switching (SPS); V interfaces at the Local Exchanges (LE) V5.1 interface for the support of Access Network (AN)Part 1: V5.1 Interface Specification
EN 300 347-1	V interfaces at the digital Local Exchange (LE) V5.2 interface for the support of Access Network (AN)Part 1: V5.2 interface Specification

8.7.3 SDH specifications

ITU-T	Recommendation name
G.707	Network Node Interface for SDH
G.783	Characteristics of Synchronous Digital Hierarchy (SDH) Equipment Functional Blocks
G.784	Synchronous Digital Hierarchy (SDH) Management
G.957	Optical interfaces for equipment and systems relating to the Synchronous Digital Hierarchy
G.958	Digital line systems based on the Synchronous Digital Hierarchy for use on optical fibre cables

ETSI	Recommendation name
ETS 300 147	Synchronous Digital Hierarchy Multiplexing structure
ETS 300 417-x	Transmission and Multiplexing (TM) Generic functional requirements for Synchronous Digital Hierarchy (SDH) equipment; consisting of part 1 to part 8
ETS 300 417-1-1	Part 1-1: Generic processes and performance
ETS 300 417-2-1	Part 2-1: Physical section layer functions
ETS 300 417-3-1	Part 3-1: STM-N regenerator and multiplex section layer functions
ETS 300 417-4-1	Part 4-1: SDH path layer functions
ETS 300 417-5-1	Part 5-1: PDH path layer functions
ETS 300 417-6-1	Part 6-1: Synchronisation distribution layer functions
prETS 300 417-7-1	Part 7-1: Auxiliary layer functions
prETS 300 417-8-1	Part 8-1: Compound and major compound functions

8.7.4 Synchronisation

ITU-T	Recommendation name
G.813	Timing characteristics of SDH equipment slave clocks (SEC)
G.823	The control of jitter and wander within digital networks which are based on the 2048 kbit/s hierarchy
G.825	The control of jitter and wander within digital networks which are based on the Synchronous Digital Hierarchy (SDH)

ETSI	Recommendation name
EN 300 462-5	Generic requirements for synchronisation networks; Part 5: Timing characteristics of slave clocks suitable for operation in Synchronous Digital Hierarchy (SDH) equipment

8.7.5 Miscellaneous

ITU-T	Recommendation name
G.775	Loss of signal (LOS) and alarm indication signal (AIS) defect detection and clearance criteria
O.153	Basic parameters for the measurement of error performance at bit rates below the primary rate
O.162	Equipment to perform in-service monitoring on 2048 kHz

8.7.6 ISDN BRA (U) interfaces

ITU-T	Recommendation name
G.961	Digital transmission system on metallic local lines for ISDN basic rate access

ETSI	Recommendation name
ETS 300 297	Access digital section for ISDN basic access
ETR 080	Integrated Services Digital Network (ISDN) basic rate access Digital transmission system on metallic local lines

8.7.7 PSTN voice frequency specifications

ITU-T	Recommendation name
G.711	Pulse Code Modulation (PCM) of Voice Frequencies
G.712	Transmission Performance Characteristics of PCM Channels
Q.552	Transmission Characteristics at 2-wire Analog Interfaces of Digital Exchanges

8.7.8 Data interface unit

ANSI	Recommendation name
EIA-530A	High Speed 25 Position Interface for Data Terminal Equipment and Data Circuit-Terminating Equipment, including Alternative 26 Position Connector

ITU-T	Recommendation name
R.111	Code and speed independent TDM system for anisochronous telegraph and data transmission
V.10	Electrical characteristics for unbalanced double-current interchange circuits operating at data signalling rates nominally up to 100 kbit/s
V.11	Electrical characteristics for balanced double-current interchange circuits operating at data signalling rates up to 10 Mbit/s
V.110	Support of data terminal equipments with V-Series type interfaces by an integrated services digital network
V.13	Simulated carrier control
V.14	Transmission of start-stop characters over synchronous bearer channels
V.24	List of definitions for interchange circuits between data terminal equipment (DTE) and data circuit-terminating equipment (DCE)
V.28	Electrical characteristics for unbalanced double-current interchange circuits
V.35	List of definitions for interchange circuits between data terminal equipment (DTE) and data circuit-terminating equipment (DCE) on public data networks
V.36	Modems for synchronous data transmission using 60-108 kHz group band circuits
V.54	Loop test devices for modems; 11/88
X.21	Use on public data networks of Data Terminal Equipment (DTE) which is designed for interfacing to synchronous V-Series modems; 11/88
X.24	List of definitions for interchange circuits between data terminal equipment (DTE) and data circuit-terminating equipment (DCE) on public data networks
X.150	Principles of maintenance testing for public data networks using Data Terminal Equipment (DTE) and Data Circuit-terminating Equipment (DCE) test loops; 11/88
X.745	Data Networks and Open System Communications OSI Management

8.7.9 HDSL

ETSI	Recommendation name
ETR 152	Transmission and Multiplexing (TM); High bitrate Digital Subscriber Line (HDSL) transmission system on metallic local lines; HDSL core specification and applications for 2048 kbit/s based access digital sections including HDSL dual-duplex Carrierless Amplitude Phase Modulation (CAP) based system

8.7.10 Optical fibre

ITU-T	Recommendation name
G.652	Characteristics of a single-mode optical fibre cable
G.653	Characteristics of a dispersion-shifted single-mode optical fibre cable
G.654	Characteristics of a 1550 nm wavelength loss-minimised single-mode optical fibre cable

8.7.11 Power supply

ETSI	Recommendation name
ETS 300 132-2	Power supply interface at the input to telecommunications equipment; Part 2: Operated by direct current (DC)

8.7.12 Network

ITU-T	Recommendation name
G.805	Generic functional architecture of transport networks

8.7.13 Environmental

ETSI	Recommendation name
EN 55022	Limits and Methods of Measurement of Radio Interference Characteristics of Information Technology Equipment.
EN 61000-4-2...6	Electromagnetic Compatibility (EMC) Part 4: Testing and Measurement Techniques
EN 61000-4-2	Section 2: Electrostatic Discharge Immunity Test – Basic.
EN 61000-4-3	Section 3: Radiated, Radio-Frequency, Electromagnetic Field Immunity Test.
EN 61000-4-4	Section 4: Electrical Fast Transient/Burst Immunity Test.
EN 61000-4-5	Section 5: Surge Immunity Test.
EN 61000-4-6	Section 6: Immunity to Conducted Disturbances, Induced by Radio-Frequency Fields.
ENV 50204 (1995)	Radiated Electromagnetic Field from Digital Radio Telephones – Immunity Test.
ETS 300 386-1	Equipment Engineering (EE); Telecommunication Network Equipment Electromagnetic Compatibility (EMC) Requirements; Part 1: Product Family Overview, Compliance Criteria and Test Levels.
prETS 300 019-1-1	Environmental Class 1.2: Conditions for weatherprotected, partly temperature controlled storage locations.
prETS 300 019-1-2	Environmental Class 2.3: Conditions for public transportation
prETS 300 019-1-3	Environmental Class 3.2: Conditions for stationary use in weatherprotected, partly temperature controlled storage locations.

IEC	Recommendation name
C.I.S.P.R 22	Information Technology Equipment – Radio Disturbance Characteristics – Limits and Methods of Measurement.

Nokia Eksos N20

Narrowband Multiservice Access Node

Specific Instructions for Germany

NOKIA

The information in this document is subject to change without notice and describes only the product defined in the introduction of this documentation. This document is intended for the use of Nokia Networks' customers only for the purposes of the agreement under which the document is submitted, and no part of it may be reproduced or transmitted in any form or means without the prior written permission of Nokia Networks. The document has been prepared to be used by professional and properly trained personnel, and the customer assumes full responsibility when using it. Nokia Networks welcomes customer comments as part of the process of continuous development and improvement of the documentation.

The information or statements given in this document concerning the suitability, capacity, or performance of the mentioned hardware or software products cannot be considered binding but shall be defined in the agreement made between Nokia Networks and the customer. However, Nokia Networks has made all reasonable efforts to ensure that the instructions contained in the document are adequate and free of material errors and omissions. Nokia Networks will, if necessary, explain issues which may not be covered by the document.

Nokia Networks' liability for any errors in the document is limited to the documentary correction of errors. Nokia Networks WILL NOT BE RESPONSIBLE IN ANY EVENT FOR ERRORS IN THIS DOCUMENT OR FOR ANY DAMAGES, INCIDENTAL OR CONSEQUENTIAL (INCLUDING MONETARY LOSSES), that might arise from the use of this document or the information in it.

This document and the product it describes are considered protected by copyright according to the applicable laws.

NOKIA logo is a registered trademark of Nokia Corporation.

Any other trademarks mentioned in the documents are the property of their respective companies, and they are mentioned for identification purposes only.

Copyright © Nokia Corporation 2002. All rights reserved.

Document History

Document	Date	Comment
C33993003SE_00	20 Sep 2002	

Contents

Chapter 1	
About this document	1
Chapter 2	
Technical specifications	3
2.1 Power consumption	5
2.2 Recommendations	6
Chapter 3	
Commissioning PSTN user interface	7
3.1 Default settings	7
3.2 Signalling settings (DC Set)	8
3.3 General settings	9
3.4 Speech settings	9
Chapter 4	
ISDN Interface Unit	11
4.1 Commissioning power feeding of ISDN user interfaces	11
4.2 Power consumption and heat dissipation	11
Chapter 5	
PSTN mapping	15
5.1 Recommendations and standards	15
5.2 Key features	15

Chapter 1

About this document

This document describes the features that are specific to Eksos N20 system release designed for Germany.

The specifications and instructions given here complement the other, more generic, documents included in this manual.

- To get an overall picture of the specifications met in Eksos N20 DEU, use this document together with the *Product Description* document.
- To be able to commission the entire node, and especially the PSTN and ISDN units, use this document together with the *Commissioning and Maintenance* document.

Chapter 2

Technical specifications

The standards mentioned in Section 2.2 are always fulfilled when using the default settings.

DC Set				
Function	Attribute	Set 1 Default	Set 2 Option 2	Set 3 Option 3
DC feed	Resistance (Ω)	2 x 200	2 x 200	
	Current (mA)	25	25	
	Optional current (mA)	35	35	
Loop resistance	(Ω)	<1800	<1800	
Off-hook detection	Level (mA)	9	9	
On-hook with transmission	(V)	> 43	> 43	
On-hook without transmission (power save)	(V) $R_i = 2 \times 5 \text{ k}\Omega$	≥ 48	≥ 48	–
Metering	Level (V_{rms})	4.0	5.0	4.0
Ringing	Level (V_{rms})	70	70	
	Frequency (Hz)	25	25	
	DC offset (V)	30	30	

Table 1 Signalling settings

Line feeding mode	Default value	Optional value
Feeding mode	Normal ¹⁾	Direct battery ¹⁾
Polarity reversal	Fast	Slow
1) With either normal or optional current (see section 3.2)		

Table 2 Line feeding settings

Function	Default value	Optional value
Metering pulse type	16 kHz	–
Generator impedance	180 Ω	–
Nominal load impedance	200 Ω	–
Metering rise/fall envelope	Slow	Fast ¹⁾
Ringing mode	Internal	–
1) For testing purposes only		

Table 3 General settings

Function	Default value	Optional value
Nominal and balance impedance	220 Ω + 820 Ω // 115 nF 220 Ω + 820 Ω // 115 nF	270 Ω + 750 Ω // 150 nF 270 Ω + 750 Ω //150 nF
		600 Ω 600 Ω
Input level (Li)	0 dBr	-5 to +3 dBr
Output level (Lo)	-7 dBr	-10 to 0 dBr

Table 4 Speech settings

Voltage	Level
Central battery voltage	-48 V (-44 to -58 V)

Table 5 Power supply

2.1 Power consumption

Tables 6 and 7 gives some average power consumption figures for different traffic loads.

- < 60 mErl Normal traffic
- 60 to 125 mErl Busy hour
- 125 to 250 mErl Exceptionally heavy traffic.

Note

When estimating the power supply capacity needed, you also have to consider the power required by the NCU (10 W) and ISDN units in the configuration.

IFs (pcs)	Units (pcs)	60 mErl		125 mErl		250 mErl		500 mErl	
		P _{heat} (W)	P _{tot} (W)	P _{heat} (W)	P _{tot} (W)	P _{heat} (W)	P _{tot} (W)	P _{heat} (W)	P _{tot} (W)
32	1	10	11	12	15	16	21	24	34
64	2	20	22.5	24	29	32	42	48	68
128	4	40	45	48	58	64	84	96	136
192	6	60	67.5	72	87	96	126	144	204
256	8	80	90	96	116	128	168	192	272
320	10	100	113	120	145	160	210	240	340
384	12	120	135	144	174	192	252	288	408
480	15	150	169	180	218	240	315	360	510
Depending on the line lengths the accuracy of the power levels is ±10%									
The grey areas in P _{tot} columns show the recommended levels for planning the power supply capacity. For small numbers of interfaces, the calculations need to be done according to heavier traffic because the statistical values are not necessarily applicable.									

Table 6 Power levels at average line lengths and 25 - 35 mA current limitation

IFs (pcs)	Units (pcs)	60 mErl		125 mErl		250 mErl		500 mErl	
		40 mA P_{tot} (W)	20 mA P_{tot} (W)	40 mA P_{tot} (W)	20 mA P_{tot} (W)	40 mA P_{tot} (W)	20 mA P_{tot} (W)	40 mA P_{tot} (W)	20 mA P_{tot} (W)
32	1	12	10	16	13	24	18	39	28
64	2	24	21	32	26	47	36	78	55
128	4	48	42	63	52	94	71	156	110
192	6	71	63	95	77	141	107	234	165
256	8	95	84	126	103	188	142	312	220
320	10	119	104	158	129	235	178	390	275
384	12	143	125	189	155	282	213	468	330
480	15	178	157	236	193	353	266	585	413

On long lines the levels can be 20% lower.

The grey areas in P_{tot} columns show the recommended levels for planning the power supply capacity. For small numbers of interfaces, the calculations need to be done according to heavier traffic because the statistical values are not necessarily applicable.

Table 7 Maximum power levels at 40 and 20 mA current limitation

2.2 Recommendations

The following table lists the recommendation referred to in the technical specifications.

ITU-T	
Q.552 (11/96)	Transmission Characteristics at 2-wire Analog Interfaces of Digital Exchanges

Table 8 International recommendations and standards

Chapter 3

Commissioning PSTN user interface

3.1 Default settings

Normally, PSTN interfaces can be brought into use with their default settings without having to change any interface related settings. The following default settings are suitable for most applications and have been preintegrated into the software.

Setting	Default value
DC Set	
DC set	Default (Set 1)
Feeding mode	Normal
Polarity reversal	Fast
General	
Metering pulse type	16 kHz
Metering rise/fall envelope	Slow
Ringing mode	Internal
Speech	
Input level	0 dBr
Output level	-7 dBr
Impedance pair	Nominal: 220 Ω + 820 Ω // 115 nF Balance: 220 Ω + 820 Ω // 115 nF

Table 9 Default settings for PSTN user interface

The default settings need to be modified only in special cases, such as for exceptionally long or short lines. This section gives some guidelines for choosing the correct alternative settings. For detailed instructions on how to set these settings, refer to the *Commissioning and Maintenance* document.

The signalling, general and speech settings can be accessed through the **Configure PSTN** dialog box in Node Manager.

3.2 Signalling settings (DC Set)

The following settings can be accessed through the **DC Set** tab in the **Configure PSTN** dialog box of Node Manager.

DC Sets 1 to 3

There are three sets of settings available for the configuration of the signalling. The DC sets can be defined individually for each interface and should be used as follows:

Set 1 (selection: default)

- Default settings conform to the German specifications.
- Suitable for all line lengths.

Set 2 (selection: option 2)

- Designed for long lines: metering pulse level higher than in the default set
- Recommended to be used on long lines when metering pulse support is required.

For more detailed information about line lengths and minimum metering levels, see Table 10.

Set 3 (selection: option 3)

- Equivalent to Set 1, but inhibits power save state.
 - Set 3 is used with some special terminal equipment.
 - Idle state voltage is about 44 V instead of 68 V.
 - Set 3 increases power consumption. For this reason, Set 3 should be used only when necessary.

DC feed

- Current feeding to the line is defined by the DC set selected.
- In each set there are two options:
 - normal current: conforms to the German standards
 - optional current: when increased current is needed.

Line feeding settings

Normal feed

Selecting normal feed means that the supply voltage source for line feeding is always automatically selected to minimise the power consumption.

Direct battery

Selecting direct battery option means that the battery voltage (-48 V) is always used for line feeding. It inhibits the use of lower internal signalling voltage for short lines.

Note

This option may increase power consumption and heat dissipation.

Polarity reversal time

The default value (**Fast**) should always be used. The optional values are only intended for testing purposes.

3.3 General settings

The following settings can be accessed through the **General** tab in the **Configure PSTN** dialog box of Node Manager.

Metering rise/fall envelope

The default value (**Slow**) should always be used. The **Fast** option is only intended for testing purposes.

3.4 Speech settings

The following settings can be accessed through the **Speech** tab in the **Configure PSTN** dialog box of Node Manager.

Impedances

- Balance and nominal impedances are always used as pairs.
- Impedance pair can be defined individually for each interface.
 - First impedance ($220\ \Omega + 820\ \Omega // 115\ \text{nF}$) conforms to the German requirements.
 - ($270\ \Omega + 750\ \Omega // 150\ \text{nF}$) is defined by ETSI.
 - $600\ \Omega$ impedance is primarily meant for testing purposes.

Speech levels

- Input and output level settings can be defined individually for each interface. Levels are adjustable in 0.5 dB steps within the specified range (see Table 4).
- In normal use, the default settings do not need to be changed. The levels only need to be adjusted:
 - *Long loop:* When exceptionally long lines are used, the gain control of the telephone set alone cannot compensate for the strong attenuation. In this case, the default level can be adjusted for the selected lines. Table 10 gives some guidelines for estimating the new levels. For example, if the attenuation is compensated by 1.5 dB, the new levels are:

$$Li = 0 \text{ dBr} - 1.5 \text{ dB} = -1.5 \text{ dBr and}$$

$$Lo = -7 \text{ dBr} + 1.5 \text{ dB} = -5.5 \text{ dBr}$$

		wire 0.4 mm			wire 0.5 mm			wire 0.6 mm		
Line type	Line res. Ω	Line length km	Line Att. dB	SPM Level V_{rms}	Line length km	Line Att. dB	SPM Level V_{rms}	Line length km	Line Att. dB	SPM Level V_{rms}
Short line	0	0.0	0	4.0	0.0	0	4.0	0.0	0	4.0
	300	1.0	1.5	4.0	1.6	2	4.0	2.4	2.5	4.0
	600	2.0	3	4.0	3.2	4	4.0	4.7	5	4.0
Medium line	700	2.4	4	4.0	3.8	5	4.0	5.5	6	4.0
	800	2.7	4.5	4.0	4.3	5.5	4.0	6.3	7	4.0
	950	3.2	5	4.0	5.1	6.5	5.0	7.5	8	5.0
Long line	1000	3.4	5.5	(5.0) 4.0	5.4	7	5.0	7.9	8.5	5.0
	1100	3.8	6	(5.0) 4.0	5.9	7.5	5.0	8.7	9	5.0
	1200	4.1	6.5	(5.0) 4.0	6.5	8	5.0	9.4	10	
	1500	5.1	8	5.0	8.1	10		12	13	
	1600	5.5	9		8.6	11		13	14	
	1800	6.1	10		9.7	12		14	15	
Line res: Loop resistance of copper pair cable, resistance of TE (Terminal Equipment) not included.										
Line Att: Copper line attenuation at 1 kHz										

Table 10 Cable length and attenuation

Chapter 4

ISDN Interface Unit

4.1 Commissioning power feeding of ISDN user interfaces

Check that the power fed to the line is 97 V. For detailed instructions, see the *Commissioning and Maintenance* document.

No other settings are required. The ISDN unit can start operating with the default settings preconfigured to the software.

4.2 Power consumption and heat dissipation

Tables 13 to 17 give some average power consumption figures for different configurations and traffic loads.

- < 60 mErl Normal traffic
- 60 to 125 mErl Busy hour
- 125 to 250 mErl Exceptionally heavy traffic
- 1000 mErl Line is always activated.

Note

When estimating the power supply capacity needed, you also have to consider the power required by the NCU (10 W) and PSTN units in the configuration.

For an explanation of abbreviations used in section 4.2, see Table 11.

Abbreviations used	
NT	Network Termination
REG	Regenerator
UNI	User-Network interface

Table 11 Abbreviations used in text

In Tables 13 and 14, the following power and resistance values have been used.

Attribute	Value
Power NT	1.2 W
Power REG	1.2 W
Loop resistance NT	1000 Ω
Loop resistance NT + REG	1000 Ω + 400 Ω

Table 12 Power and loop resistance values for NT and REG

IFs pcs	Units pcs	60 mErl		125 mErl		250 mErl		500 mErl		1000 mErl	
		P _{heat} (W)	P _{tot} (W)	P _{heat} (W)	P _{tot} (W)	P _{heat} (W)	P _{tot} (W)	P _{heat} (W)	P _{tot} (W)	P _{heat} (W)	P _{tot} (W)
16	1	10	13	10	15	11	18	12	25	14	37
32	2	20	27	20	30	21	36	23	49	27	75
64	4	40	53	41	60	43	73	46	98	54	150
96	6	60	80	61	90	64	109	70	148	81	224
128	8	70	94	71	105	75	128	81	172	95	262
160	10	99	134	102	150	107	182	116	246	135	374
192	12	119	160	122	180	128	219	139	295	162	449
240	15	149	200	153	225	160	273	174	369	203	561
256	16	159	214	163	240	171	291	186	394	217	598
Maximum power setting: 1500 mW (4500 mW for IF16)											
Power feeding mode: Restricted (that is, Eksos N20 feeds NT + REG + UNI)											

Table 13 Configuration of 15 NTs and 1 NT + REG, with restricted power

IFs pcs	Units pcs	60 mErl		125 mErl		250 mErl		500 mErl		1000 mErl	
		P _{heat} (W)	P _{tot} (W)	P _{heat} (W)	P _{tot} (W)	P _{heat} (W)	P _{tot} (W)	P _{heat} (W)	P _{tot} (W)	P _{heat} (W)	P _{tot} (W)
16	1	10	12	10	13	10	12	10	16	11	21
32	2	20	25	20	26	20	25	21	33	22	42
64	4	39	50	39	52	39	50	42	66	44	84
96	6	59	74	59	78	59	74	62	98	66	126
128	8	68	87	69	91	68	87	73	115	78	147
160	10	98	124	99	130	98	124	104	164	111	210
192	12	117	149	118	156	117	149	125	197	133	252
240	15	147	186	148	195	147	186	156	246	166	315
256	16	157	198	158	208	157	198	166	262	177	336
Maximum power setting (P _{max}): 1500 mW (4500 mW for IF16)											
Power feeding mode: Normal (that is, Eksos N20 feeds NT + REG)											

Table 14 Configuration of 15 NTs and 1 NT + REG, with normal power

In Tables 16 and 17, the following power and resistance values have been used.

Attribute	Value
Power NTab	1.7 W
Loop resistance NTab	1000 Ω

Table 15 Power and loop resistance values for NTab

IFs pcs	Units pcs	60 mErl		125 mErl		250 mErl		500 mErl		1000 mErl	
		P _{heat} (W)	P _{tot} (W)	P _{heat} (W)	P _{tot} (W)	P _{heat} (W)	P _{tot} (W)	P _{heat} (W)	P _{tot} (W)	P _{heat} (W)	P _{tot} (W)
16	1	10	14	10	16	11	21	12	30	15	48
32	2	20	28	21	32	22	41	25	59	30	96
64	4	40	55	41	65	44	83	50	119	60	191
96	6	60	83	62	97	66	124	74	178	91	287
128	8	70	96	72	113	77	145	87	208	106	335
160	10	100	138	103	161	110	207	124	297	151	478
192	12	120	165	124	194	132	248	149	357	181	574
240	15	150	207	155	242	165	310	186	446	227	718
256	16	160	221	166	258	176	331	198	476	242	765
Maximum power setting: 2250 mW											
Power feeding mode: Restricted (that is, Eksos N20 feeds NTab + UNI)											

Table 16 Configuration of 16 NTabs, with restricted power

IFs pcs	Units pcs	60 mErl		125 mErl		250 mErl		500 mErl		1000 mErl	
		P _{heat} (W)	P _{tot} (W)	P _{heat} (W)	P _{tot} (W)	P _{heat} (W)	P _{tot} (W)	P _{heat} (W)	P _{tot} (W)	P _{heat} (W)	P _{tot} (W)
16	1	10	12	10	12	10	13	10	15	11	19
32	2	19	24	20	25	20	26	20	30	21	37
64	4	39	48	39	49	40	53	41	60	43	74
96	6	58	71	59	74	59	79	61	90	64	111
128	8	68	83	68	86	69	93	71	105	75	130
160	10	97	119	98	124	99	132	102	150	107	185
192	12	117	143	117	148	119	159	122	180	129	223
240	15	146	178	147	185	149	199	153	225	161	278
256	16	155	190	157	198	159	212	163	240	171	297
Maximum power setting: 2250 mW											
Power feeding mode: Normal (that is, Eksos N20 feeds NTab)											

Table 17 Configuration of 16 NTabs, with normal power

Chapter 5

PSTN mapping

5.1 Recommendations and standards

PSTN mapping is implemented according to the *German PSTN mapping*.

5.2 Key features

Supported services

Note that all the services listed below are activated in the Local Exchange (LE).

- Sending of CLI (Calling Line Identity) to user terminal
 - The LE sends the subscriber number information of the calling party to the called terminal.
- Sending subscriber private metering information to user terminal.

Ringling types

Initial ring		
Type 0	Normal ringing	1.0 s ring, (with notification of the ended sequence)
Cadenced ringing		
Type 0	Normal ringing	1.0 s ring, 4.0 s pause

Table 18 Ringling types

8.7.14 Management

ITU-T	Recommendation name
G.773	Management interface Q3
G.774.01	Synchronous Digital Hierarchy - Performance Monitoring for the Network Element View
G.774.02	Synchronous Digital Hierarchy - Management information model
G.826	Error performance and objectives for international, constant bit rate digital paths at or above the primary rate
M.3100	Generic Network Information Model - Maintenance: Telecommunications Management Network
M.3400	TMN Management Functions - Maintenance Telecommunications Management Network
Q.811	Lower layer protocol profiles for the Q3 interface
Q.812	Upper layer protocol profiles for the Q3 interface
Q.835	Line and line circuit test management of ISDN and analogue customer access

ETSI	Recommendation name
ETS 300 304	SDH Information Model for the Network Element View
ETS 300 150	Protocol suites for Q interfaces for management transmission systems equipment
EN 300 376-1	Q3 interface at the Access Network (AN) for configuration management of V5 interfaces and associated user ports Part 1: Q3 Interface Specification
EN 300 377-1	Q3 interface at the Local Exchange (LE) for configuration management of V5 interfaces and associated customer profiles Part 1: Q3 Interface Specification
EN 300 378-1	Q3 interface at the Access Network (AN) for fault and performance management of V5 interfaces and associated user ports Part 1: Q3 Interface Specification
EN 300 379-1	Q3 interface at the Local Exchange (LE) for fault and performance management of V5 interfaces and associated customer profiles Part 1: Q3 Interface Specification
ETS 300 795	V interface at the digital Local Exchange (LE); Access Network (AN) supporting V5; Transmission characteristics and performance design objectives for call handling and bearer channel connection management

Glossary

Abbreviations

2B1Q	2 Binary, 1 Quaternary	DC-PSA	Nokia DC Power Supply Adapter
4B3T	4 Binary, 3 Ternary	DEG	Degraded signal
10Base-2	10 Mbit/s baseband 185 meters per segment Ethernet LAN	DIU	Data Interface Unit
10Base-T	10 Mbit/s baseband Ethernet using twisted pair cabling	DTE	Data Terminal Equipment
ACL2	Nokia 2 Mbit/s HDSL line terminal	DNT128	Nokia 2 x 64 kbit/s network terminal
ACM2	Nokia 2 Mbit/s primary multiplex equipment	DNT2M	Nokia 2 Mbit/s HDSL network terminal
ADM	Add/Drop Multiplexer	DNT2M-G	Nokia 2 Mbit/s G.703/G.704 network terminal
ADSL	Asymmetric Digital Subscriber Line	DXC	Digital Cross-connect
AFI	Authority and Format Identifier	E&M	Earth/Minus signalling
AIS	Alarm Indication Signal	ECC	Embedded Communications Channel
AN	Access Network	EFD	Event Forwarding Discriminator
AUX	Auxiliary	EMC	Electromagnetic Compatibility
BCC	Bearer Channel Connection	ENM	Eksos Node Manager
BRA	Basic Rate Access	ESD	Electrostatic Discharge
CCBS	Completion of Calls to Busy Subscribers	ETSI	European Telecommunications Standards Institute
CLI	Calling Line Identity	GND	Ground
CORE2M	Main unit of SAN, with 2 Mbit/s interfaces	HDSL	High data rate Digital Subscriber Line
CPU	Central Processing Unit	ID	Identification
CRC	Cyclic Redundancy Check	IDI	Initial Domain Identifier
DCC	Data Communications Channel	ISDL	ISDN Digital Subscriber Line
DCE	Data Circuit-terminating Equipment	IF	Interface
DCN	Data Communication Network	IN	Intelligent Network

Nokia Eksos N20 Glossary

ISDN	Integrated Services Digital Network	PSTN	Public Switched Telephone Network
ITU-T	International Telecommunication Union – Telecommunication Standardization Sector	Q1 (Q1')	Nokia's proprietary management interface (= V.11)
LAN	Local Area Network	Q3	network-node management interface (ITU-T)
LE	Local Exchange	RDI	Remote Defect Indication
LED	Light-Emitting Diode	REG	Regenerator
LL	Leased Line	SAN	SYNFONET Access Node
LMU	Line Measurement Unit	SDH	Synchronous Digital Hierarchy
LOS	Loss Of Signal	SPLL	Semi-permanent Leased Line
LT	Line Termination	SPS	Signalling Protocols and Switching
MEB	Main Earthing Bar	SSF	Server Signal Failed
NCU	Node Control Unit	STM-1	Synchronous Transport Module, level 1
NMS	Nokia Network Management System	T	Unit of width in mechanics, 5.08 mm
NSAP	Network Service Access Point	TDM	Time-division Multiplexing
NT	Network Termination	TE	Terminal Equipment
NTM	Nokia Transmission Mechanics, mechanics platform suitable for several network elements	TM	Terminal Multiplexer
ODBC	Open Database Connectivity	TR2M4	4 x 2 Mbit/s interface unit
OSI	Open Systems Interconnection	TS	Time Slot
OVP	Over-Voltage Protection	U	Unit
PABX	Private Automatic Branch Exchange	U	Unit of height in mechanics, 44.45 mm
PCM	Pulse Code Modulation	UNI	User-network Interface
PDH	Plesiochronous Digital Hierarchy	VF	Voice Frequency
PE	Protective Earth	WAN	Wide Area Network
PEN	Protective Earth and Neutral connected together		

Terms

19-inch rack

A rack which is 19 inches wide and conforms to the IEC 297 specification.

access node

A node implemented between the local exchange (LE) and the user, replacing part or the whole of the local line distribution network.

The access node may consist of multiplexing, cross-connect and transmission functions.

active bank

See *leased line bank*.

actual unit

See *expected unit*.

aggregate

That side of the node that provides the interfaces towards the centre of network.

alarm indication signal; AIS

A signal which replaces the normal traffic signal when a critical or major alarm indication has been activated.

asymmetric digital subscriber line; ADSL

Technology which enables high speed data communications over existing twisted pair telephone lines and supports downstream data rate of 1.5 to 8 Mbit/s and upstream data rate of 16 kbit/s to 1 Mbit/s.

An ADSL line uses frequency division to separate the PSTN/ISDN channel, enabling simultaneous PSTN/ISDN and ADSL communications and guaranteeing uninterrupted PSTN/ISDN, even if asymmetric digital subscriber line (ADSL) fails.

authority and format identifier; AFI

See *NSAP address*.

backplane

A printed circuit board of a subrack or cartridge, where the plug-in units are connected. Also known as *motherboard*.

bearer channel

A channel (64 kbit/s time slot) on a V5-type interface used to carry subscriber traffic.

cable tray

A construction used in Nokia Eksos N20 installations for guiding cables from the front of the node directly into the front of the construction, where they are secured with strain reliefs, and for improving thermal management of the node.

Capacitor Unit

A unit that provides back-up power during short power disturbances.

cartridge

A mechanical housing that fits in a rack and contains plug-in units.

centrex

A service implemented in public telecommunications exchange which enables the subscriber lines connected to the exchange to use the facilities typical for private branch exchanges or key telephone system extensions.

C-channel (communication channel)

A channel (64 kbit/s time slot) on a V5-type interface used for messaging between the node and the local exchange.

commissioning

The process of taking software or hardware into use for the first time.

concentration

Configuration of a V5.2 interface where the number of subscribers is larger than the number of bearer channels.

cross-connection

Either fixed or flexible connection between two termination points with the same data rate.

data communication network; DCN

A telecommunication network mainly meant for transmitting network management data.

A data transmission network can either be a stand-alone network or be a part of or connected to a telecommunication network. It can be a dedicated network or it can use circuits or channels reserved from other telecommunication network.

dry loop

A feature which allows a PSTN/ISDN interface to be isolated from the subscriber loop, after which it can be tested.

earthing

To make an electric connection between a given point in equipment and the Earth.

Also referred to as *grounding*.

EF address

The address of an ISDN subscriber in a V5 interface.

embedded data communication channel

A channel which is provided as an integral part of a communications facility for the purpose of carrying operations messages. Also known as embedded operations channel (EOC).

equipment loopback

A method for testing the operation of an interface in which the outgoing signal is looped back to the input.

ETSI rack

A rack that conforms to the ETSI specification ETS 300 119-3 and accommodates 500 mm wide subracks or 19-inch subracks with adapters.

event

A notification of a change in the state of the node or of a momentary problem, usually in the communication between the node and the local exchange.

An event is not an alarm.

expected unit

A plug-in unit configured as the default unit in a particular slot in a node.

If the plug-in unit actually installed in the slot (actual unit) differs from the expected unit, the node will send an Unit Mismatch alarm.

extension board

A board at the back of a subrack or cartridge which makes the connectors more easily accessible and includes connectors for station alarms, service switch, test buses, SV1 measurement, overvoltage protection, power supply, fans and signalling voltage.

Extension Unit

A unit that provides four additional outputs for DC-PSA.

Extension Unit is needed, for example, in racks that contain four Nokia Eksos N20 subracks.

Fan Unit

A unit providing forced air circulation for a variety of telecommunications equipment installed in IEC and ETSI compliant mechanical constructions.

fatal error

An unexpected condition where signal transfer is no longer possible.

forced convection

A cooling method which is based on using an external agency to maintain the airflow in a device.

grading message

A message from the node to the local exchange about degraded ISDN line quality.

granularity

The bit rate at which a cross-connection is made.

In Nokia Eksos N20 the granularity is 64 kbit/s, that is, one time slot of a 2 Mbit/s signal. This means that even if a data interface is configured for 9.6 kbit/s it will be cross-connected at 64 kbit/s.

grooming

The merging of partially filled transmission lines into almost fully utilised lines for increased transmission effectivity.

In Nokia Eksos N20, grooming can be used for collecting V5.1 traffic to a V5.2 interface.

grounding

See *earthing*.

high bit rate digital subscriber line; HDSL

Broadband technology based on copper cables, carrying out a high-rate symmetric digital subscriber connection with two copper cable pairs.

hot insert

A feature enabling to detect, configure and use hardware that has been added to a node while it is actively running.

inactive bank

See *leased line bank*.

Indoor Access Cabinet

A construction system for housing access node equipment, such as Nokia Eksos N20 and the DYNANET products, providing the subscriber lines to customers.

initial domain identifier; IDI

See *NSAP address*.

installation

The assembly of constructional parts into a cartridge, subrack and rack, carried out before commissioning.

interface loopback

A method for testing the operation of an interface in which the incoming signal is looped back to the output.

ISDN digital subscriber line; IDSL

An xDSL service based on the use of standard ISDN 2B+D transmission technology. It provides (typically frame relay) data access with variable bit rate including 64 kbit/s and 128 kbit/s.

L3 address

An address identifying a PSTN subscriber port within a V5 interface.

leased line

A permanent connection between two interfaces which is not routed through a local exchange.

leased line bank

A set of leased lines stored in the node.

Nokia Eksos N20 contains two banks, one of which is always active.

link

A 2 Mbit/s interface used for communicating with the local exchange.

In Nokia Eksos N20, link is a 2 Mbit/s interface used for V5 transmission. Within V5.2, links have unique IDs, whereas within V5.1, links have no IDs.

See also *primary link* and *secondary link*.

motherboard

See *backplane*.

multihosting

A feature which enables the same node to be connected to several different local exchanges via separate V5.2 interfaces. It is used for load balancing or taking advantage of the services offered by various local exchanges.

natural convection

A cooling method which is based on the physical phenomenon of warmer air having a smaller density than colder air, resulting in an upward flow of hot air.

NMS

System for controlling and monitoring network elements, for recording their use and performance, in order to provide telecommunications services.

node master

A node control unit (NCU) performing the configuration, data communication network (DCN) and synchronisation related functions.

NSAP address

The address of the node in the data communication network (DCN).

In Nokia Eksos N20, the NSAP address consists of the system ID, authority and format identifier (AFI), initial domain identifier (IDI) and area address.

on demand line testing

A set of line tests to be performed immediately to one or several interfaces.

See also *scheduled line testing*.

OSI-DCN Adaptor

A plug-in unit used to build data communications network between network elements and the management site. Together with the cross-connection function, the OSI-DCN Adaptor groups several embedded communication channels (ECCs) into a single 2 Mbit/s connection and passes these to an OSI router via Ethernet, where protocol stacks are similar.

Outdoor Cabinet

A roadside cabinet that houses, for example, Nokia Eksos N20 and DYNANET products.

primary link

A 2 Mbit/s link carrying vital signalling.

See also *secondary link*.

product code

A code which is used for identifying sales items: plug-in units, programs, manuals etc. Example: T30000.01.

product release

A letter by which the different releases of a product or its part can be identified and separated from each other.

Example: product identification T30000.01 A, where 'T30000.01' is the product code and 'A' is the product release. The first release of each product is 'A', and when the product is enhanced or otherwise changed, the release is incremented (to 'B', 'C' ...). See also *system release*.

PSTN mapping

The usually country-specific definition of the relationship between analog PSTN signalling elements and the V5 protocol.

Q1

A serial protocol used in transferring management information to and from a network element.

Q1 is Nokia's proprietary management protocol.

Q1 master

The computer (PC) used for managing Q1 nodes.

Q1 slave

A node managed by the Q1 master.

Q1 summing point

A virtual point in the network where the traffic from Q1 slaves is collected together and forwarded to the Q1 master in one leg.

Q3

A set of OSI 7 standard definitions for the transfer of management information to and from a network element across the telecommunications management network q reference point.

rack alarm

An alarm in one of the equipment in the rack indicated by a common alarm lamp. There are three types of rack alarms: A-alarms (prompt), B-alarms (deferred) and D-alarms (reminders of alarm cancellation). Also known as *station alarm*.

release

See *system release* and *product release*.

scheduled line testing

Line tests performed to one or several interfaces at pre-defined dates, times and intervals.

See also *on demand line testing*.

secondary link

A stand-by 2M link used for protection of vital signalling.

See also *primary link*.

semi-permanent leased line; SPLL

A permanent connection provided between two user-network interfaces routed through the local exchange.

service switch

A feature which enables changing subscriber services via the management system, instead of switching the physical connection cables.

signalling

In Nokia Eksos N20, communication between the node and the local exchange.

signalling protection

A configuration in which hardware resources are reserved for taking over in case some other hardware fails.

See also *V5 protection*.

splitter

An analog device for dividing a combined PSTN/ADSL input signal into a PSTN and an ADSL output signal or combining a PSTN and an ADSL input signal together into one output signal.

stand-by time slot

A time slot protecting another time slot carrying ISDN or PSTN signalling.

subrack

A mechanical housing that fits in a rack and contains plug-in units.

switched service

A service which is connected through the network on the basis of the telephone number dialled.

system release

Defines the system and equipment level functionality and compatibility. See also *product release*.

tributary

That side of the node that provides the interfaces towards the subscriber.

U-interface

An interface between an ISDN network termination equipment (NT1) and the local exchange.

user port

In Nokia Eksos N20, a POTS or ISDN interface which is taken into V5 use and provided with a telephone number.

user port blocking

A feature used for discontinuing the functioning of a user port on account of unpaid telephone bills, for example.

V5

A signalling interface between an access node and local exchange using 64 kbit/s channels and 2 Mbit/s links.

There are two variants of V5: V5.1 and V5.2.

V5 master

A node control unit (NCU) dedicated for a V5.2 interface, executing the actual V5.2 software.

V5 protection

A feature which enables to move signalling to another link if there is a problem with the link carrying the C-channel.

V5 slave

A node control unit (NCU) providing additional 2 Mbit/s interfaces for a V5.2 interface.

V5.1 to V5.2 conversion

Application where the user ports of one or more V5.1 interfaces are presented as normal user ports to a V5.2 interface.

V5.1 interface

A static multiplexer interface between the local network and subscribers who physically belong to a separate subscriber network.

The V5.1 interface is designed in accordance with the standard ETS 300 324-1 and it supports analog subscriber lines, ISDN basic rate access and semi-permanent connections. In V5.1 the bearer channels for user ports are allocated statically.

V5.2 interface

A dynamic concentrator interface between the local network and subscribers who physically belong to a separate subscriber network.

The V5.2 interface is designed in accordance with the standard ETS 300 327-1 and it supports analog subscriber lines, ISDN basic rate access and semi-permanent connections. V5.2 can supply a maximum of sixteen 2 Mbit/s lines and channel protection. In V5.2 the bearer channels for user ports are allocated dynamically.

vital signalling

Communication between the node and the local exchange, excluding POTS and ISDN signalling, used for keeping the connection up and running.

vital stand-by

The time slot that is used to protect the time slot carrying vital signalling.

Wall Mounting Set

A mechanical construction for mounting a 17-slot Nokia Eksos N20 node in a small location.

In addition to the subrack, the Wall Mounting Set can also accommodate a DC-PSA, Fan Unit and cross-connection panel.

Index

Numbers

- 2 Mbit/s interface, connector pinout (TR2M4):
Installation 72
- 2 Mbit/s interfaces, connector pinout (NCU):
Installation 61
- 2M interfaces, configuring:
Comm. and Maintenance 25
- 2M links
 - adding to existing V5 interface:
Comm. and Maintenance 60
 - configuring in V5.1:
Comm. and Maintenance 47
 - configuring in V5.2:
Comm. and Maintenance 40
 - primary: *Comm. and Maintenance* 43
- 2M-LOS:
Comm. and Maintenance B-10–B-12
- 2M-RDI:
Comm. and Maintenance B-13
- 2M-SSF:
Comm. and Maintenance B-14
- 2M-AIS:
Comm. and Maintenance B-1

A

- abbreviations. *See* Glossary
- access levels:
Comm. and Maintenance A-7
- setting:
Comm. and Maintenance A-9
- actual unit in slot:
Comm. and Maintenance 25
- Add Manual Adjacency dialox box:
Comm. and Maintenance 30

- addresses
 - EF:
Comm. and Maintenance 58
 - L3:
Comm. and Maintenance 58
 - NSAP:
Comm. and Maintenance 22, A-5
- advanced settings, V5.1, configuring:
Comm. and Maintenance 45
- advanced settings, V5.2, configuring:
Comm. and Maintenance 37
- AFI:
Comm. and Maintenance 22
- air deflectors
 - installing:
Installation 107
 - use:
Product Description 49
- AIS:
Comm. and Maintenance B-1
- alarm cables:
Installation 21, 29
- Alarm Indication Signal:
Comm. and Maintenance B-1
- Alarm Input:
Comm. and Maintenance B-2
- Alarm List Incomplete:
Comm. and Maintenance B-2
- alarm log, setting:
Comm. and Maintenance 71
- alarm thresholds:
Comm. and Maintenance 36
- configuring:
Comm. and Maintenance 53

alarms

alarm connector pinout:

Installation 31

colour codes in Node Manager:

Comm. and Maintenance 94

configuring:

Comm. and Maintenance 96

current alarms list:

Comm. and Maintenance 71, 97

descriptions:

Comm. and Maintenance B-1

disabling:

Comm. and Maintenance 95

managing with Node Manager:

Comm. and Maintenance 96

messages:

Comm. and Maintenance B-1

rack:

Comm. and Maintenance 95

severity:

Comm. and Maintenance 95

severity classes:

Comm. and Maintenance 93

alarm inputs, external:

Product Description 19

analog inputs, configuring:

Comm. and Maintenance 35

anti-static precautions:

Installation 4

application window:

Comm. and Maintenance A-11

applications, introduced in release C2.0:

System Rel. Notes 2

AUX interface, connector pinout:

Installation 79

AUX management interface, connector pinout:

Installation 63

B

back-up, configuration:

Comm. and Maintenance A-15

Backup Fail:

Comm. and Maintenance B-2

balanced interface:

Installation 93–95

BCC Protocol Syntax Error:

Comm. and Maintenance B-2

bearer channel allocation:

Product Description 7

BKUP:

Comm. and Maintenance B-2

blanking plates, fitting:

Installation 87

block status, viewing:

Comm. and Maintenance 77

C

C-channel, ID:

Comm. and Maintenance 43

C-channel, signalling settings:

Comm. and Maintenance 43

C-channel, V5.1, configuring:

Comm. and Maintenance 47

C-channel, V5.2, configuring:

Comm. and Maintenance 42

cable ties:

Installation 11–13, 88

cable trays:

Product Description 50

installing:

Installation 53–56

mounting to rack:

Installation 54–56

tying cables to:

Installation 91

cables

alarm:

Installation 21, 29

earthing:

Installation 49

Ethernet:

Installation 50

grounding:

Installation 49

marking:

Installation 13–15

order codes:

Installation 21, 29

power:

Installation 21, 29

routing in the rack:

Installation 11–13

types used in Eksos N20:

Installation 58–60

cabling

Data Interface Unit:

Installation 89

Ethernet:

Installation 101–104

optical:

Installation 15

plug-in units:

Installation 88

- cabling space:
 - Installation 7*
- Calling Line Identification (CLI):
 - Country Specific Instr. 15*
- Capacitor Unit, use:
 - Product Description 47*
- capacity of Eksos N20:
 - Product Description 7*
- cartridge
 - attaching to shelf:
 - Installation 45*
 - construction:
 - Installation 41*
 - dimensions:
 - Installation 41*
 - installation:
 - Installation 41*
 - mounting onto cartridge shelf:
 - Installation 43*
 - unit locations:
 - Installation 84*
- cartridge extension board:
 - Installation 30*
- cartridge extension board connectors, specifications:
 - Product Description 60*
- cartridge shelf:
 - Installation 43*
 - installing:
 - Installation 42*
- cartridges, Eksos N20:
 - Product Description 48*
 - dimensions:
 - Product Description 49*
- CCH:
 - Comm. and Maintenance B-3*
- Cessation of Flags on a C-channel:
 - Comm. and Maintenance B-3*
- changing node settings:
 - Comm. and Maintenance 24*
- clearing node configuration data:
 - Comm. and Maintenance 91*
- closing the node manager:
 - Comm. and Maintenance 90*
- CMPF:
 - Comm. and Maintenance B-3*
- coaxial 2 Mbit/s interface (SAN), connector pinout:
 - Installation 78*
- coaxial connectors, on TR2M4:
 - Installation 72*
- coding block:
 - Installation 82*
- commissioning
 - basic procedure:
 - Comm. and Maintenance 5*
 - basic settings:
 - Comm. and Maintenance 4–6*
 - general procedure:
 - Comm. and Maintenance 3*
 - leased lines:
 - Comm. and Maintenance 13*
 - requirements:
 - Comm. and Maintenance 4*
 - scheduled line testing:
 - Comm. and Maintenance 14*
 - service switch:
 - Comm. and Maintenance 11–13*
 - V5.1/V5.2 converter:
 - Comm. and Maintenance 9–11*
 - V5.2 multiplexer:
 - Comm. and Maintenance 6–9*
- communications failure:
 - Comm. and Maintenance A-19*
- compatibility, internal:
 - System Rel. Notes 1*
- Compatibility Failure:
 - Comm. and Maintenance B-3*
- compatibility of Eksos N20, with other products:
 - System Rel. Notes 1*
- concentration, network:
 - Product Description 24*
- configuration back-up:
 - Comm. and Maintenance A-15*
- configuring
 - 2M interfaces:
 - Comm. and Maintenance 25*
 - alarm inputs:
 - Comm. and Maintenance 33*
 - alarm outputs:
 - Comm. and Maintenance 34*
 - alarms:
 - Comm. and Maintenance 96*
 - analog inputs:
 - Comm. and Maintenance 35*
 - cross-connections:
 - Comm. and Maintenance 67*
 - DC set:
 - Comm. and Maintenance 49*
 - DIU interfaces:
 - Comm. and Maintenance 65*
 - ISDN interfaces:
 - Comm. and Maintenance 51*
 - management channels:
 - Comm. and Maintenance 29*

- PSTN interfaces:
 - Comm. and Maintenance* 49
 - service switch:
 - Comm. and Maintenance* 61
 - speech settings:
 - Comm. and Maintenance* 49
 - stack settings:
 - Comm. and Maintenance* A-6
 - user ports:
 - Comm. and Maintenance* 56
 - V5 interface:
 - Comm. and Maintenance* 37
 - V5.1 interface:
 - Comm. and Maintenance* 45
 - V5.2 interface:
 - Comm. and Maintenance* 37
 - connecting
 - Eksos N20 to SAN:
 - Installation* 91–94
 - external synchronisation interfaces:
 - Installation* 93–95
 - interfaces:
 - Installation* 57
 - management cables:
 - Comm. and Maintenance* 18
 - power supply:
 - Installation* 19
 - service switch cables:
 - Installation* 95–98
 - station alarms:
 - Installation* 19
 - connecting Node Manager to node:
 - Comm. and Maintenance* 20
 - connector carriers, inserting and replacing:
 - Installation* 88–90
 - connector pinout
 - AUX interface:
 - Installation* 79
 - AUX management interface:
 - Installation* 63
 - external supervisory interface:
 - Installation* 64
 - external test access interface:
 - Installation* 66
 - fan:
 - Installation* 27
 - fan and alarm:
 - Installation* 31
 - G.703 interface:
 - Installation* 76
 - ISDN interface:
 - Installation* 70
 - LMU. *See* connector pinout, NCU
 - NCU:
 - Installation* 61–65
 - power:
 - Installation* 26, 32
 - PSTN interface:
 - Installation* 68–70
 - Q1 management interface:
 - Installation* 63
 - Q3 management interface:
 - Installation* 64
 - SAN CORE2M coaxial 2 Mbit/s interface:
 - Installation* 78
 - SAN CORE2M symmetrical 2 Mbit/s interface:
 - Installation* 78
 - service switch:
 - Installation* 24
 - signalling voltage:
 - Installation* 26, 32
 - SR synchronisation interface (SAN):
 - Installation* 79
 - ST synchronisation interface (SAN):
 - Installation* 80
 - station alarm outputs:
 - Installation* 23, 31
 - SV1 measurement:
 - Installation* 25
 - test bus:
 - Installation* 25
 - TR2M4 unit:
 - Installation* 72
 - V.xx interface (DIU):
 - Installation* 74
 - X.21 interface (DIU):
 - Installation* 75
- connectors
 - DIU:
 - Installation* 73
 - ISDN unit:
 - Installation* 67
 - LMU:
 - Installation* 65
 - NCU:
 - Installation* 60
 - PSTN unit:
 - Installation* 67
 - SAN CORE2M:
 - Installation* 77
 - TR2M4:
 - Installation* 71
- Control Protocol Syntax Error:
 - Comm. and Maintenance* B-3
- Control Protocol Time Out:
 - Comm. and Maintenance* B-3
- conversion from V5.1 to V5.2:
 - Product Description* 24
- cooling
 - forced convection:
 - Product Description* 41

natural convection:
Product Description 40

CORE2M unit:
Installation 77

interfaces:
Product Description 44

creating V5 interface:
Comm. and Maintenance 37

Critical Fan Failure:
Comm. and Maintenance B-4

cross-connect function:
Product Description 10

current alarms list:
Comm. and Maintenance 71

D

Data folder:
Comm. and Maintenance A-2

Data Interface Unit

 cabling:
 Installation 89

 configuring interfaces:
 Comm. and Maintenance 65

 connecting cables to:
 Installation 90

 connector pinout:
 Installation 74–77

 connectors:
 Installation 73

 EMC in cabling:
 Installation 89

 loopback tests:
 Comm. and Maintenance 85

Database folder:
Comm. and Maintenance A-3

DC set:
Country Specific Instr. 3, 8

 configuring:
 Comm. and Maintenance 49

DC-PSA, features:
Product Description 47

DCN channels, setting:
Comm. and Maintenance 29

defects, corrected:
System Rel. Notes 4

DEG:
Comm. and Maintenance B-4

DEG alarm parameters:
Comm. and Maintenance 53

Degraded Signal:
Comm. and Maintenance B-4

digital inputs, configuring:
Comm. and Maintenance 33

digital outputs, configuring:
Comm. and Maintenance 34

dimensions, mechanical:
Product Description 60

direct battery, PSTN:
Country Specific Instr. 9

DIU unit, interfaces:
Product Description 45

DLF:
Comm. and Maintenance B-16, B-17, B-18, B-20

downloading software, with Node Manager:
Comm. and Maintenance 101

Dying Gasp:
Comm. and Maintenance B-4

E

earth loops:
Installation 47

earthing:
Installation 49

Ethernet cables:
Installation 50

multiple racks:
Installation 47–49

protective:
Installation 47

rack:
Installation 49

station:
Installation 47

subrack:
Installation 50

wrist strap:
Installation 85

earthing bus conductor:
Installation 49

earthing wire, minimum cross-section:
Installation 50

EBOF:
Comm. and Maintenance B-5

EF addresses:
Comm. and Maintenance 58

EksosNM2.0 folder:
Comm. and Maintenance A-2

Eksos Node Manager window:
Comm. and Maintenance A-11

- electrical cables
 - precautions:
 - Installation* 5
 - routing:
 - Installation* 11
 - tying to cable trays:
 - Installation* 91
 - electro-static discharge (ESD), sensitivity to ESD:
 - Installation* 4
 - EMC:
 - Installation* 81, 87, 108
 - EMC gasket:
 - Installation* 94
 - in cabling DIUs:
 - Installation* 89
 - specifications:
 - Product Description* 63, 64
 - equipping recommendations
 - for a 17-slot subrack:
 - Installation* 34–36
 - for an 8-slot cartridge:
 - Installation* 43–45
 - ESD. *See* electro-static discharge
 - Ethernet cable, connecting Node Manager to node:
 - Comm. and Maintenance* 18
 - Ethernet cables
 - connecting to service connector panel:
 - Installation* 40
 - earthing:
 - Installation* 50
 - terminating:
 - Installation* 40
 - Ethernet cabling:
 - Installation* 101–104
 - Event Buffer Overflow:
 - Comm. and Maintenance* B-5
 - event history log:
 - Comm. and Maintenance* 71
 - clearing:
 - Comm. and Maintenance* 73
 - setting up:
 - Comm. and Maintenance* 73
 - viewing:
 - Comm. and Maintenance* 72
 - EXC:
 - Comm. and Maintenance* B-5
 - Excessive Bit Error Ratio:
 - Comm. and Maintenance* B-5
 - exiting from the Node Manager:
 - Comm. and Maintenance* 89–91
 - expected unit in slot:
 - Comm. and Maintenance* 25
 - extension board, functions:
 - Product Description* 36
 - Extension Unit:
 - Product Description* 47
 - external alarms:
 - Product Description* 19
 - configuring:
 - Comm. and Maintenance* 32–34
 - external supervisory interface, connector pinout:
 - Installation* 64
 - external synchronisation interfaces, connecting:
 - Installation* 93–95
 - external test access interface, connector pinout:
 - Installation* 66
- ## F
- FAIL:
 - Comm. and Maintenance* B-16
 - FAN:
 - Comm. and Maintenance* B-4, B-5
 - Fan Failure:
 - Comm. and Maintenance* B-5
 - Fan Unit, installing:
 - Installation* 105
 - Far End Block Error:
 - Comm. and Maintenance* B-5
 - fault messages:
 - Comm. and Maintenance* 93
 - fault tolerance:
 - Product Description* 13
 - features, introduced in release C2.0:
 - System Rel. Notes* 2
 - features of Eksos N20:
 - Product Description* 5–9
 - FEBE:
 - Comm. and Maintenance* B-5
 - Feeding Current Short Circuit:
 - Comm. and Maintenance* B-6
 - Feeding Power Overload:
 - Comm. and Maintenance* B-6
 - Feeding Power Supply Failure:
 - Comm. and Maintenance* B-6
 - feeding voltage, to ISDN line:
 - Country Specific Instr.* 11

Feeding Voltage Failure:
Comm. and Maintenance B-6

fibre cable reels, installing:
Installation 17

files
loading data from:
Comm. and Maintenance A-17–A-19
saving data to:
Comm. and Maintenance A-15–A-17

FORC:
Comm. and Maintenance B-15

forced convection:
Product Description 41

FPO:
Comm. and Maintenance B-6

FPS:
Comm. and Maintenance B-6

FPSF:
Comm. and Maintenance B-6

front cover
alignment:
Installation 108
attaching:
Installation 108
detaching:
Installation 108

front grilles, installing:
Installation 107

FVF:
Comm. and Maintenance B-6

G

G.703 interface, connector pinout:
Installation 76

General Problem DNT:
Comm. and Maintenance B-7

GPD:
Comm. and Maintenance B-7

grading message:
Comm. and Maintenance 58

ground loops:
Installation 47

grounding:
Installation 47
Ethernet cables:
Installation 50
multiple racks:
Installation 47–49
rack:
Installation 49

station:
Installation 47
subrack:
Installation 50

grounding wire, minimum cross-section:
Installation 50

Group Memberships dialog box:
Comm. and Maintenance A-9

GSP:
Comm. and Maintenance B-4

H

Help, online:
Comm. and Maintenance A-14

hot insert feature:
Product Description 19

I

IBOU:
Comm. and Maintenance B-7

IDI:
Comm. and Maintenance 22, A-5

IDs
C-channel:
Comm. and Maintenance 43
link:
Comm. and Maintenance 41
V5.1 interface:
Comm. and Maintenance 45
V5.2 interface:
Comm. and Maintenance 38

impedance pairs:
Country Specific Instr. 4, 9

In Test:
Comm. and Maintenance B-7

INF folder:
Comm. and Maintenance A-3

Information window:
Comm. and Maintenance 23

Input Buffer Overflow/Underflow:
Comm. and Maintenance B-7

installation
procedure:
Installation 7
task list:
Installation 7
thermal management, in open racks:
Product Description 40

- tools:
 - Installation 9*
- installation options:
 - Product Description 35*
- Installation Wizard:
 - Comm. and Maintenance 21*
- installation wizard:
 - Comm. and Maintenance 20*
- installation, thermal management, in cabinets:
 - Product Description 42*
- installing
 - air deflectors:
 - Installation 107*
 - cable trays:
 - Installation 53–56*
 - cartridge:
 - Installation 44*
 - Fan Unit:
 - Installation 105*
 - front grilles:
 - Installation 107*
 - plug-in units, work procedure:
 - Installation 81*
 - service connector panel:
 - Installation 40*
 - subrack front cover:
 - Installation 108*
- installing
 - cartridge:
 - Installation 41*
 - cartridge onto a cartridge shelf:
 - Installation 43*
 - cartridge shelf:
 - Installation 42*
 - subrack:
 - Installation 33*
 - subrack to rack:
 - Installation 34–37*
- installing units in a node:
 - Comm. and Maintenance 22, 24–26*
- Interface Broken:
 - Comm. and Maintenance B-8*
- interface tests:
 - Comm. and Maintenance 82, 85*
- interface types:
 - Product Description 33*
- interface units:
 - Product Description 44*
- Interfaces, synchronisation interface, pinout:
 - Installation 62*
- interfaces
 - 2 Mbit/s interface, pinout (NCU):
 - Installation 61*
 - AUX interface, pinout:
 - Installation 79*
 - coaxial 2 Mbit/s interface, pinout:
 - Installation 78*
 - connecting:
 - Installation 57*
 - external supervisory interface, pinout:
 - Installation 64*
 - external test access interface, pinout:
 - Installation 66*
 - fan:
 - Installation 22, 30*
 - G.703 interface, pinout:
 - Installation 76*
 - ISDN U-interface, pinout:
 - Installation 70*
 - power supply:
 - Installation 22, 30*
 - PSTN interface, pinout:
 - Installation 68–70*
 - Q1/AUX management interface, pinout:
 - Installation 63*
 - Q3 interface, pinout:
 - Installation 64*
 - signalling voltage:
 - Installation 22, 30*
 - service switch:
 - Installation 22, 30*
 - station alarm:
 - Installation 22, 30*
 - SV1 measurement:
 - Installation 22, 30*
 - symmetrical 2 Mbit/s interface, pinout:
 - Installation 78*
 - synchronisation interface, pinout:
 - Installation 79–81*
 - test bus:
 - Installation 22, 30*
 - TR2M4 2 Mbit/s interface:
 - Installation 72*
 - V.xx interface, pinout:
 - Installation 74*
 - viewing:
 - Comm. and Maintenance 55*
 - X.21 interface, pinout:
 - Installation 75*
- ISDN
 - configuring user ports:
 - Comm. and Maintenance 56*
 - DEG alarm:
 - Comm. and Maintenance 53*
 - line feeding voltage:
 - Comm. and Maintenance 51;*
Country Specific Instr. 11
 - maximum power:
 - Comm. and Maintenance 52*

- ISDN BRA unit, features:
 - Product Description* 45
- ISDN interfaces, configuring:
 - Comm. and Maintenance* 51
- ISDN loopback tests:
 - Comm. and Maintenance* 82
- ISDN remote tests:
 - Comm. and Maintenance* 84
- ISDN U-interface, connector pinout:
 - Installation* 70
- ISDN unit
 - connectors:
 - Installation* 67
 - power consumption:
 - Country Specific Instr.* 11–15
- ISDN user ports, configuring:
 - Comm. and Maintenance* 56
- J**
 - jumper settings
 - 17-slot subrack:
 - Installation* 20
 - 8-slot cartridge:
 - Installation* 28
 - jumpers, default positions:
 - Installation* 21, 29
- L**
 - L3 addresses:
 - Comm. and Maintenance* 58
 - L3AD:
 - Comm. and Maintenance* B-18, B-19, B-21
 - laser safety:
 - Installation* 3
 - leased line applications:
 - Product Description* 9
 - leased line bank:
 - Comm. and Maintenance* 68;
 - Product Description* 10
 - managing:
 - Comm. and Maintenance* 70
 - leased lines
 - commissioning procedure:
 - Comm. and Maintenance* 14
 - commissioning requirements:
 - Comm. and Maintenance* 13
 - configuring:
 - Comm. and Maintenance* 67
 - deleting:
 - Comm. and Maintenance* 70
 - editing:
 - Comm. and Maintenance* 68
 - LEDs
 - flashing:
 - Comm. and Maintenance* 95
 - green:
 - Comm. and Maintenance* 94
 - red:
 - Comm. and Maintenance* 94
 - yellow:
 - Comm. and Maintenance* 94
 - levels, input and output:
 - Country Specific Instr.* 4, 10
 - LGOF:
 - Comm. and Maintenance* B-8
 - LID:
 - Comm. and Maintenance* B-18
 - line attenuation:
 - Country Specific Instr.* 10
 - line coding types in ISDN BRA:
 - Product Description* 45
 - line feeding settings, PSTN:
 - Country Specific Instr.* 3, 4, 8
 - line lengths, recommended for PSTN:
 - Country Specific Instr.* 10
 - Line Test Manager:
 - Product Description* 29
 - line testing
 - See also* LMU; on-demand line tests, scheduled line tests
 - features supported:
 - Product Description* 13
 - scheduled:
 - Product Description* 13
 - tests supported:
 - Comm. and Maintenance* 78
 - Link Control Protocol Syntax Error:
 - Comm. and Maintenance* B-8
 - Link Control Protocol Time Out:
 - Comm. and Maintenance* B-8
 - link ID:
 - Comm. and Maintenance* 41
 - LMU
 - connector pinout. *See* connector pinout, NCU
 - connectors:
 - Installation* 65
 - features:
 - Product Description* 44
 - function:
 - Product Description* 44

loading data from file:
Comm. and Maintenance A-17–A-19

locking clamps:
Installation 86

LOF:
Comm. and Maintenance B-9

LOFS:
Comm. and Maintenance B-10

Log Overflow:
Comm. and Maintenance B-8

loopback tests
aborting:
Comm. and Maintenance 85

cancelling:
Comm. and Maintenance 85

DIU:
Comm. and Maintenance 85

ISDN:
Comm. and Maintenance 82

Loss of Frame:
Comm. and Maintenance B-9

Loss of Multiframe:
Comm. and Maintenance B-9

Loss of Octet Timing:
Comm. and Maintenance B-9

Loss of Signal:
Comm. and Maintenance B-10–B-12

Loss of Timing Information:
Comm. and Maintenance B-11

Loss of V.110 Frame Synchronisation:
Comm. and Maintenance B-10

LOT:
Comm. and Maintenance B-9

LTI:
Comm. and Maintenance B-11

M

MAIN:
Comm. and Maintenance B-11

main application window:
Comm. and Maintenance A-11

main earthing bar (MEB):
Installation 49

main menus of Eksos N20 Node Manager:
Comm. and Maintenance A-20

Maintenance State:
Comm. and Maintenance B-11

Manage Node window:
Comm. and Maintenance 20

management channels, setting:
Comm. and Maintenance 29

management tools
Line Test Manager:
Product Description 29

Node Manager:
Product Description 28

Nokia NMS:
Product Description 28

OSI-DCN Adaptor:
Product Description 30

mapping, V5.2, selecting:
Comm. and Maintenance 43

marking accessories, recommended:
Installation 13

MEB. *See* main earthing bar

MISM:
Comm. and Maintenance B-16

MISS:
Comm. and Maintenance B-16

mounting
cable tray to rack:
Installation 54–56

Fan Unit:
Installation 105

strain reliefs:
Installation 11

mounting brackets:
Installation 105
in earthing:
Installation 50

multihosting:
Product Description 7, 22

N

natural convection:
Product Description 40

NCU
connector pinout:
Installation 61–65
connectors:
Installation 60
features:
Product Description 43
interfaces:
Product Description 43
power consumption:
Country Specific Instr. 5

network terminals supported:
Product Description 11

- node address:
 - Comm. and Maintenance* 22
 - node applications
 - leased line:
 - Product Description* 25
 - scheduled line testing:
 - Product Description* 26
 - service switch:
 - Product Description* 24
 - V5.1 to V5.2 converter:
 - Product Description* 24
 - V5.2 multiplexer:
 - Product Description* 22
 - node architecture:
 - Product Description* 34
 - node clock
 - calibrating:
 - Comm. and Maintenance* 27
 - real time:
 - Comm. and Maintenance* 22
 - Node Control Unit. *See* NCU
 - node data
 - clearing configuration:
 - Comm. and Maintenance* 91
 - editing:
 - Comm. and Maintenance* A-14
 - printing:
 - Comm. and Maintenance* A-18
 - saving:
 - Comm. and Maintenance* A-15–A-18
 - node information, updating:
 - Comm. and Maintenance* 23
 - node installation wizard:
 - Comm. and Maintenance* 20
 - Node Manager:
 - Product Description* 28
 - aborting an operation:
 - Comm. and Maintenance* A-19
 - access levels:
 - Comm. and Maintenance* A-7
 - alarm management:
 - Comm. and Maintenance* 96
 - closing connection to node:
 - Comm. and Maintenance* 89
 - closing down:
 - Comm. and Maintenance* 90
 - connecting cable to node:
 - Comm. and Maintenance* 18
 - connecting to node:
 - Comm. and Maintenance* 20
 - directory structure:
 - Comm. and Maintenance* A-2
 - FAQs:
 - Comm. and Maintenance* A-10
 - installation procedure:
 - Comm. and Maintenance* A-4
 - main menus:
 - Comm. and Maintenance* A-20
 - operating:
 - Comm. and Maintenance* A-13
 - overview:
 - Comm. and Maintenance* A-11
 - starting:
 - Comm. and Maintenance* 19
 - system requirements:
 - Product Description* 66
 - toolbar icons:
 - Comm. and Maintenance* A-12
 - troubleshooting installation:
 - Comm. and Maintenance* A-10
 - troubleshooting operation:
 - Comm. and Maintenance* A-19–A-21
 - node settings
 - changing:
 - Comm. and Maintenance* 24
 - viewing:
 - Comm. and Maintenance* 24
 - node size:
 - Product Description* 7
 - Node Subrack window:
 - Comm. and Maintenance* 19, A-11
 - uses:
 - Comm. and Maintenance* A-11
 - Nokia Applications folder:
 - Comm. and Maintenance* A-3
 - Nokia TP4 Protocol Stack dialog box:
 - Comm. and Maintenance* A-6
 - NOKIAMGR folder:
 - Comm. and Maintenance* A-2
 - normal feed, PSTN:
 - Country Specific Instr.* 8
 - NSAP address:
 - Comm. and Maintenance* 22, A-5
 - changing:
 - Comm. and Maintenance* A-7
 - updating:
 - Comm. and Maintenance* 23
- ## O
- on-demand line tests
 - See also* line testing
 - DIU loopback:
 - Comm. and Maintenance* 85
 - ISDN loopback tests:
 - Comm. and Maintenance* 82

ISDN remote:
 Comm. and Maintenance 84
performing:
 Comm. and Maintenance 80
online help:
 Comm. and Maintenance A-14
operating voltages, PSTN:
 Country Specific Instr. 4
optical fibres
 and strain reliefs:
 Installation 15
 bending radius:
 Installation 15
 cable reels:
 Installation 15, 17
 guiding tubes:
 Installation 16
 handling:
 Installation 15
 laying:
 Installation 15
 precautions:
 Installation 5
 routing:
 Installation 11, 15, 16
 types:
 Installation 58
order codes, marking accessories:
 Installation 13
ordering documents:
 Guide to Documentation 4
OSI-DCN Adaptor:
 Product Description 30

P

PBKN:
 Comm. and Maintenance B-8
performance monitoring
 configuring:
 Comm. and Maintenance 74
 viewing data:
 Comm. and Maintenance 75
 viewing history data:
 Comm. and Maintenance 76
pins. *See* connector pinout
plug-in units
 cabling:
 Installation 88
 how to handle:
 Installation 4, 85
 installing in a node:
 Comm. and Maintenance 24–26
 installing into subrack:
 Installation 86–88

installing, work procedure:
 Installation 81
uninstalling:
 Comm. and Maintenance 24
unit locations:
 Installation 82–85
polarity reversal time, PSTN:
 Country Specific Instr. 9
Port Control Protocol Layer 3 Address Error:
 Comm. and Maintenance B-12
POW:
 Comm. and Maintenance B-12
power cables:
 Installation 21, 29
power consumption
 ISDN:
 Country Specific Instr. 11–15
 NCU:
 Country Specific Instr. 5
 PSTN:
 Country Specific Instr. 5
Power Problem:
 Comm. and Maintenance B-12
power supply
 connecting:
 Installation 19
 distribution:
 Installation 20
power supply options
 DC-PSA:
 Product Description 36
 Extension Unit:
 Product Description 36
power supply panel:
 Installation 22, 30
powering the node:
 Comm. and Maintenance 17
PPO:
 Comm. and Maintenance B-12
precautions
 anti-static:
 Installation 4, 7
 electrical cables:
 Installation 5
 handling plug-in units:
 Installation 4
 laser safety:
 Installation 3
 optical fibres:
 Installation 5
 sensitivity to electro-static discharge (ESD):
 Installation 4

- primary link:
 - Comm. and Maintenance* 43
 - Primary Power Out:
 - Comm. and Maintenance* B-12
 - printing data:
 - Comm. and Maintenance* A-18
 - priority
 - alarm:
 - Comm. and Maintenance* 95
 - synchronisation:
 - Comm. and Maintenance* 26
 - priviledges, user:
 - Comm. and Maintenance* A-7
 - product release, definition:
 - Glossary* Glossary-8
 - PROT:
 - Comm. and Maintenance* B-17, B-19
 - protecting signalling:
 - Comm. and Maintenance* 43
 - Protection Protocol Syntax Error:
 - Comm. and Maintenance* B-12
 - Protection Protocol Time Out:
 - Comm. and Maintenance* B-13
 - PSTN
 - line feeding settings:
 - Country Specific Instr.* 3, 4, 8
 - power consumption:
 - Country Specific Instr.* 5
 - technical specifications:
 - Country Specific Instr.* 3
 - PSTN interface, connector pinout:
 - Installation* 68–70
 - PSTN interfaces, configuring:
 - Comm. and Maintenance* 49
 - PSTN mapping:
 - Country Specific Instr.* 15
 - PSTN unit
 - connectors:
 - Installation* 67
 - features:
 - Product Description* 44
- Q**
- Q1 management interface, connector pinout:
 - Installation* 63
 - Q1 Not Supported:
 - Comm. and Maintenance* B-13
 - Q1 stack, configuring:
 - Comm. and Maintenance* 31
 - Q1NS:
 - Comm. and Maintenance* B-13
 - Q3 interface:
 - Comm. and Maintenance* 18;
 - Product Description* 43
 - Q3 management interface, connector pinout:
 - Installation* 64
 - Q3 stack, configuring:
 - Comm. and Maintenance* 29
- R**
- rack, capacity:
 - Installation* 34
 - rack alarms:
 - Comm. and Maintenance* 95
 - rack earthing:
 - Installation* 49
 - rack grounding:
 - Installation* 49
 - real time clock:
 - Comm. and Maintenance* 22
 - receiving data from the node
 - auto refresh:
 - Comm. and Maintenance* A-14
 - manually:
 - Comm. and Maintenance* A-14–A-16
 - recommendations
 - PSTN mapping:
 - Country Specific Instr.* 15
 - recommendations, international:
 - Product Description* 67
 - reconfiguring a node:
 - Comm. and Maintenance* 91
 - reconnecting to a node:
 - Comm. and Maintenance* A-19
 - release, definition:
 - Glossary* Glossary-9
 - Remote Defect Indication:
 - Comm. and Maintenance* B-13
 - Remote Power Feeding Unit Overload:
 - Comm. and Maintenance* B-13
 - remote upgrade, cabling:
 - Installation* 95
 - Restart Time Out:
 - Comm. and Maintenance* B-14
 - ringing cadences:
 - Country Specific Instr.* 15

- routing
 - cables:
 - Installation* 11
 - optical fibres:
 - Installation* 11
- RPFO:
 - Comm. and Maintenance* B-13
- S**
- SAN CORE2M unit:
 - Installation* 77
 - connecting to Eksos N20:
 - Installation* 91–94
 - connector pinout:
 - Installation* 78–81
 - connectors:
 - Installation* 77
- Save Configuration Data dialog box:
 - Comm. and Maintenance* A-15
- saving node data:
 - Comm. and Maintenance* A-15–A-18
- scheduled line testing:
 - Product Description* 13, 26
 - commissioning:
 - Comm. and Maintenance* 14
 - commissioning procedure:
 - Comm. and Maintenance* 15
 - commissioning requirements:
 - Comm. and Maintenance* 14
 - test types:
 - Product Description* 15, 16
- scheduled line tests
 - See also* line testing
 - creating and editing:
 - Comm. and Maintenance* 86
 - setting threshold values:
 - Comm. and Maintenance* 88
 - viewing results:
 - Comm. and Maintenance* 88
 - viewing summary:
 - Comm. and Maintenance* 89
- SDH application:
 - Product Description* 6
- Secondary Power Out:
 - Comm. and Maintenance* B-14
- security
 - enabling:
 - Comm. and Maintenance* A-7–A-9
 - user access levels:
 - Comm. and Maintenance* A-7
- sending data to the node:
 - Comm. and Maintenance* 24, A-14
- Server Signal Fail:
 - Comm. and Maintenance* B-14
- service connector panel:
 - Comm. and Maintenance* 18
 - installation:
 - Installation* 40
- service LEDs, operation:
 - Comm. and Maintenance* 94
- service protection:
 - Product Description* 12
- service switch
 - commissioning procedure:
 - Comm. and Maintenance* 11
 - commissioning requirements:
 - Comm. and Maintenance* 11
 - configuring:
 - Comm. and Maintenance* 61
 - configuring cabling:
 - Comm. and Maintenance* 62
 - connecting cables:
 - Installation* 95–98
 - upgrade wiring:
 - Installation* 95
- service switching:
 - Product Description* 12
 - general rules:
 - Comm. and Maintenance* 63–65
- shielding foil, grounding:
 - Installation* 11
- signalling interfaces:
 - Product Description* 7
- Signalling Voltage Failure:
 - Comm. and Maintenance* B-14
- signalling, V5.1, configuring:
 - Comm. and Maintenance* 47
- signalling, V5.2, configuring:
 - Comm. and Maintenance* 43
- software downloads:
 - Comm. and Maintenance* 101
- software upgrades:
 - Product Description* 51
- specifications
 - cartridge extension board connectors:
 - Product Description* 60
 - environmental:
 - Product Description* 62
 - mechanical:
 - Product Description* 59
 - subrack extension board connectors:
 - Product Description* 59

- specifications, technical
 - EMC emission:
 - Product Description* 64
 - EMC immunity:
 - Product Description* 63
 - interfaces:
 - Product Description* 53
 - line tests:
 - Product Description* 57
 - power consumption:
 - Product Description* 59
 - speech settings, configuring:
 - Comm. and Maintenance* 49
 - SPO:
 - Comm. and Maintenance* B-14
 - stack settings, changing:
 - Comm. and Maintenance* A-6
 - Startup Failure:
 - Comm. and Maintenance* B-15
 - station alarms:
 - Comm. and Maintenance* 95
 - connecting:
 - Installation* 19
 - disabling:
 - Comm. and Maintenance* 32–34
 - enabling:
 - Comm. and Maintenance* 32–34
 - station earthing:
 - Installation* 47
 - station ground:
 - Installation* 47
 - strain reliefs
 - and optical fibres:
 - Installation* 15
 - installing:
 - Installation* 12
 - mounting:
 - Installation* 11
 - subrack
 - construction:
 - Installation* 33
 - earthing:
 - Installation* 50
 - grounding:
 - Installation* 50
 - installing:
 - Installation* 33
 - installing into Wall Mounting Set:
 - Installation* 38
 - mounting brackets:
 - Installation* 33, 36
 - mounting to rack:
 - Installation* 34–37
 - unit locations:
 - Installation* 83
 - subrack extension board:
 - Installation* 22
 - subrack extension board connectors, specifications:
 - Product Description* 59
 - subrack front cover, installing:
 - Installation* 108
 - subracks, Eksos N20:
 - Product Description* 47
 - dimensions:
 - Product Description* 48
 - subscriber private metering:
 - Country Specific Instr.* 15
 - SVF:
 - Comm. and Maintenance* B-14
 - symmetrical 2 Mbit/s interface, connector pinout:
 - Installation* 78
 - synchronisation, priority:
 - Comm. and Maintenance* 26
 - Synchronisation Forced:
 - Comm. and Maintenance* B-15
 - synchronisation interfaces, connector pinout:
 - Installation* 62
 - synchronisation interfaces (ST, SR), connector pinout:
 - Installation* 79–81
 - synchronisation settings, configuring:
 - Comm. and Maintenance* 26
 - Synchronisation window:
 - Comm. and Maintenance* 26
 - SYNT:
 - Comm. and Maintenance* B-2, B-3, B-8, B-12, B-17, B-19, B-20, B-21
 - SYSTEM folder:
 - Comm. and Maintenance* A-2
 - system release, definition:
 - Glossary Glossary-10*
 - System Release Item List, key:
 - System Rel. Notes* 8
 - SYSTEM32 folder:
 - Comm. and Maintenance* A-3
- ## T
- TAE:
 - Comm. and Maintenance* B-15
 - terms. *See* Glossary
 - TEST:
 - Comm. and Maintenance* B-7

THC:

Comm. and Maintenance B-15

thermal management

cable trays:

Product Description 50

in cabinets:

Product Description 42

in open racks:

Product Description 40

principles:

Product Description 36–40

Threshold Crossed:

Comm. and Maintenance B-15

threshold values for scheduled tests:

Comm. and Maintenance 88

time slots, viewing:

Comm. and Maintenance 55

Time-out Activation Error:

Comm. and Maintenance B-15

toolbar icons in Node Manager:

Comm. and Maintenance A-12

TOUT:

Comm. and Maintenance B-3, B-8, B-13, B-14, B-17, B-19, B-20, B-21

TR2M4, use:

Product Description 46

TR2M4 unit

connector pinout:

Installation 72

connectors:

Installation 71

tributary units

adding:

Comm. and Maintenance 99

removing:

Comm. and Maintenance 100

replacing:

Comm. and Maintenance 100

restoring settings:

Comm. and Maintenance 100

troubleshooting:

System Rel. Notes 5

installing Node Manager:

Comm. and Maintenance A-10

operating Node Manager:

Comm. and Maintenance A-19–A-21

typographic conventions:

Guide to Documentation 5

U

ugrading, from C1.1 to C2.0:

System Rel. Notes 3

unbalanced interface:

Installation 93–95

uninstalling a unit:

Comm. and Maintenance 24

Unit Failure:

Comm. and Maintenance B-16

unit locations

in cartridge:

Installation 84

in subrack:

Installation 83

Unit Mismatch:

Comm. and Maintenance B-16

Unit Missing:

Comm. and Maintenance B-16

unit slot coding block:

Installation 82

updating node information:

Comm. and Maintenance 23

upgrading, software from C1.1 to C2.0:

Comm. and Maintenance 101

upgrading software:

Product Description 51

user access levels:

Comm. and Maintenance A-7

setting up:

Comm. and Maintenance A-9

user ports

blocking, unblocking, cancelling:

Comm. and Maintenance 58

configuring:

Comm. and Maintenance 56

Ux 2M window:

Comm. and Maintenance 25

V

V.xx interface, connector pinout:

Installation 74

V5 BCC Protocol Data Link Failure:

Comm. and Maintenance B-16

V5 BCC Protocol Time Out:

Comm. and Maintenance B-17

V5 Common Control Protocol Syntax Error:

Comm. and Maintenance B-17

V5 Control Protocol Data Link Failure:

Comm. and Maintenance B-17

V5 interface

configuring:

Comm. and Maintenance 37

- creating:
 - Comm. and Maintenance* 45
 - deleting:
 - Comm. and Maintenance* 60
 - editing:
 - Comm. and Maintenance* 60
 - modifying:
 - Comm. and Maintenance* 60
 - starting:
 - Comm. and Maintenance* 59
 - stopping:
 - Comm. and Maintenance* 59
 - V5 interfaces:
 - Product Description* 7
 - V5 Link Control Protocol Data Link Failure:
 - Comm. and Maintenance* B-18
 - V5 Link Control Protocol Error while "Out of Service":
 - Comm. and Maintenance* B-17
 - V5 Link Control Protocol Layer 3 Address Error:
 - Comm. and Maintenance* B-18
 - V5 Link Identification Failure:
 - Comm. and Maintenance* B-18
 - V5 Persistent Link Control Protocol Layer 3 Address Error:
 - Comm. and Maintenance* B-18
 - V5 Port Control Protocol Error while "Out of Service":
 - Comm. and Maintenance* B-19
 - V5 Port Control Protocol Layer 3 Address Error:
 - Comm. and Maintenance* B-19
 - V5 Port Control Protocol Syntax Error:
 - Comm. and Maintenance* B-19
 - V5 Port Control Protocol Timer Expiration Error:
 - Comm. and Maintenance* B-19
 - V5 Protection Protocol Data Link Failure:
 - Comm. and Maintenance* B-20
 - V5 Protection Protocol Syntax Error:
 - Comm. and Maintenance* B-20
 - V5 Protection Protocol Timer Expiration Error:
 - Comm. and Maintenance* B-20
 - V5 PSTN Protocol Data Link Failure:
 - Comm. and Maintenance* B-20
 - V5 PSTN Protocol Layer 3 Address Error:
 - Comm. and Maintenance* B-21
 - V5 PSTN Protocol Syntax Error:
 - Comm. and Maintenance* B-21
 - V5 PSTN Protocol Time Out:
 - Comm. and Maintenance* B-21
 - V5.1 interface
 - configuring:
 - Comm. and Maintenance* 45
 - starting:
 - Comm. and Maintenance* 59
 - V5.1 to V5.2 conversion:
 - Product Description* 8, 24
 - application requirements:
 - Product Description* 24
 - V5.1/V5.2 converter
 - commissioning:
 - Comm. and Maintenance* 9–11
 - commissioning procedure:
 - Comm. and Maintenance* 10
 - commissioning requirements:
 - Comm. and Maintenance* 9
 - V5.2 interface
 - configuring:
 - Comm. and Maintenance* 37
 - starting:
 - Comm. and Maintenance* 59
 - V5.2 multiplexer
 - commissioning:
 - Comm. and Maintenance* 6
 - commissioning procedure:
 - Comm. and Maintenance* 7–9
 - requirements for commissioning:
 - Comm. and Maintenance* 6
 - V5S:
 - Comm. and Maintenance* B-15
 - vital signalling:
 - Comm. and Maintenance* 43
 - Vital Standby signalling:
 - Comm. and Maintenance* 43
 - voltages, used by PSTN:
 - Country Specific Instr.* 4
- ## W
- Wall Mounting Set:
 - Product Description* 50
 - installing subrack:
 - Installation* 37
 - weights of units & accessories:
 - Product Description* 61
 - windows, closing:
 - Comm. and Maintenance* 89
 - wiring
 - after service is switched:
 - Installation* 99
 - service switch:
 - Installation* 95

wrist strap:
Installation 85

X

X.21 interface, connector pinout:
Installation 75
