

SIMtrace - Feature #1436

add VCC_PHONE to an unused GPIO

02/19/2016 10:48 PM - laforge

Status:	Closed	Start date:	
Priority:	Normal	Due date:	
Assignee:	tsaitgaist	% Done:	0%
Category:	SIMtrace hardware		
Target version:			
Spec Reference:			
Description			
this way we can get an interrupt in software once the phone turns on VCC.			

History

#1 - 06/19/2011 01:11 PM - tsaitgaist

- Resolution set to fixed

done in PC v0.9.8 (pin 27)

#2 - 02/20/2016 06:42 PM - laforge

- Project changed from OsmocomBB to SIMtrace

- Category changed from 244 to SIMtrace hardware