

SDR (Software Defined Radio) - Support #2764

osmocom_fft & siggen can't access the X display

12/15/2017 06:09 PM - fzy139

Status: New	Start date: 12/15/2017
Priority: Normal	Due date:
Assignee:	% Done: 0%
Category:	
Target version:	
Resolution:	Spec Reference:
Description Hi, Using the RaspberryPi 3b Debian. BladeRF x40 Have build the GROSmosdr without error. Now when I type the command in terminal,there is no graph of fft appear. This error happened: Client is not authorized to connect to ServerUnable to access the X display,is display set properly? And I'm already build the libbladeRF and it's appeared in my enabled components. thanks!	